



Quick Setup Guide – IFM OGD550 (FSWB Machine Only)

Setpoints:

- SP1 = 360 mm
- SP2 = 515 mm

1. Wiring Connections (M12, 4-wire)

Brown – +24 VDC (Power +)

Blue – 0 VDC (Power –)

Black – Jam Sensor Input

White – Bucket Door Sensor Input

Note: Refer to the machine's electrical schematics for actual terminal numbers.

Important: OUT2 (Bucket Door Sensor) should only be ON when the bucket door is fully closed.

2. Output Mode Setup

- OUT1 → PNP / NO
- OUT2 → PNP / NO

3. Set Distance Setpoints

- SP1 (Output 1) = 360 mm
- SP2 (Output 2) = 515 mm

4. Verification

- At 360 mm: Black wire output = ON (Jam Sensor)
- At 515 mm: White wire output = ON (Bucket Door Sensor)
- Out of range: Both OFF

Installer Notes

- Clean lens before powering up.
- If readings are unstable, adjust alignment or reduce ambient light.