

# Manage access-control roles

ONTAP 9

NetApp May 03, 2022

This PDF was generated from https://docs.netapp.com/us-en/ontap/authentication/manage-access-control-roles-concept.html on May 03, 2022. Always check docs.netapp.com for the latest.

# **Table of Contents**

Mana	age access-control roles
Ma	anage access-control roles overview
Mo	odify the role assigned to an administrator
De	efine custom roles
Pr	edefined roles for cluster administrators
Pr	edefined roles for SVM administrators

## Manage access-control roles

## Manage access-control roles overview

The role assigned to an administrator determines the commands to which the administrator has access. You assign the role when you create the account for the administrator. You can assign a different role or define custom roles as needed.

## Modify the role assigned to an administrator

You can use the security login modify command to change the role of a cluster or SVM administrator account. You can assign a predefined or custom role.

### What you'll need

You must be a cluster administrator to perform this task.

### Step

1. Change the role of a cluster or SVM administrator:

security login modify -vserver SVM\_name -user-or-group-name user\_or\_group\_name -application application -authmethod authentication\_method -role role -comment comment

For complete command syntax, see the worksheet.

### Creating or modifying login accounts

The following command changes the role of the AD cluster administrator account <code>DOMAIN1\guest1</code> to the predefined <code>readonly</code> role.

```
cluster1::>security login modify -vserver engCluster -user-or-group-name
DOMAIN1\guest1 -application ssh -authmethod domain -role readonly
```

The following command changes the role of the SVM administrator accounts in the AD group account DOMAIN1\adgroup to the custom vol role role.

```
cluster1::>security login modify -vserver engData -user-or-group-name
DOMAIN1\adgroup -application ssh -authmethod domain -role vol role
```

### **Define custom roles**

You can use the security login role create command to define a custom role. You can execute the command as many times as necessary to achieve the exact combination of capabilities that you want to associate with the role.

### What you'll need

You must be a cluster administrator to perform this task.

#### About this task

 A role, whether predefined or custom, grants or denies access to ONTAP commands or command directories.

A command directory (volume, for example) is a group of related commands and command subdirectories. Except as described in this procedure, granting or denying access to a command directory grants or denies access to each command in the directory and its subdirectories.

· Specific command access or subdirectory access overrides parent directory access.

If a role is defined with a command directory, and then is defined again with a different access level for a specific command or for a subdirectory of the parent directory, the access level that is specified for the command or subdirectory overrides that of the parent.



You cannot assign an SVM administrator a role that gives access to a command or command directory that is available only to the admin cluster administrator—for example, the security command directory.

### Step

1. Define a custom role:

```
security login role create -vserver SVM_name -role role -cmddirname command or directory name -access access level -query query
```

For complete command syntax, see the worksheet.

The following commands grant the vol\_role role full access to the commands in the volume command directory and read-only access to the commands in the volume snapshot subdirectory.

```
cluster1::>security login role create -role vol_role -cmddirname
"volume" -access all

cluster1::>security login role create -role vol_role -cmddirname "volume
snapshot" -access readonly
```

The following commands grant the SVM\_storage role read-only access to the commands in the storage command directory, no access to the commands in the storage encryption subdirectory, and full access to the storage aggregate plex offline nonintrinsic command.

```
cluster1::>security login role create -role SVM_storage -cmddirname
"storage" -access readonly

cluster1::>security login role create -role SVM_storage -cmddirname
"storage encryption" -access none

cluster1::>security login role create -role SVM_storage -cmddirname
"storage aggregate plex offline" -access all
```

### Predefined roles for cluster administrators

The predefined roles for cluster administrators should meet most of your needs. You can create custom roles as necessary. By default, a cluster administrator is assigned the predefined admin role.

The following table lists the predefined roles for cluster administrators:

This role	Has this level of access	To the following commands or command directories
admin	all	All command directories ( DEFAULT)
autosupport	all	• set • system node autosupport
	none	All other command directories (DEFAULT)
backup	all	vserver services ndmp
	readonly	volume
	none	All other command directories (DEFAULT)
readonly	all	• security login password • set
	none	security
	readonly	All other command directories (DEFAULT)

none	none	All command directories (
		DEFAULT)



The autosupport role is assigned to the predefined autosupport account, which is used by AutoSupport OnDemand. ONTAP prevents you from modifying or deleting the autosupport account. ONTAP also prevents you from assigning the autosupport role to other user accounts.

### Predefined roles for SVM administrators

The predefined roles for SVM administrators should meet most of your needs. You can create custom roles as necessary. By default, an SVM administrator is assigned the predefined vsadmin role.

The following table lists the predefined roles for SVM administrators:

Role name	Capabilities
vsadmin	Managing own user account local password and key information
	Managing volumes, except volume moves
	<ul> <li>Managing quotas, qtrees, Snapshot copies, and files</li> </ul>
	Managing LUNs
	<ul> <li>Performing SnapLock operations, except privileged delete</li> </ul>
	<ul> <li>Configuring protocols: NFS, SMB, iSCSI, and FC. including FCoE</li> </ul>
	Configuring services: DNS, LDAP, and NIS
	Monitoring jobs
	Monitoring network connections and network interface
	Monitoring the health of the SVM

vsadmin-volume	<ul> <li>Managing own user account local password and key information</li> </ul>
	Managing volumes, including volume moves
	<ul> <li>Managing quotas, qtrees, Snapshot copies, and files</li> </ul>
	Managing LUNs
	<ul> <li>Configuring protocols: NFS, SMB, iSCSI, and FC, including FCoE</li> </ul>
	<ul> <li>Configuring services: DNS, LDAP, and NIS</li> </ul>
	Monitoring network interface
	Monitoring the health of the SVM
vsadmin-protocol	Managing own user account local password and key information
	<ul> <li>Configuring protocols: NFS, SMB, iSCSI, and FC, including FCoE</li> </ul>
	<ul> <li>Configuring services: DNS, LDAP, and NIS</li> </ul>
	Managing LUNs
	Monitoring network interface
	Monitoring the health of the SVM
vsadmin-backup	Managing own user account local password and key information
	<ul> <li>Managing NDMP operations</li> </ul>
	Making a restored volume read/write
	<ul> <li>Managing SnapMirror relationships and Snapshot copies</li> </ul>
	Viewing volumes and network information
vsadmin-snaplock	Managing own user account local password and key information
	<ul> <li>Managing volumes, except volume moves</li> </ul>
	<ul> <li>Managing quotas, qtrees, Snapshot copies, and files</li> </ul>
	<ul> <li>Performing SnapLock operations, including privileged delete</li> </ul>
	Configuring protocols: NFS and SMB
	<ul> <li>Configuring services: DNS, LDAP, and NIS</li> </ul>
	Monitoring jobs
	<ul> <li>Monitoring network connections and network interface</li> </ul>

vsadmin-readonly	<ul> <li>Managing own user account local password and key information</li> </ul>
	<ul> <li>Monitoring the health of the SVM</li> </ul>
	<ul> <li>Monitoring network interface</li> </ul>
	<ul> <li>Viewing volumes and LUNs</li> </ul>
	<ul> <li>Viewing services and protocols</li> </ul>

### **Copyright Information**

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

### **Trademark Information**

NETAPP, the NETAPP logo, and the marks listed at <a href="http://www.netapp.com/TM">http://www.netapp.com/TM</a> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.