## USER GUIDE AirQu

Display Temperature

Display Gas

Indoor Air
Quality



Humidity

Pressure

## **How to Use AirQu**

- 1. Install Blynk app in your mobile phone. The app could be downloaded using app store or play store.
- 2. Create an account in the Blynk app
- 3. Scan our QR Code to gain access to AirQu code and insert your Wi-Fi SSID and password inside the code.
- 4. Customize your Blynk template
- 5. Upload the code
- 6. Start scanning using the sensor module and look the result in your Blynk app



