

## Instruction Manual for FrSky RX4R

1. Put the transmitter RF module into binding mode
Note: After binding procedure is completed, resupply the power and check if the
How to Switch FS mode/HS mode
Note: The SBUS output is 9ms, no matter HS/FS mode.
How to select output 1 ~ 4CH / 9 ~ 12CH
<u> </u>
FrSky Electronic Co., Ltd <u>www.frsky-rc.com</u> Contact us : <u>frsky@frsky-rc.com</u> Add:F-4,Building C, Zhongxiu Technology Park, No.3 Yuanxi Road, Wuxi, 214125, Jiangsu, China Technical Support: <u>sales4tech@gmail.com</u>