

Button explanations



Cycle Start

- Executes the G-Code loaded into memory.



Feed Hold

- Stops motion of all axis and outputs remain active
 - Press Cycle start to resume motion



Stop

- Stops all motion and turns off all outputs.



Regen. Tool Path

- Refreshes the toolpath




Change Display

- Toggles Tool Path view
- Machine boundary view
 - Part View



Jog Follow

- Toggles Tool Path view
- Locks Tool Path to display
 - Locks Tool to display



Tool Path Display

- Shows the Tool Paths of the currently loaded G-Code



Zero X

- Zeros the X axis DRO



Zero Y

- Zeros the Y axis DRO



Zero Z

- Zeros the Z axis DRO



Zero 4

- Zeros the 4 axis DRO

Reference all Home

Reference all home

- Seeks all home switches
- Sets absolute machine coordinates to Zero
 - Activates soft limits

Coordinates

Coordinates

- Toggles DRO view
- Absolute machine coordinates(red led)
- Relative machine coordinates(black led)

Soft Limits

Soft Limits

- Minimum and Maximum travel distances set by the software
 - Limitations on (green led)
 - Limitations off (black led)

Goto Zero's

- Go to Zeros
- Moves machine to current X and Y zero positions
 - Moves Z axis to Safe Z height

Goto Home

- Go to Home
- Moves machine to the defined Home position
 - Moves Z axis to Safe Z height

Dust Collector

- Turns Dust Collection System on/off
 - Dust collection on (green led)
 - Dust collection off (black led)

Spindle

- Turns Spindle On/Off
- Spindle on (green led)
- Spindle off (black led)

Vacuum Bed

- Turns on Vacuum Pump
- Vacuum Pump on (green led)
- Vacuum Pump off (black led)

Rewind G-Code

Rewind G-Code

- Rewinds current G-Code to the beginning.

Close G-Code

Close G-Code

- Closes current G-Code that is loaded into memory.



Load G-Code

Load G-Code

- Allows you to browse and select the G-code file.



Single Block

Single Block

- Executes a single line of code and then enters feed hold
- Continues to the next line when cycle start is pressed



Edit G-Code

Edit G-Code

- Allows the currently loaded G-code to be manually edited.



Recent G-Code

Recent G-Code

- Opens recently opened G-Code files.



Run From Line

Run From Line

- Starts the program at the current G-Code line
- Sets all modal states of the current G-Code
- Gives a preparatory move window for verification of position



Set Next Line


Set Next Line

- Sets the start point of the G-Code



Reset

- Activates controller (green led)
- Deactivates controller (green, red flashing led)




Clear

- Clears information from the status bar




Settings Screen

- Used for user settings



Diagnostics Screen

- Used for machine Diagnostics



Jog On/Off

- Enables Keyboard jogging (green led)
- Disables Keyboard jogging (black led)



Tool Change Position

- Moves spindle to the user defined tool change position



Auto Z Setter

- Automatic tool touch off for setting the Z axis Zero

Manual Data Input

- Used for Inputting and executing G-Code immediately



Feed Rate Decrease

- Decreases Feedrate of currently running G-Code



Feed Rate Reset

- Toggles the Feedrate override to 100%



Feed rate increase

- Increases Feedrate of currently running G-Code



Spindle Speed decrease

- Decreases the spindle speed of the currently running G-Code




Spindle Speed Reset

- Toggles the Spindle speed override to 100%




Spindle Speed increase

- Increases the spindle speed of the currently running G-Code



Program Run Screen

- Main Screen used for running the Machine



Tool Path Screen

- Used to display Tool Paths in a larger format



Manual Data Input Screen

- Used for Teach Mode



Work Offsets Screen

- Used for setting up work coordinate offsets