

ezROUTER

“Quality and Innovation”

Changing the Zero Location to the opposite end of the Machine

In Mach 3, select the “Config.” button at the top of the screen.

When the drop down appears select the “Homing/Limits” option.

- Change the original values in this window (Only change the values for the X & Y axis and the only changes needed to be made are under the Home Off. column) to the values used in the example below and select “OK”

- You will then go back to the “Config.” menu. This time when the drop down appears you will select “System Hotkeys”

In this window you must do the following to change the orientation of the travel direction! (Example: pressing the left arrow key makes the x-axis move to the right)

- Select X++ (using the arrow keys assign this button a direction!)
- Select X-- (using the arrow keys assign this button a direction!)
- Select Y++ (using the arrow keys assign this button a direction!)
- Select Y-- (using the arrow keys assign this button a direction!)

Once you have assigned each of the axis a button you must now click “OK” and exit the software for the changes to take effect.

Motor Home/SoftLimits

Entries are in setup units.

Axis	Reversed	Soft Max	Soft Min	Slow Zone	Home Off.	Home N...	Auto Zero	Speed %
X	✗	49.50	0.00	4.00	-49.50	✓	✓	10
Y	✓	100.00	0.00	4.00	-100.00	✓	✓	10
Z	✗	0.00	-20.00	2.00	0.0000	✗	✓	10
A	✗	100.00	0.00	4.00	0.0000	✓	✓	10
B	✗	0.00	0.00	8.00	0.0000	✓	✓	10
C	✗	0.00	0.00	0.00	0.0000	✗	✗	10

G28 home location coordinates

X 0 A 0
Y 0 B 0
Z 0 C 0

OK

Change the home offset to a negative value!