

Safety Precautions

(Read, understand and follow all instructions and warnings in instruction manual as well as those provided with recommended accessories.)

- Keep guards in place and in working order.
- Use recommended accessories only.
- Check damaged parts. (Before further use of a tool, a guard or other part that is damaged it should be carefully checked to determine that it will operate properly and perform its intended function.) A guard or other part that is damaged should be properly repaired or replaced by an authorized service.
- Keep work area clean. (Cluttered areas and benches invite injuries.)
- Consider work area environment. Do not operate in damp or wet locations. Keep work area well lit. Do not expose Ez-Router to rain. Do not use in presence of flammable liquids or gases.
- Keep children away. All visitors should be kept away from work area.
- Tools that are not in use should be kept in a secure location so that they are not accessible by anyone who isn't qualified to operate the equipment.
- Use the right tool. Do not force a small tool or attachment to do the job of a heavy duty tool. Do not use tools or accessories for purpose other than what they are intended for.
- Dress properly. Do not wear loose clothing or jewelry. They can be caught in moving parts. Wear protective hair covering to contain long hair.
- Use safety glasses whenever operating Ez-Router. Also use face or dust mask if operation is dusty.
- Secure work piece. Use clamps or a vise to hold work piece. It can be safer and it frees both hands to operate and control Ez-Router.
- Maintain Ez-Router with care. Keep tools sharp and clean for best and safest performance. Follow instructions for lubrication.
- Un-plug your ez-Router before servicing and when changing accessories.
- Remove adjusting keys and wrenches. Form a habit of checking to see that keys and adjusting wrenches are removed from tool before turning it on.
- Avoid unintentional starting. Be sure switch is OFF when plugging in.

- If your Ez-Router is used outdoors, use only extension cords intended for use outdoors and so marked.
- Use only Genuine ez-Router replacement parts. (www.ez-router.com)
- Never leave an Ez-Router running unattended. Turn power off.

Instructions & Recommendations for Safe Use of Router Bits

(Large diameter carbide-tipped routing tools can be dangerous when improperly used, so please read and fully understand the following guidelines before using any tool.)

- The overall performance and quality of a cut depends on speed (RPM), feed-rate, material type and amount of material being removed per pass. Small depth adjustments can be made to provide the desired finish of a cut.
- When using large diameter bits, make several passes, taking off a little material at a time. Do not attempt to make the full cut in one pass.
- When installing the router bit into the router be sure the router is off and the tool is straight and firmly tightened. Router bits should be completely inserted into the collet. The proper depth of the tool into the collet is determined by inserting the tool so that approximately .0625" of the tool shaft is visible. (Meaning from the beginning of the flute of the tool to the collet should be approximately .0625 (1/16")! Never partially insert the bit into the collet.
- Do not use a dull router bit. This results in a poor quality cut, excessive vibration, burning of certain types of materials, and possible chipping or breaking of the router bit. Sharp tools cut smoother, faster, and with less strain on both the router and the operator.
- Always push the off button on the router before changing router bits.
- As with all power tools, wear proper eye protection before changing the tooling and during machine operation
- Follow all instructions included with your router machine.