# **Foream Wireless Remote Control API**

Version 1.0.1

March 9,2016

# 1. System Command:

#### 1.1 AMBA\_GET\_DEVICEINFO

Message ID: msg\_id: 0x0000000b(11)

API Overview:

Description: This API is used to retrive information related to the camera device itself, such as the model name, serial number and firmware version.

Direction: From the APP to the camera.

Example:

Arguments:

{"token": TokenNumber, "msg\_id":11}

Successful return:

 $\label{local_compass} $$ {\tt "rval":0,"msg_id":11,"param":{\tt "model":"Compass","fw_ver":"Ver3.0.2.5","serial\_number":"86D $$ {\tt IGLLJONK4HP86"}} $$$ 

# 1.2 AMBA\_GET\_DEVICE\_STATUS

Message ID: msg\_id: 0x00000011(17)

API Overview:

Description: This API is used to retrive current status related to the camera device itself, such as

the recording status, capture mode etc..

Direction: From the APP to the camera.

Example:

Arguments:

{"token": TokenNumber, "msg\_id":17}

Successful return:

{"rval":0,"msg\_id":17,"param":{"vres":0,"pres":0,"adapter":1,"battery":0,"available":4528352,"capacity":7753728,"rec\_timelapse":0,"rec\_status":0,"capture\_mode":0}}

#### 1.3 AMBA\_GET\_ALL\_CURRENT\_SETTINGS

```
Message ID: msg_id: 0x00000003(3)
API Overview:
Description: This API is used to retrive all setting related to the camera device itself, such as the
video resolution, photo size etc.
Direction:
             From the APP to the camera.
Example:
Arguments:
{"token": TokenNumber, "msg_id":3}
Successful return:
{ "rval": 0, "msg_id": 3, "param": [ { "stream_out_type": "tcp" }, { "video_resolution": "1" },
{ "photo_size": "0" }, { "timelapse_interval": "0" }, { "timelapse_mode": "6" }, { "key_sensitivity":
"1" }, { "led": "0" }, { "ap_auto_start": "0" }, { "camera_auto_off": "1" }, { "ap_password":
"0987654321" } ] }
          AMBA_SET_SETTING
1.4
Message ID: msg_id: 0x00000002(2)
API Overview:
Description: This API is used to set the single setting related to the camera device itself, such as
the video resolution, photo size etc.
            From the APP to the camera.
Direction:
Example:
Arguments:
{"msg_id": 2,"param": "1","token": TokenNumber,"type": "video_resolution"}
```

{"msg\_id" : 2,"param" : "1234567890","token" : 1,"type" : "ap\_password"}

Successful return:

{ "rval": 0, "msg\_id": 2, "param": "1"}

{ "rval": 0, "msg\_id": 2, "param": "1234567890"}

#### 1.5 AMBA\_FORMAT

Message ID: msg\_id: 0x00000004(4)

API Overview:

Description: This API is used to format the camera SD card.

Direction: From the APP to the camera.

Example:

Arguments:

{"msg\_id" : 4,"param" : "D:","token" : 1}

Successful return: {"rval":0,"msg\_id":4}

#### 1.6 AMBA\_NOTIFICATION

Message ID: msg\_id: 0x00000007(7)

API Overview:

Description: Notifications are send from the camera to the APP to notify it of events, such as

manual button presses and task completions.

Direction: From the camera to APP

**Notification List:** 

start\_video\_record:start record button pressedstop\_video\_record:stop record button pressedstart\_photo\_capture:photo capture button pressed

**start\_photo\_timelapse**: start photo timelapse button pressed **start\_video\_timelapse**: start video timelapse button pressed

Example:{ "msg\_id": 7, "type": "start\_photo\_capture" }

switch\_to\_video\_timelapse\_mode: mode button pressed and switch to video timelapse mode
switch\_to\_photo\_timelapse\_mode: mode button pressed and switch to photo timelapse

mode

Example:{ "msg\_id": 7, "type": "switch\_to\_cap\_mode" }

6816}}

"photo\_taken","param":{"path":"/tmp/fuse\_d/DCIM/100MEDIA/IMGN0033.jpg","available":452 6816}}

**battery**: battery changed, and return the battery value

Example: { "msg\_id": 7, "type": "battery" ,"param": 40}

adapter: USB cabel connected

Example: { "msg\_id": 7, "type": "adapter" ,"param":0}

sd card status: card inserted or removed

Example: { "msg\_id": 7, "type": "sd\_card\_status" ,"param":"remove"} { "msg\_id": 7, "type": "sd\_card\_status" ,"param":"insert"}

#### **Error notification:**

STORAGE\_RUNOUT STORAGE\_IO\_ERROR LOW\_SPEED\_CARD CARD\_REMOVED

## 1.7 AMBA\_SWITCH\_RECORD\_MODE

Message ID: msg\_id: 0x0000012(18)

API Overview:

Description: This API is used to switch the capture mode to record mode.

Direction: From the APP to the camera.

Example:

Arguments:

{"msg\_id": 18,"token": 1}

Successful return:

{"rval":0,"msg\_id": 18}

#### 1.8 AMBA\_SWITCH\_SINGLE\_PHOTO\_MODE

Message ID: msg\_id: 0x0000013(19)

API Overview:

Description: This API is used to switch the capture mode to single photo mode.

Direction: From the APP to the camera.

Example:

Arguments:

{"msg\_id": 19,"token": 1}

Successful return: {"rval":0,"msg\_id": 19}

### 1.9 AMBA\_SWITCH\_PHOTO\_TIMELAPSE\_MODE

Message ID: msg\_id: 0x00000014(20)

API Overview:

Description: This API is used to switch the capture mode to photo timelapse mode.

Direction: From the APP to the camera.

Example:

Arguments:

{"msg\_id" : 20,"token" : 1}

Successful return:

{"rval":0,"msg\_id": 20}

# 2.0 AMBA\_SWITCH\_VIDEO\_TIMELAPSE\_MODE

Message ID: msg\_id: 0x00000015(21)

API Overview:

Description: This API is used to switch the capture mode to photo timelapse mode.

Direction: From the APP to the camera.

Example:

Arguments:

{"msg\_id" : 21,"token" : 1}

Successful return:

{"rval":0,"msg\_id":21}

#### 2.1 AMBA\_RECORD\_START

Message ID: msg\_id: 0x00000201(513)

API Overview:

Description: This API is used to initiate camera video recording.

Direction: From the APP to the camera.

Example:

Arguments:

{"msg\_id" : 513,"token" : 1}

Successful return:

{"rval":0,"msg\_id":518}

# 2.2 AMBA\_RECORD\_STOP

Message ID: msg\_id: 0x00000202(514)

API Overview:

 $\label{eq:Description:Description:Description:Description:This API is used to terminate camera video recording on the camera.$ 

Direction: From the APP to the camera.

Example:

Arguments:

```
{"msg_id" : 514,"token" : 1}
```

Successful return:

{"rval":0,"msg\_id":514}

## 2.3 AMBA\_TAKE\_PHOTO

Message ID: msg\_id: 0x00000301(769)

API Overview:

Description: This API is used to capture a still image.

Direction: From the APP to the camera.

Example:

Arguments:

{"msg\_id": 769,"token": 1}

Successful return:

{"rval":0,"msg\_id":769}

#### 2.4 AMBA\_RTSP\_START

Message ID: msg\_id: 0x00000016(22)

API Overview:

Description: This API is used to start the rtsp streaming.

Direction: From the APP to the camera.

Example:

Arguments:

{"msg\_id" : 22,"token" : 1}

Successful return:

{"rval":0,"msg\_id":22}

## 2.5 AMBA\_RTSP\_STOP

Message ID: msg\_id: 0x00000017(23)

API Overview:

Description: This API is used to stop streaming.

Direction: From the APP to the camera.

Example:

Arguments:

{"msg\_id" : 23,"token" : 1}

Successful return:

{"rval":0,"msg\_id":23}

## 2.6 AMBA\_NAS\_START

Message ID: msg\_id: 0x00000018(24)

API Overview:

Description: This API is used to start nas uploading.

Direction: From the APP to the camera.

Example:

Arguments:

{"msg\_id" : 23,"token" : 1}

Successful return:

{"rval":0,"msg\_id":23}

#### 2.7 AMBA\_NAS\_STOP

Message ID: msg\_id: 0x00000019(25)

API Overview:

Description: This API is used to stop nas uploading.

Direction: From the APP to the camera.

Example:

Arguments:

{"msg\_id" : 24,"token" : 1}

Successful return:

{"rval":0,"msg\_id":24}