



Notation Clarification +BATT is the driving voltage of the load -BATT is GND USB_PWR is the connected USB's voltage input (GND when not connected)





UAH CRW		
Sheet: /powersys/		
File: powersys.	sch	
Title: USLI	Payload PCB	
Size: A4	Date: 2020-12-28	Rev: v1
KiCad E.D.A. kicad (5.1.8)-1		ld: 3/5
4	5	

