CAN2IO Accessary CAN-BUS

 Date:
 07.12.2023

 Version:
 Version 1

Endianess: Little Endian. In this format, the least significant byte (LSB) of the number is sent first.

Baudrate: 500 kbit/s

 Mesage Name:
 ID:
 Interval:

 motorGenData
 0x777
 200 ms

Name Start Bit Length [bit] Type Factor Offset Unit Comment Signal Description Power consumption/generation by motor in watts 16 Signed16 o w (negative Values: Motor is generating Power) Motor Power Motor power usage Motor RPM 16 16 Signed16 1 0 RPM Revolutions per minute of the motor Motor speed Temperature of the motor in Celsius Value 0 == 50°C, Motor temp Motor Temperature 32 8 Signed8 -50 °C Value 100 = 150°C 1 Generator Power 40 16 Unsigned16 1 o w Generator power Power output of the generator in watts Operational mode of the generator 0 to 15 (0 =Parking | 1 - 5 Assist Levels | 6=RFID Locked) Generator Assist Level 56 8 Unsigned8 0 -Generator mode

 Mesage Name:
 ID:
 Interval:

 batteryData
 0x778
 200 ms

Name	Start Bit	Length [bit]	Type	Factor	Offset	Unit	Comment	Signal Description
Battery State of Charge	0	8	Unsigned8	1	0	%	Battery charge	Percentage of the battery's current charge
Battery State of Health	8	8	Unsigned8	1	0	%	Battery health	Percentage indicating the health of the battery
Battery Power	16	16	Signed16	1	0	W	Battery power	Power supplied/drawn from the battery in watts
Battery Voltage	32	16	Unsigned16	1	0	mV	Battery voltage	Current voltage of the battery in millivolts
Battery Temperature	48	16	Unsigned16	1	0	K	Battery temp	Temperature of the battery in Kelvin

 Mesage Name:
 ID:
 Interval:

 VEHICLE_PART1
 0x779
 200 ms

Name	Start Bit	Length [bit]	Туре	Factor	Offset	Unit	Comment	Signal Description
Vehicle Speed	0	8	Unsigned8	1	0	km/h	Vehicle speed	Speed of the vehicle in km/h
								Direction of vehicle movement (-1 for backward, +1
Vehicle Direction	8	8	Signed8	1	0	-	Driving direction	for forward)
Vehicle Gear	16	8	Unsigned8	1	0	-	Vehicle gear	Current gear of the vehicle
Vehicle Mileage	24	32	Unsigned32	1	0	km	Total mileage	Total mileage of the vehicle in kilometers

 Mesage Name:
 ID:
 Interval:

 VEHICLE_PART2
 0x77A
 200 ms

Name	Start Bit	Length [bit]	Туре	Factor	Offset	Unit	Comment	Signal Description
Vehicle Error Code	0	16	Unsigned16	1	0	-	Error code	Codes representing errors in the vehicle
Vehicle Recouperation	16	8	Unsigned8	1	0	-		0 for no recouperation, 1 for recouperation