

Linker script in CW10

MinhNQ2




Memory Sections

- Text- Instructions that the program runs
- Data Initialized global variables.
- •Bss Uninitialized global variables. They are initialized to zeroes.
- •Heap Memory returned when calling malloc/new.
- •Stack It stores local variables and return addresses.
- •Each section has different permissions: read/write/execute or a combination of them.

Stack Heap Bss Data. Text



Building a program





LCF Structure

Linker command files consist of three kinds of segments, which must be in this order:

- A memory segment, which begins with the MEMORY{} directive
- Optional closure segments, which begin with the FORCE_ACTIVE{}, KEEP_SECTION{}, or REF_INCLUDE{} directives
- A sections segment, which begins with the SECTIONS{} directive



Memory Segment

Use the memory segment to divide available memory into segments.

- •The (*RWX*) portion consists of ELF-access permission flags: R = read, W = write, or X= execute.
- ORIGIN specifies the start address of the memory segment, either an actual memory address or, via the AFTER keyword, the name of the preceding segment.
- •LENGTH specifies the size of the memory segment. The value 0 means unlimited length.



Closure Segments

- Closure segments let you make symbols immune from deadstripping.
- FORCE_ACTIVE Use this directive to make the linker include a symbol that it otherwise would not include.
- **KEEP_SECTION** Use this directive to keep a section in the link, particularly a user-defined section.
- •**REF_INCLUDE** Use this directive to keep a section in the link, provided that there is a reference to the file that contains the section. This is a useful way to include version numbers.



Sections Segment

- •Use the sections segment to define the contents of memory sections, and to define any global symbols that you want to use in your output file.
- Format

```
SECTIONS {
    sectionName : [AT (loadAddress)]
    {
        Contents
    } > segmentName
}
```



Sections Segment

- sectionName: Name for the output section
- <u>AT (loadAddress)</u>: Optional specify for the load address of the section. The default value is the relocation address.
- <u>Contents</u>: Statements that assign a value to a symbol or specify section placement, including input sections.
- •<u>segmentName</u>: Predefined memory-segment destination for the contents of the section. The two variants are:
 - > segmentName: puts section contents at the beginning of memory segment segmentName.
 - >> segmentName: appends section contents to the end of memory segment segmentName



LCF syntax

- Variables, Expressions, and Integrals
- Arithmetic, Comment Operators
- Alignment
- Specifying Files and Functions
- Stack and Heap
- •ROM-RAM Copying



Variables, Expressions, and Integrals

- •All symbol names must start with the underscore character (_). The other characters can be letters, digits, or underscores.
 _symbolicname = some_expression;
- There are 2 types of expression
 - ❖<u>Absolute expression</u>— the symbol contains the value that it will have in the output file.
 - ❖ <u>Relocatable expression</u> the value expression is a fixed offset from the base of a section
- •LCF syntax for expressions is very similar to the syntax of the C programming language

```
_decimal_number = 123245;
```

 $_{\text{hex}_number} = 0x999999FF;$



Arithmetic Operators

Precedence	Operators
1	-~!
2	* / %
3	+ -
4	>> <<
5	== != > < <= >=
6	&
7	1
8	&&
9	11



Comment Operators

- •Use the sharp character "#" for one line comment
 #this is one line comment
- •Use slash and asterisk "/*" for multi-line comment
 /* this is
 multiline comment */

•Use double slash "//" for partial-line comment
//this is partial-line comment



Specifying Files and Functions

- •Specifying Files: Defining the contents of a sections segment includes specifying the source file of each section.
 - ❖Method 1: listing the files
 - Method 2: use the asterisk (*) wild-card character, which represents the names of every file in your project.
- •Specifying Files: For precise control over function placement within a section, use the **OBJECT** keyword.

```
SECTIONS {
    .program_section :
    {
        OBJECT (beta, main.c)
        OBJECT (alpha, main.c)
        * (.text)
    } > ROOT
```



Stack and Heap

 Reserving space for the stack and heap requires some arithmetic operations to set the symbol values used at runtime.

Stack Setup Operations

```
_stack_address = __END_BSS;
_stack_address = _stack_address & ~7; /*align top of stack by 8 */
_SP_INIT = _stack_address + 0x4000; /*set stack to 16KB*/
```

Heap Setup Operations

```
___heap_addr = __SP_INIT; /* heap grows opposite stack */
__heap_size = 0x50000; /* heap size set to 500KB */
```



ROM-RAM Copying

- •It is common that data or code of a program residing in ROM gets copied into RAM at runtime. To indicate such data or code, use the LCF to assign it two addresses:
 - The memory segment specifies the intended location in RAM
 - ❖The sections segment specifies the resident location in ROM, via its AT (address) parameter
- •For program execution to copy the section from ROM to RAM, a copy table must supply the information that the program needs at runtime. This copy table, which the symbol __S_romp identifies, contains a sequence of three word values per entry:
 - ROM start address
 - ❖RAM start address
 - **♦** size



. (location counter)	ADDR	<u>ALIGN</u>
ALIGNALL	EXCEPTION	FORCE ACTIVE
INCLUDE	KEEP SECTION	MEMORY
<u>OBJECT</u>	REF_INCLUDE	SECTIONS
SIZEOF	SIZEOF_ROM	WRITEB
<u>WRITEH</u>	WRITEW	WRITESOCOMMENT
ZERO FILL UNINITIALIZ ED		



. (location counter): Denotes the current output location

```
.data :
{
     *.(data)
     *.(bss)
     *.(COMMON)
     __start = .;
     . = __start + 0x10000;
     __end = .;
} > DATA
```

ADDR: Returns the address of the named section or memory segment

```
ADDR (sectionName | segmentName)
```

- sectionName: Identifier for a file section.
- segmentName: Identifier for a memory segment



ALIGN: Returns the location-counter value, aligned on a specified boundary.

ALIGN (alignValue)

alignValue: Alignment-boundary specifier; must be a power of two.

ALIGNALL: Forces minimum alignment of all objects in the current segment to the specified value.

ALIGNALL (alignValue);

alignValue: Alignment-value specifier; must be a power of two.



•FORCE_ACTIVE: Starts an optional LCF closure segment that specifies symbols the linker should not deadstrip.

```
FORCE_ACTIVE { symbol[, symbol] }
symbol: Any defined symbol.
```

INCLUDE: Includes a specified binary file in the output file.

```
INCLUDE filename
```

filename: Name of a binary file. The path of the binary file needs to be specified as linker command line argument.

•KEEP_SECTION: Starts an optional LCF closure segment that specifies sections the linker should not deadstrip.

```
KEEP_SECTION{ sectionType[, sectionType] }
```

sectionType: Identifier for any user-defined or predefined section.



•MEMORY: Starts the LCF memory segment, which defines segments of target memory.

- segmentName: Name for a new segment of target memory.
- ❖accessFlags: ELF-access permission flags R = read, W = write, or X = execute.
- address: A memory address or an AFTER command
- Length: Size of the new memory segment
- ❖fileName: Optional, binary-file destination



 SIZEOF: Returns the size (in bytes) of the specified segment or section.

```
SIZEOF (segmentName | sectionName)
```

- segmentName: Name of a segment
- •SIZEOF_ROM: Returns the size (in bytes) of the specified segment or section.

```
SIZEOF(segmentName | sectionName)
```

- segmentName: Name of a ROM segment
- •WRITEB, WRITEH, WRITEW: Inserts a byte of data at the current address of a section.

```
WRITEx (expression);
```

expression: Any expression that returns a value in range



 WRITESOCOMMENT: Inserts an S0 comment record into an Srecord file.

WRITESOCOMMENT "comment"

comment: Comment text

•ZERO_FILL_UNINITIALIZED: Forces the linker to put zeroed data into the binary file for uninitialized variables. This directive must lie between the directives MEMORY and SECTIONS; placing it anywhere else would be a syntax error.

ZERO FILL UNINITIALIZED



Defining Sections in Source Code

Format

```
#pragma define_section sname ".istr" [.ustr] [.rostr] [addrmode] [accmode]
#pragma section sname begin
/* Code */
#pragma section sname end
__declspec(section " sname ") prototype>;
```

Parameters

- * <u>sname</u>: Identifier for source references to this user-defined section.
- <u>istr</u>: Section-name string for initialized data assigned to this section
- <u>ustr</u>: Optional: ELF section name for uninitialized data assigned to this section.
- rostr. Optional: ELF section name for read only data assigned to this section.
- addrmode: Optional: optional parameter indicates how the linker addresses the section.
- *acc: access permission in this section





Thanks for your attention!