

Industrial PC

# Linux Qt 5.5 OS on iMX6UL User Manual

For iMX6UL Products

Content can change at anytime, check our website for latest information of this product. **www.chipsee.com** 

# **Contents**

Linux Qt 5.5 OS	3
1. Preparation	5
1.1. Hardware Requirements	5
1.2. Software Requirements	5
2. Debug	6
2.1. Serial Debug	6
2.2. SSH Debug	8
2.3. VNC Debug	10
3. Downloading images	12
3.1. Boot Switch Configuration	12
3.2. Prebuilt Files Package	12
3.3. Downloading Images by using the TF card	13
4. System Resource	15
4.1. TF Card/USB Disk	15
4.2. Network	16
4.2.1. Wired Ethernet	16
4.2.2. Wi-Fi	17
4.3. Sound Test	20
4.4. Serial Port	22
4.5. CAN Bus	24
4.6. GPIO	27
4.7. Buzzer	29
5. Development	30
5.1. Preparation	30
5.2. Example — Develop a HelloWorld Program	33
6. Q&A	36
6.1. How to Change psplash's	36
7. Disclaimer	38
8. Technical Support	38

# Linux Qt 5.5 OS

## **Chipsee Linux Qt 5.5 OS User Manual**



This manual provides users with a fast guide of Chipsee Industrial Computer (Abbreviate as IPC) about Linux Qt 5.5 OS development. Through this manual, users can quickly understand the hardware resources; users can build a complete compilation of Linux development environment; users can debug Linux Qt 5.5 OS via serial and Internet.

Revision	Date	Author	Description
V1.1	2021-12-30	Randy	Revised
V1.0	2018-05-14	Madi	Initial Version

#### **SUPPORTED BOARDS:**

CS10600U070

#### PREBUILT FILES PACKAGE:

Below is the link to the prebuilt images for the Linux Qt operating system on the various industrial PC.

prebuilt-cs10600u070v1-emmc-20210719.tar.gz

#### System Features

Feature	Comment
Kernel	Kernel 3.14.52
Bootloader	Uboot 2015.04
System	Linux Qt 5.5

## Linux Qt 5.5 OS on iMX6UL User Manual

Feature	Comment
Python	Python 2.7.9
Qt	Qt 5.5.1
Desktop	matchbox
user/password	[root/root]

# **Preparation**

You will need to prepare the following items before you can start using the Prebuilt Files Package to re-flash the system.

Power Supply Unit (PSU) with the appropriate voltages, as follows:

• The CS10600U070 product needs a 6V to 36V power adapter.

You need to prepare the Power Adapter by yourself

#### **Hardware Requirements**

- Chipsee Industrial PC
- PSU according to the instructions above
- USB-to-serial or other serial cable for debugging
- USB A-A cable (used only if the hardware configured as OTG)
- Windows 7 PC
- Mini-B USB OTG Cable
- TF Card (at least 4GB) and card reader

## **Software Requirements**

- Linux Qt 5.5 OS Prebuilt Files Package (from the link above)
- Xshell or other terminal emulation software
- VNC-Viewer
- Cross-toolchain
- Useful tools for Qt development



- If you want to re-flash the system, you need the Prebuilt image package.
- You can use Xshell or other terminal emulation software to debug Chipsee Industrial PC products in Windows.
- You can use VNC-Viewer to to remote control Chipsee Industrial PC over Ethernet.
- The cross-toolchain can compile a program for Chipsee Industrial PC.



In this documentation, all the commands are executed with <code>root</code> user privileges.

# **Debug**

In this document, we use Xshell to debug the Chipsee Industrial Computer. You can also use other tools such as Putty, Minicom, SecureCRT or any terminal emulation software.

## **Serial Debug**

You can refer to the RS232/RS485/CAN Connector section under the EPC/PPC-A7-070HB-C manual to understand the serial ports of the IPC. The debug serial port of Chipsee Industrial Computer is the first RS232 port. You can use it to debug directly, and the default user and password is [root/root]. You can use RS232\_1\_TXD, RS232\_1\_RXD, GND.

Follow these steps to perform serial debugging:

- Connect your Windows PC to the Chipsee IPC over a serial cable. Please reference the
   How To Connect Board By Serial manual to connect your PC and Chipsee Industrial
   Computer over a serial cable.
- Open XShell and use the session properties as shown on the figure below.




Figure 355: Add Session




Figure 356: Session Properties




Figure 357: Serial Debug

## **SSH Debug**

To perform SSH debugging on the Chipsee IPC, you must first connect the product to the Internet.

Continue the debugging by follow these steps:

- Get the IP address of the Chipsee IPC product.
- You can configure XShell or you can directly use the SSH tool in Linux OS. In this tutorial, we will use the XShell tool to perform SSH debugging.
- Open XShell and add a new session and set it as shown on the figure below.




Figure 358: SSH Setting

Now we can perform SSH debugging using XShell.




Figure 359: SSH Debug

## **VNC Debug**


You can use the VNC-Viewer software in Windows to control Chipsee IPC over Ethernet.

• Open the VNC-Viewer software as shown on the figure below.



Figure 360: VNC Desktop

Click on the X11VNC icon to enable the X11VNC.



#### Figure 361: X11VNC Enable

• Use VNC-Viewer in Windows to control it over Ethernet, as shown on the figure below.




Figure 362: VNC-Viewer Connect



Figure 363: *Authentications* 

# **Downloading images**

# **Boot Switch Configuration**

CS-IMX6 has a boot configuration select switch, as shown on the figure below. You can use the boot select switch to change between three modes, namely

- TF Card
- eMMC Boot
- Download




Figure 364: Boot Mode Setup

SW Mode	1	2	3	4
TF Card	1	0	0	0
еММС	1	1	0	1
Download	0	1	1	0

Table 76 Boot Configuration Selection



The user can use both the pre-built Linux Qt 5.5 image files and the **MFGTools** software to download new images to the system, boot system and perform necessary software and hardware test.

# **Prebuilt Files Package**

You can get the Prebuilt Files Package for each model from links mentioned at the beginning of this documentation. You can also get the Prebuilt Files Package from the DVD in /Linux Qt 5.5/Prebuilds folder. However, it may be outdated so always compare the versions (the last number in the filename is the release date).

The prebuilt package has the following content:

Contents	Comment
boot/imx6q-eisd.dtb	TF Card boot dtb file
boot/u-boot-sd.imx	TF Card boot bootloader
boot/zImage	TF Card boot kernel file
boot/logo.bmp	TF Card boot logo file
filesystem/rootfs-emmc-flasher.tar.bz2	TF Card boot rootFS
mksdcard.sh	Shell tools to make bootable TF Card
README	Simple guidelines
S1.jpg	Boot Switch Config Figure
emmc-flash/emmc/rootfs.tar.bz2	RootFS in target eMMC
emmc-flash/emmc/u-boot-emmc.imx	Bootloader in target eMMC
emmc-flash/emmc/zImage	Kernel file in target eMMC
emmc-flash/emmc/zImage_framebuffer	Kernel file with frame-buffer
emmc-flash/emmc/imx6q-eisd.dtb	Dtb file in target eMMC
emmc-flash/emmc/imx6q-eisd.dtb_framebuffer	Dtb file with frame-buffer
emmc-flash/emmc/logo.bmp	Logo file in eMMC
emmc-flash/mkemmc.sh	Shell tool to download images to eMMC

Table 77 Prebuilt Files Package



- The default <code>zImage</code> and <code>imx6q-sabresd.dtb</code> files support 'keep the logo from uboot to kernel' but don't support framebuffer.
- We also provide <code>zImage\_framebuffer</code> and <code>imx6q-eisd.dtb\_framebuffer</code> file versions that support the framebuffer function but do not support the <code>keep the logo from uboot kernel</code> feature. If you need the framebufer, just rename these two files to <code>zImage</code> and <code>imx6q-eisd.dtb</code>.

# Downloading Images by using the TF card

Follow the steps below to download images onto the eMMC by using the TF Card:

- 1. Copy the Prebuilt Files Package to a Linux environment (such as Ubuntu 14.04).
- 2. Insert the SD card into your computer. If you are using virtual machines, please ensure the SD card is mounted to the Linux operating system.
- 3. Confirm the SD card mount point,  $\lceil \text{dev/sdX} \rceil$  (e.g.,  $\lceil \text{dev/sdc} \rceil$  or  $\lceil \text{dev/sdb} \rceil$ , be sure to use the right one). In a Linux system, you can use the command below to find out what X is.

\$ sudo fdisk —l

- 4. Copy the prebuilt-imxv1-csXXXXXfXXXvX-android6-emmc-YYYYMMDD.tar.gz to somewhere(such as \$HOME) on the Ubuntu PC.
- 5. **Extract the** prebuilt-imxv1-csXXXXXfXXXvX-android6-emmc-YYYYMMDD.tar.gz

\$ tar -xzvf prebuilt-imxv1-csXXXXXfXXXvX-android6-emmc-YYYYMMDD.tar.gz

6. Go to the folder

\$ cd prebuilt-imxv1-csXXXXXfXXXvX-android6-emmc-YYYYMMDD

7. Use the following command to flash the Linux Qt 5.5 OS to the SD card

\$ sudo ./mksdcard.sh --device /dev/sd<?>



- $\bullet$  sd<?> means the SD card mount point, (e.g.,  $\mbox{/dev/sdc}$  or  $\mbox{/dev/sdb}$  ) in Ubuntu system.
- The recommended SD card should be Sandisk Class4 level SD card or above.
- 8. The bootable SD Card is now ready. Power OFF the industrial PC and insert the SD Card.
- 9. Set the switch S1 to TF card boot mode. (refer to **Boot Switch Configuration** above)
- 10. Connect the industrial PC to PC via COM1. Power ON the IPC.
- 11. After 20 minutes, if the LED on industrial PC stays lit, flashing is completed. Using COM1, you can also find this message >>>>> **eMMC Flashing Completed** <<<<< which indicates that the system image was downloaded correctly to the eMMC.
- 12. Power OFF and set the switch S1 to eMMC boot mode. (refer to Boot Switch Configuration above)

# **System Resource**

## **TF Card/USB Disk**

The TF Card and USB Storage supports hot-plug. These devices will be automatically mounted on  $\mbox{\it /run/media/mmcblk0P*}$ , as shown in the figure.




Figure 365: TF Card



The TF card and USB Storage do not support NTFS format. Please format it to FAT32 first before plugging into IPC.

#### Network

This system uses a networking service to control Ethernet and uses wpa\_supplicant to control the WIFI network.

#### **Wired Ethernet**

You can get the IP address from the following application, as shown on the figure below.




Figure 366: Wired Connection




Figure 367: Ethernet Information

#### Wi-Fi

You can configure the Wi-Fi using these methods:

- Config Wi-Fi by GUI
- Config Wi-Fi by Command

#### Config Wi-Fi by GUI

- Click the terminal on the desktop
- Use the following command to generate network config information.

```
# wpa_passphrase "Chipsee" "1chipsee234567890"
```

• Replace the information in /etc/wpa\_supplicant.conf by setting the ssid=Chipsee and psk=1chipsee234567890, as shown on the figure below.

```
root@imx6qsabresd:~# cat /etc/wpa_supplicant.conf
ctrl_interface=/var/run/wpa_supplicant
ctrl_interface_group=0
update_config=1

network={
    ssid="Chipsee"
    psk="1chipsee234567890"
    key_mgmt=WPA-PSK
```

#### Figure 368: Wi-Fi Config File

• Open the **Wi-Fi** icon on the desktop, then click the **Enable** button. Wait for some time to get the Wi-Fi working. The Wi-Fi is working when the network tab displays the *WIFI Enabled!* message, as shown on the figure below.




Figure 369: Wi-Fi Enable

# **Config Wi-Fi by Command**

• Use the command below to enable Wi-Fi.

```
# wifienable.sh
```

• List available network and remove default if exist using these commands

```
# wpa_cli list_network
# wpa_cli remove_network
# wpa_cli scan
# wpa_cli scan_result // get latest scan results
# wpa_cli ap_scan 1
```

• Add a new network and list added network using these commands

```
# wpa_cli add_network
# wpa_cli list_network
```

Set SSID, Password, and key management using these commands

```
# wpa_cli set_network 0 ssid "Chipsee"
# wpa_cli set_network 0 key_mgmt WPA-PSK
# wpa_cli set_network 0 psk "1chipsee234567890"
```

• Enable the network 0 with this command

```
# wpa_cli select_network 0
```

Save config

```
# wpa_cli save_config
```

• Re-enable Wi-Fi

```
# wifienable.sh
```

#### **Sound Test**

You can use the command below to record music. The \_-d parameter means interrupt after # seconds. In this example, \_-d is equal to 18 seconds.

```
$ sudo arecord -N -M -r 44100 -f S16_LE -c 2 -d 18 test.wav
```

You can use the command below to playback the recorded sound above.

```
$ sudo aplay -N -M test.wav
```

You can also use the **QT Test Application** to record and playback audio.

On the **QT Test Application** desktop, click on the **HT** button to perform a hardware test, as shown on the figure below.




Figure 370: Hardware Test

You can click the **Audio** button to playback audio. You can also click the **Record** button to record 18 seconds of audio then the application will playback the audio automatically.




Figure 371: Audio Test

#### **Serial Port**

There are five serial ports on the Chipsee IPC:  $2 \times RS232$  and  $3 \times RS485$  (can be customised). Refer to the table below for the available serial device nodes.

The default serial port configuration is  $2 \times RS232$ ,  $2 \times RS485$ ,  $1 \times RS485$  which is shared with Bluetooth.

**Contact us** if you need help with changing the default serial port configuration


Ports	Device Node
COM1(RS232, Debug)	/dev/ttymxc0
COM2(RS485)	/dev/ttymxc1
COM3(RS232)	/dev/ttymxc2
COM4(RS485)	/dev/ttymxc3
COM5(RS485)	/dev/ttymxc4

Table 78 Serial Ports Nodes on the System



If you use COM2(RS485), you can't use Bluetooth because COM2(RS485) share pin with Bluetooth.

You can test the serial port by using the **HT\_Serial Application** in the desktop, as shown on the figure below.



#### Figure 372: HT\_Serial Test




Figure 373: HT\_Serial Test

#### **CAN Bus**

Chipsee Industrial PC is equipped with two CAN busses (CAN1 and CAN2). Two devices can be interconnected. You can test the CAN buses by using the **HT application** but you must add one  $120\Omega$  resistor between CAN\_H and CAN\_L on one of the two Boards, as shown on the figure below.




Figure 374: CAN Connect



The Chipsee IPC does not mount the  $120\Omega$  matched resistor on all CAN signals by default.

Here are a few examples to test CAN by using CAN units

• **Install** can-utils

```
$ sudo apt install can-utils
```

• Set the bit-rate to 50Kbits/sec with triple sampling using the following command (use ROOT user):

```
$ sudo ip link set can0 type can bitrate 50000 triple-sampling on
```

• Bring up the device using the command:

```
$ sudo ip link set can0 up
```

#### Transfer packets

- Transmit 8 bytes with standard packet id number as 0x10
- \$ sudo cansend can0 -i 0x10 0x11 0x22 0x33 0x44 0x55 0x66 0x77 0x88
  - Transmit 8 bytes with extended packet id number as 0x800
- \$ sudo cansend can0 -i 0x800 0x11 0x22 0x33 0x44 0x55 0x66 0x77 0x88 e
  - Transmit 20 8 bytes with extended packet id number as 0xFFFFF
- \$ sudo cansend can0 -i 0xFFFFF 0x11 0x22 0x33 0x44 0x55 0x66 0x77 0x88 -e
  --loop=20

#### Receive data from CAN bus

```
$ sudo candump can0
```

#### Bring down the device

```
$ sudo ip link set can0 down
```

You can use the **HT application** to test CAN. To perform the CAN test, you need two Chipsee IPC boards to perform the test.

Follow these steps to perform the CAN test:

- Connect the two IPC boards and select the CAN port can0 or can1 simultaneously on both IPC boards.
- Click on the **CanStart** button simultaneously on both IPC boards.

Refer to the figure below for the CAN part in the HT application.




Figure 375: CAN

#### **GPIO**

There are 8 GPIOs, 4 Output, and 4 Input, they are all isolated. You can control the output or input pin voltage by feeding the VDD\_ISO suite voltage. The pin voltage should be from 5V to 24V. Refer to the tables below for a detailed port definition:

Pin Number	Definition
1	VDD_24v
2	GND_ISO
3	/dev/chipsee-gpio1(out)
4	/dev/chipsee-gpio2(out)
5	/dev/chipsee-gpio3(out)
6	/dev/chipsee-gpio4(out)
7	/dev/chipsee-gpio5(in)
8	/dev/chipsee-gpio6(in)
9	/dev/chipsee-gpio7(in)
10	/dev/chipsee-gpio8(in)

Table 79 CS10600F070 - V1.0 P23 Port

Set GPIO1 Output to high using this command

```
# echo 1 > /dev/chipsee-gpio1
```

Set GPIO2 Output to low using this command

```
# echo 0 > /dev/chipsee-gpio2
```

Check *GPIO5* value using this command

```
# cat /dev/chipsee-gpio5
```

You can use the **HT application** to test GPIO. Follow these steps to perform the GPIO test:

- Before you test, you need to connect the output gpio and input gpio, like pin 3 pin 7 / pin 4 pin 8 / pin 5 pin 9 / pin 6 pin 10 .
- Don't forget to give outside power to the pin 1 and pin2. You can use the outside 24V input power.

- Click on the **SetAllHigh** or **SetAllLow** button to check the right light status.
- Also, you can set the *output gpio* to high or low respectively. Then check the right *input gpio* status, as shown on the figure below.




Figure 376: GPIO Test



The default gpio has 4 Outputs and 4 Inputs. If you want a custom solution, please check the /etc/init.d/chipsee-init file for details.

#### **Buzzer**

You can control the buzzer easily, with the following command:

• Enable the buzzer

```
# echo 1 >/dev/buzzer
```

Disable the buzzer

```
# echo 0 >/dev/buzzer
```

You also can use the HT application to test the buzzer.




Figure 377: Buzzer

# **Development**

In this chapter, you will learn how to set up the QT development environment, and develop the first QT application on Chipsee IPC boards.

## **Preparation**

- 1. Download QT5.5.1 and install it on the system. Install it in the /home/<user>/program directory.
- 2. Install IMX6UL SDK. Get and install the SDK by using the following commands:

```
# wget -c https://chipsee-tmp.s3.amazonaws.com/SDK/fsl-imx-x11-glibc-
x86_64-meta-toolchain-qt5-cortexa7hf-vfp-neon-toolchain-3.14.52-1.1.1.sh
    # chmod +x fsl-imx-x11-glibc-x86_64-meta-toolchain-qt5-cortexa7hf-vfp-
neon-toolchain-3.14.52-1.1.1.sh
# ./fsl-imx-x11-glibc-x86_64-meta-toolchain-qt5-cortexa7hf-vfp-neon-
toolchain-3.14.52-1.1.1.sh
```

The default install directory is /opt/fsl-imx-x11/3.14.52-1.1.1 . You can install it in this directory or you can also use another directory.

3. Use the following command to test SDK:

```
# source /opt/fsl-imx-x11/3.14.52-1.1.1/environment-setup-cortexa7hf-vfp-
neon-poky-linux-gnueabi
# echo ${CC}
```

- 4. **Setting Qtcreator. If you installed** qt-opensource-linux-x64-5.5.1.run , the **Qtcreator will be installed automatically.** 
  - Before you open QtCreator, you need to add the following code-block in the first line of /home/<user>/program/Qt5.5.1/Tools/QtCreator/bin/qtcreator.sh , as shown on the figure below.

```
$ source /opt/fsl-imx-x11/3.14.52-1.1.1/environment-setup-
cortexa7hf-vfp-neon-poky-linux-gnueabi
```

Figure 378: Setting QtCreator

5. Use the following command to open Qtcreator.

```
# /home/program/Qt5.5.1/Tools/QtCreator/bin/qtcreator.sh
```

6. Open the QtCreator Options, then click on Tools->Options->Build & Run. Set the Debuggers/Compilers/Qt Versions/Kits as shown on the figures below.




Figure 379: Debuggers



Figure 380: Compilers




Figure 381: Qt Versions




Figure 382: Kits

#### Example — Develop a Helloworld Program

1. Use QtCreator to create a new Qt Widgets Application, named Helloworld, as shown on the figure below.



Figure 383: Qt Widgets Application

2. Select IMX kits, as shown on the figure below.



Figure 384: Kit Selection

3. Use QMainWindow as the Base class, as shown on the figure below.




Figure 385: Base Class

4. Click the Design icon to add one label widget, as shown on the figure below.




Figure 386: Add Label Widget

5. Click on the Build icon to build app, as shown on the figure below.



Figure 387: Build App

6. Copy the Helloworld app to the IPC board's /home/root/ directory and use the following command to run it:

```
# export DISPLAY=:0.0
# ./HelloWorld
```

You can get the HelloWorld app from the /home/leave/build-HelloWorld-imx-Debug directory, but your directory might not be the same as this one.

# Q&A

In this chapter, you can learn how to set up the QT development environment, and develop the first QT application on Chipsee IPC boards.

## How to Change psplash's

• Install IMX SDK and some Packages. Reference the install SDK point under the Preparation section above to install IMX SDK and install some recommends packages using this command:

```
$ sudo apt-get install autoconf libgdk-pixbuf2.0-dev
```

- · Generate psplash of your own.
  - Get psplash.tar.gz from DVD/Linux+QT5/Tools/ and extract it.

```
$ sudo tar zxvf psplash.tar.gz
```

Prepare a PNG file, such as chipsee.png

```
$ sudo cp chipsee.png psplash/
$ sudo cd psplash
```

Setting environment

```
$ source /opt/fsl-imx-x11/3.14.52-1.1.1/environment-setup-
cortexa9hf-vfp-neon-poky-linux-gnueabi
```

```
chipsee@chipsee-build:-$ source /opt/fsl-imx-x11/3.14.52-1.1.1/environment-setup-cortexa9hf-vfp-neon-poky-linux-gnueabi
chipsee@chipsee-build:-$ echo $CC
arm-poky-linux-gnueabi=gcc - march=armv7-a -mfloat-abi=hard -mfpu=neon -mtune=cortex-a9 --sysroot=/opt/fsl-imx-x11/3.14.52-1.1.1/sysroots/cortexa9hf-vfp-neon-poky-linux-gnueabi
chipsee@chipsee-build:-$
```

• Generate header file and modify the psplash.c, then config and make:

```
$ ./make-image-header.sh chipsee.png POKY //you will find a new
file named chipsee-img.h
$ vi psplash.c // replace the header file name (psplash-poky-
img.h) in psplash.c with chipsee-img.h
$ ./autogen.sh
$ make // you will generate the file psplash
```

- Then you will find the file psplash, replace the one in rootfs /usr/bin/psplash. Reboot your IPC board to apply the changes made to the psplash.
- You can remove the /etc/init.d/psplash.sh file in rootfs to disable it.
- If you want to rotate the psplash screen, just do the following in the system:

```
# echo 180 > /etc/rotation // rotate 180 angle
# echo 0 > /etc/rotation // reset to default.
```

# **Disclaimer**

This document is provided strictly for informational purposes. Its contents are subject to change without notice. Chipsee assumes no responsibility for any errors that may occur in this document. Furthermore, Chipsee reserves the right to alter the hardware, software, and/or specifications set forth herein at any time without prior notice and undertakes no obligation to update the information contained in this document.

While every effort has been made to ensure the accuracy of the information contained herein, this document is not guaranteed to be error-free. Further, it does not offer any warranties or conditions, whether expressed orally or implied in law, including implied warranties and conditions of merchantability or fitness for a particular purpose. We specifically disclaim any liability with respect to this document, and no contractual obligations are formed either directly or indirectly by this document.

Despite our best efforts to maintain the accuracy of the information in this document, we assume no responsibility for errors or omissions, nor for damages resulting from the use of the information herein. Please note that Chipsee products are not authorized for use as critical components in life support devices or systems.

# **Technical Support**

If you encounter any difficulties or have questions related to this document, we encourage you to refer to our other documentation for potential solutions. If you cannot find the solution you're looking for, feel free to contact us. Please email Chipsee Technical Support at **support@chipsee.com**, providing all relevant information. We value your queries and suggestions and are committed to providing you with the assistance you require.