RADIO-CONTROLLED CLOCK

USER MANUAL | MODEL SR808

WWVB Atomic Time Signal • Dual Alarms • Indoor Temperature & Humidity

Welcome

Thank you for choosing this radio-controlled clock. It receives standard time signals from the U.S. WWVB time station to help set the time automatically. When a valid signal is received, the clock can correct its time and update for Daylight Saving Time (DST). If a signal is unavailable, the clock continues to keep time using its internal quartz movement.

Before use, check that the product and included accessories are complete and undamaged. Read these instructions before operating the clock. If the product is damaged or you have questions, contact customer service. Our customer service team will respond within 24 hours.

1. What's Included / Power

• Radio-controlled clock (Model SR808)
• Power: 3 × 1.5 V AAA batteries (4.5 V total; batteries included)

Install three AAA batteries, observing the polarity marks inside the battery compartment. After power-up, the display briefly shows all segments and the backlight turns on. The clock then starts searching for the WWVB time signal automatically.

2. Main Features

- WWVB radio-controlled time synchronization
- Four U.S. time zones: PST (UTC−8), MST (UTC−7), CST (UTC−6), and EST (UTC−5)
- 12-hour or 24-hour time display; hours, minutes, and seconds
- Calendar display (2026–2099)
- Indoor temperature: 14°F to 122°F (−9.9°C to 50°C)
- Indoor relative humidity: 10% to 95%
- Two alarms with adjustable snooze duration
- LED backlight

3. Button Guide

Button	Function
SET	Press and hold for 2 seconds to enter time/date settings. In normal mode, press to cycle alarm ON/OFF combinations.
ALARM	Press to view Alarm 1 and Alarm 2 times. Press and hold for 2 seconds to enter alarm settings.
UP / ”**+**”	Increase a setting. In normal mode, press to switch between °F and °C.
DOWN / “**−**”	Decrease a setting. Press and hold to start RCC reception; press briefly during reception to stop it.
SNZ/LIGHT	Turn on the backlight. When an alarm sounds, press

	to snooze.

Important: Immediately after inserting batteries, the clock may be receiving the WWVB signal. During RCC reception, the other buttons are unavailable except “SNZ/LIGHT”. Press “**–**” briefly to stop reception before changing settings.

4. RCC Automatic Time Synchronization

Signal format: WWVB (United States).

1. After batteries are installed, the clock automatically begins searching for the WWVB time signal. The antenna icon flashes while searching.
2. When a signal is detected, the antenna icon remains displayed and the curved signal-wave marks expand to indicate that time data is being received.
3. When synchronization succeeds, the clock corrects the time automatically and the antenna/signal indicators show successful reception.
4. If reception is unsuccessful, the clock continues to run on its quartz movement and will try again during its scheduled reception periods.

The clock automatically attempts reception at 1:00, 2:00, 3:00, 4:00, and 5:00 AM. Reception may take up to 7 minutes. If a signal containing DST information is received, the DST indicator appears.

To start reception manually, press and hold “**–**”. To stop reception, press “**–**” briefly. To enable or disable automatic synchronization, enter the time-setting menu and select RCC ON or RCC OFF.

For better reception, place the clock near a window and away from large metal objects and electronic devices that may cause interference. Reception can vary with location, building materials, and local conditions.

5. Setting the Time and Date

If RCC reception is active, press “**–**” briefly to stop it before setting the clock.

1. In normal time mode, press and hold “SET” for 2 seconds to enter settings.

2. The settings appear in this order: 12/24-hour format → RCC ON/OFF → time zone → hour → minute → date format → year → month → day → exit.

3. The current setting flashes. Press “SET” to confirm and move to the next item. Press “**+**” or “**–**” to change the value. Press and hold “**+**” or “**–**” to change values more quickly.

4. When setting minutes, the seconds reset to 00. The weekday updates automatically when the date is changed.

5. If no button is pressed for 20 seconds, the clock exits setting mode and saves the settings entered.

6. Alarm Settings

View an alarm: In normal mode, press ALARM to view the Alarm 1 and Alarm 2 times. The display returns to normal mode after approximately 5 seconds without input.

Set the alarms: Press and hold ALARM for 2 seconds. The setting order is Alarm 1 hour → Alarm 1 minute → Alarm 1 snooze duration → Alarm 2 hour → Alarm 2 minute → Alarm 2 snooze duration → exit. Press ALARM to confirm and move to the next item; use “**+**” or “**–**” to adjust. Settings are saved automatically if no button is pressed for 20 seconds. Setting an alarm time turns that alarm on.

Turn alarms on or off: In normal mode, press “SET” to cycle through these combinations: Alarm 1 ON / Alarm 2 OFF → Alarm 1 OFF / Alarm 2 ON → both ON → both OFF.

When an alarm sounds, press “SNZ/LIGHT” to delay it. The snooze icon flashes and the alarm sounds again after the selected snooze interval. The snooze duration can be set to OFF or 1–30 minutes. Press any other button to stop the sounding alarm or exit snooze mode.

Each alarm sounds for up to 2 minutes. The sound pattern becomes progressively faster/louder in stages, then continues until the alarm is stopped or the alarm period ends.

7. Temperature, Humidity, and Backlight

The clock displays indoor temperature and relative humidity. Press “**+**” in normal mode to switch between Fahrenheit (°F) and Celsius (°C). The temperature display range is 14°F–122°F (−9.9°C–50°C); out-of-range temperatures may appear as LL.L or HH.H. Humidity is displayed from 10% to 95%.

Press “SNZ/LIGHT” to turn on the LED backlight. The backlight is designed to turn off automatically after approximately 60 seconds.

8. Troubleshooting

Issue	What to Do
The time has not synchronized	Make sure RCC is set to ON. Move the clock near a window, away from interference, and allow it to try again—nighttime reception may be better.
Buttons do not respond	The clock may be receiving the WWVB signal. Press “-” briefly to stop reception, then try again.
Temperature or humidity looks unusual	Keep the clock away from direct sunlight, heaters, air conditioners, and other sources of rapid temperature change. Allow time for the reading to stabilize.

9. Specifications

Model	SR808
Time signal	WWVB
Power	3 × 1.5 V AAA batteries; 4.5 V total
Time zones	PST, MST, CST, EST
Time format	12-hour / 24-hour
Calendar	2026–2099
Temperature range	14°F–122°F (−9.9°C–50°C)
Humidity range	10%–95% RH
Alarm	Two alarms; adjustable snooze

Note: Radio reception depends on location and environmental conditions. Automatic time correction cannot be guaranteed in every indoor location.