Flux Capacitor



Single button actions			
1 Play	2 Music Player :	3 Play	
"key1.mp3" [3001]	Previous song [3002]	"key3.mp3" [3003]	
4 Play "key4.mp3" [3004]	5 Music Player : Play/Stop [3005]	6 Play "key6.mp3" [3006]	
7 Play "key7.mp3" [3007]	8 Music Player : Next song [3008]	9 Play "key9.mp3" [3009]	
* Start command sequence	O Time Travel	# Abort command	
	↑ Volume +		
← Chase speed -	OK Execute command	+ Chase speed +	
	↓ Volume –		

Flux Capacitor

Special key sequences	IR	TCD
Set original chase sequence	*1□←	3010
Set alternative chase sequence	*1×← ⁷	301x
Disable flux sound	*20 <i>~</i>	3020
Enable flux sound	*21₽	3021
Enable flux sound (30 seconds)	*22 <i>~</i>	3022
Enable flux sound (60 seconds)	*23 <i>~</i>	3023
Set relative flux volume level (0-3)	*3×← ⁷	303x
Select volume level (00 - 19)	*3×x₽	33xx
Enable volume knob	*399₽	3399
Set minimum box light level (0-4)	*40x← ⁷	340x
Music Player : Set folder number	*5x← ⁷	305x
Music Player : Shuffle off	*222 <i>+</i> 7	3222
Music Player : Shuffle on	*555₽	3555
Music Player : Go to song 000	*888₽	3888
Music Player : Go to song xxx	*888xxx+ ⁻⁷	3888xxx
Toggle IR remote command lock	*70↩	3070
Reset chase speed	*80←	3080
Toggle usage of Speed knob	*81₽	3081
Say current IP address	*90←	3090
Enter TCD remote control mode*	*95⊄	3095
Restart the Flux Capacitor	*64738₽	3064738
Delete static IP address	*123456+7	3123456
Forget learned IR rem. control	*654321 <i>←</i>	3654321

Control of FC through TCD requires BTTFN connection.

^{*} Remote controlling the TCD keypad requires BTTFN connection. Keys 0-9 and OK are sent as brief presses; *x sends key x as "held". # quits remote control mode.