Flux Capacitor



Single button actions			
1	2	3	
Play	Music Player :	Play	
"key1.mp3"	Previous song	"key3.mp3"	
[3001]	[3002]	[3003]	
4	5	6	
Play	Music Player :	Play	
"key4.mp3"	Play/Stop	"key6.mp3"	
[3004]	[3005]	[3006]	
フ	8	9	
Play	Music Player :	Play	
"key7.mp3"	Next song	"key9.mp3"	
[3007]	[3008]	[3009]	
*		#	
Start command	Time Travel	Abort	
sequence		command	
	↑ Volume +		
(Chase speed -	OK Execute command	→ Chase speed +	
	↓ Volume –		

Flux Capacitor



Special key sequences	IR	TCD
Set original chase sequence	*1□←	3010
Set alternative chase sequence	*1×← ⁷	301x
Disable flux sound	*20 <i>~</i>	3020
Enable flux sound	*21 <i>⊷</i>	3021
Enable flux sound (30 seconds)	*22 <i>→</i>	3022
Enable flux sound (60 seconds)	*23 <i>~</i>	3023
Set minimum box light level (0-4)	*3x←	303x
Reset chase speed	*40←	3040
Select volume level (00 - 19)	*3×x← ⁷	33xx
Enable volume knob	*399₽	3399
Music Player : Set folder number	*5x←	305x
Music Player : Shuffle off	*2 <u>22</u> ₽	3222
Music Player : Shuffle on	*555₽	3555
Music Player : Go to song 000	*888₽	3888
Music Player : Go to song xxx	*888xxx+ ⁻⁷	3888xxx
Toggle IR remote command lock	*70←	3070
Toggle usage of Speed knob	*81←	3081
Say current IP address	*90←	3090
Enter TCD remote control mode*	*95←	3095
Restart the Flux Capacitor	*64738₽	3064738
Delete static IP address	*123456+7	3123456
Forget learned IR rem. control	*654321 ←	3654321

Control of FC through TCD requires BTTFN connection.

^{*} Remote controlling the TCD keypad requires BTTFN connection. Keys 0-9 and OK are sent as brief presses; *x sends key x as "held". # quits remote control mode.