Remote Control



Power ON	Press	Hold	
0.0	Previous Song	Play/Stop	
RESET	Next Song	Toggle Shuffle	
CALIBRATION	Reset speed	Display IP address	

Power OFF	Press	Hold	
0.0	Volume up	Brightness up	
RESET	Volume down	Brightness down	
CALIBRATION	Calibrate neutral	Start calibration for up and down	

Remote Control



Special key sequences	TCD
Toggle Movie-mode acceleration	7060
Toggle TCD speed display while off	7061
Select volume level (00 - 19)	73xx
Enable click sound	7350
Disable click sound	7351
Music Player: Play / Stop	7005
Music Player : Previous Song	7002
Music Player : Next Song	7008
Music Player : Set folder number	705x
Music Player: Shuffle off	7222
Music Player : Shuffle on	7555
Music Player : Go to song 000	7888
Music Player : Go to song xxx	7888xxx
Play "keyX.mp3" on SD card (X = 1, 3, 4, 6, 7, 9)	700x
Display current IP address	7090
Restart	7064738
Delete static IP address	7123456

Control through TCD requires BTTFN connection.