Time Circuits Display

Destination time programming	
Set date and time	mmddyyyyhhMM↵
Set date / time only	mmddyyyy↵ / hhMM↵

Disable / Enable **beep** sound	000↵ / 001↵
Enable **beep** sound (30/60 seconds)	002↵ / 003↵
Toggle **Room Condition mode**	111↵
Toggle **World Clock mode**	112↵
Toggle both WC and RC mode	113↵
Show weekday of *present time* date	33↵
Select volume level / Enable knob	300 - 319↵ / 399↵
Disable / Enable line-out audio	350↵ / 351↵
Alarm: Show / Set to hh:MM	11↵ / 11hhMM↵
Timer : Show / Set to MM minutes	44↵ / 44MM↵
Timer : Delete timer	440↵
Reminder : Display reminder	77↵ / 777↵
Reminder : Program reminder	77mmdd↵
Reminder : Program reminder	77mmddhhMM↵
Reminder : Delete reminder	770↵
Play "keyX.mp3" (X = 1 - 9)	501 - 509↵
Set **TT OUT** to LOW / HIGH	900↵ / 901↵
Disable / Enable **Car Mode**	990↵ / 991↵
Forbid / Allow **Remote Control**	992↵ / 993↵
Forbid / Allow Keypad Rem. Control	994↵ / 995↵
Release HA **Fake-Power Control**	996↵
Restore stored dest./last dep. times	998↵
Toggle **Exhibition Mode**	999↵
Program Time for **Exhibition Mode**	99mmddyyyyhhMM↵
Restart the Time Circuits	64738↵

Time Circuits Display

Holding keys for 2 seconds		
1 Toggle **Alarm** on/off	**2** **Music Player** : Previous song	**3** Play "key3.mp3"
4 Toggle **Night mode**	**5** **Music Player** : Play/Stop	**6** Play "key6.mp3"
7 **Re-enable WiFi**	**8** **Music Player** : Next song	**9** Return from Time Travel
	0 **Time Travel**	

Additional Music Player commands	
Music Player : Display curr. played	55↵
Music Player : Shuffle off / on	222↵ / 555↵
Music Player : Go to song 000 / xxx	888↵ / 888xxx↵