## Time Circuits Display Keypad Cheat Sheet



Destination time programming		
mmddyyyyhhMM↔ Set date/time		
mmddyyyy↔	Set date	
hhMM↔	Set time	

Special key sequences		
000+7	Disable <b>beep</b> sound	
001₽	Enable <b>beep</b> sound	
002+7	Enable <b>beep</b> sound (30 seconds)	
0034	Enable <b>beep</b> sound (60 seconds)	
111 <i>⊷</i>	Toggle <b>Room Condition mode</b>	
112₽	Toggle <b>World Clock mode</b>	
113₽	Toggle both WC and RC mode	
11⊷	Show current <b>alarm</b> time/weekday	
11hhMM+ <sup>7</sup>	Set <b>alarm</b> to hh:MM	
44+³	<b>Timer</b> : Show remaining time	
44MM+³	<b>Timer</b> : Set timer to MM minutes	
440₽	Timer : Delete timer [2.9]	
77←	Reminder : Display reminder	
777+ <sup>2</sup>	Reminder : Display time until reminder	
77mmdd+³	Reminder : Program reminder	
77mmddhhMM <b>⁴</b>	<b>Reminder</b> : Program reminder	
770₽	<b>Reminder</b> : Delete reminder	
222₽	<b>Music Player</b> : Shuffle off	
555₽	<b>Music Player</b> : Shuffle on	
8847	<b>Music Player</b> : Display curr. played	
888₽	<b>Music Player</b> : Go to song O	
888xxx₽	<b>Music Player</b> : Go to song xxx	
64738₽	Restart the clock	

## Time Circuits Display Keypad Cheat Sheet



Holding keys for 2 seconds		
<b>1</b> Toggle <b>Alarm</b> on/off	<b>2</b> <b>Music Player</b> : Previous song	<b>3</b> Play "key3.mp3"
<b>4</b> Toggle <b>Night mode</b>	<b>5</b> <b>Music Player :</b> Play/Stop	<b>6</b> Play "key6.mp3"
7 Re-enable WiFi	<b>8</b> Music Player : Next song	<b>9</b> Return from Time Travel
	O Time Travel	