Time Circuits Display Keypad Cheat Sheet



Destination time programming		
mmddyyyyhhMM ⁴⁷ Set date∕time		
mmddyyyy↔	Set date	
hhMM↔	Set time	

Special key sequences		
000←7	Disable beep sound	
001₽	Enable beep sound	
002₽	Enable beep sound (30 seconds)	
0034	Enable beep sound (60 seconds)	
111← ⁷	Toggle Room Condition mode	
112₽	Toggle World Clock mode	
113₽	Toggle both WC and RC mode	
11←	Show current alarm time/weekday	
11hhMM← ⁷	Set alarm to hh:MM	
44←	Timer : Show remaining time	
44MM← ⁷	Timer : Set timer to MM minutes	
440₽	Timer : Delete timer [2.9]	
<i>77</i> ← ³	Reminder : Display reminder	
<i>777←</i>	Reminder : Display time until reminder	
77mmdd+³	Reminder : Program reminder	
77mmddhhMM↔	Reminder : Program reminder	
770₽	Reminder : Delete reminder	
55₽	Music Player : Display curr. played _[2.9]	
222+7	Music Player : Shuffle off	
555₽	Music Player : Shuffle on	
888₽	Music Player : Go to song 000	
888xxx <i>↔</i>	Music Player : Go to song xxx	
64738₽	Restart the clock	

Time Circuits Display Keypad Cheat Sheet



Holding keys for 2 seconds		
1 Toggle Alarm on/off	2 Music Player : Previous song	3 Play "key3.mp3"
4 Toggle Night mode	5 Music Player : Play/Stop	6 Play "key6.mp3"
7 Re-enable WiFi	8 Music Player : Next song	9 Return from Time Travel
	O Time Travel	