Time Circuits Display



Destination time programming		
Set date and time	mmddyyyyhhMM⁴	
Set date	mmddyyyy↔	
Set time	hhMM←	

Special key sequences		
Disable beep sound	000←7	
Enable beep sound	001₽	
Enable beep sound (30 seconds)	002+7	
Enable beep sound (60 seconds)	0034	
Toggle Room Condition mode	111≁	
Toggle World Clock mode	112+7	
Toggle both WC and RC mode	113+7	
Alarm: Show current setting	11← ⁷	
Alarm: Set to hh:MM	11hhMM+ ⁷	
Timer : Show remaining time	44₽	
Timer: Set timer to MM minutes	44MM+ ⁷	
Timer : Delete timer	440₽	
Reminder : Display reminder	<i>77</i> ₽	
Reminder : Display time until reminder	<i>777+</i> ³	
Reminder : Program reminder	77mmdd+³	
Reminder : Program reminder	77mmddhhMM+³	
Reminder : Delete reminder	770₽	
Music Player : Display curr. played	55₽	
Music Player : Shuffle off	222+7	
Music Player : Shuffle on	555 <i>→</i>	
Music Player : Go to song 000	888 <i>+</i> 7	
Music Player : Go to song xxx	888xxx€ ⁷	
Disable / Enable Car Mode	990~ / 991~	
Restart the Time Circuits	64738₽	

Time Circuits Display



Holding keys for 2 seconds		
1 Toggle Alarm on/off	2 Music Player : Previous song	3 Play "key3.mp3"
4 Toggle Night mode	5 Music Player : Play/Stop	6 Play "key6.mp3"
7 Re-enable WiFi	8 Music Player : Next song	9 Return from Time Travel
	O Time Travel	