Time Circuits Display



Destination time programming		
mmddyyyyhhMM+ ⁷ Set date and time		
mmddyyyy↔	Set date	
hhMM↔	Set time	

Special key sequences		
000€	Disable beep sound	
001€	Enable beep sound	
0024	Enable beep sound (30 seconds)	
003←	Enable beep sound (60 seconds)	
111≁	Toggle Room Condition mode	
112+7	Toggle World Clock mode	
113←	Toggle both WC and RC mode	
11← ⁷	Alarm: Show current setting	
11hhMM← ⁷	Alarm: Set to hh:MM	
44← ⁷	Timer : Show remaining time	
44MM← ⁷	Timer : Set timer to MM minutes	
440+7	Timer : Delete timer	
<i>77</i> ← ³	Reminder : Display reminder	
<i>777₽</i>	Reminder : Display time until reminder	
77mmdd← ⁷	Reminder : Program reminder	
77mmddhhMM↔	Reminder : Program reminder	
770₽	Reminder : Delete reminder	
55≁	Music Player : Display curr. played	
222+7	Music Player : Shuffle off	
555₽	Music Player : Shuffle on	
888₽	Music Player : Go to song 000	
888×××	Music Player : Go to song xxx	
64738₽	Restart the Time Circuits	

Time Circuits Display



Holding keys for 2 seconds		
1 Toggle Alarm on/off	2 Music Player : Previous song	3 Play "key3.mp3"
4 Toggle Night mode	5 Music Player : Play/Stop	6 Play "key6.mp3"
7 Re-enable WiFi	8 Music Player : Next song	9 Return from Time Travel
	O Time Travel	