## Time Circuits Display



Destination time programming		
Set date and time	mmddyyyyhhMM↔	
Set date / time only	mmddyyyy+³ / hhMM+³	

Disable <b>beep</b> sound	000₽
Enable <b>beep</b> sound	001←
Enable <b>beep</b> sound (30/60 seconds)	002€/003€
Toggle <b>Room Condition mode</b>	111+7
Toggle <b>World Clock mode</b>	112₽
Toggle both WC and RC mode	113₽
Show weekday of <i>present time</i> date	33~
Select volume level / Enable knob	300-3194/3994
<b>Alarm</b> : Show current setting	11⊷
Alarm: Set to hh:MM	11hhMM← <sup>7</sup>
Timer : Show remaining time	44₽
Timer: Set timer to MM minutes	44MM+ <sup>7</sup>
Timer : Delete timer	440₽
Reminder : Display reminder	<i>77</i> ₽
Reminder : Display time until	<i>777←</i> <sup>7</sup>
Reminder : Program reminder	77mmdd+³
Reminder : Program reminder	77mmddhhMM+³
Reminder : Delete reminder	<i>77</i> 0 <i>₽</i>
Music Player : Display curr. played	55₽
Music Player : Shuffle off / on	222 <del>7</del> / 555 <del>7</del>
Music Player : Go to song 000	888₽
Music Player : Go to song xxx	888xxx <i>₽</i>
Disable / Enable <b>Car Mode</b>	9904/9914
Restore stored dest./last dep. times	998₽
Enable / disable <b>Exhibition Mode</b>	999₽
Program Time for <b>Exhibition Mode</b>	99mmddyyyyhhMM⊷
Restart the Time Circuits	64738₽

## Time Circuits Display



Holding keys for 2 seconds		
<b>1</b> Toggle <b>Alarm</b> on/off	<b>2</b> <b>Music Player</b> : Previous song	<b>3</b> Play "key3.mp3"
4 Toggle Night mode	<b>5</b> <b>Music Player :</b> Play/Stop	<b>6</b> Play "key6.mp3"
7 Re-enable WiFi	<b>8</b> <b>Music Player :</b> Next song	<b>9</b> Return from Time Travel
	O Time Travel	