Time Circuits Display



Destination time programming		
Set date and time	mmddyyyyhhMM↔	
Set date / time only	mmddyyyy+³/hhMM+³	

Special key sequences		
Disable beep sound	000←7	
Enable beep sound	001←7	
Enable beep sound (30/60 seconds)	002√ / 003 <i>←</i>	
Toggle Room Condition mode	111 <i>⊷</i>	
Toggle World Clock mode	112+7	
Toggle both WC and RC mode	113←	
Show weekday of <i>present time</i> date	33₽	
Select volume level / Enable knob	300-3194/3994	
Alarm : Show current setting	11← ⁷	
Alarm: Set to hh:MM	11hhMM+ ⁷	
Timer: Show remaining time	44+7	
Timer : Set timer to MM minutes	44MM+ ⁷	
Timer : Delete timer	440₽	
Reminder : Display reminder	<i>77←</i> ⁷	
Reminder : Display time until	777+ ³	
Reminder : Program reminder	77mmdd+³	
Reminder : Program reminder	77mmddhhMM+³	
Reminder : Delete reminder	<i>770₽</i>	
Music Player : Display curr. played	55₽	
Music Player : Shuffle off / on	2224/5554	
Music Player : Go to song 000	888₽	
Music Player : Go to song xxx	888xxx+ ⁷	
Disable / Enable Car Mode	9904/9914	
Enable / disable Exhibition Mode	999₽	
Program Time for Exhibition Mode	99mmddyyyyhhMM↔	
Restart the Time Circuits	64738 <i>+</i> ⁷	

Time Circuits Display



Holding keys for 2 seconds		
1 Toggle Alarm on/off	2 Music Player : Previous song	3 Play "key3.mp3"
4 Toggle Night mode	5 Music Player : Play/Stop	6 Play "key6.mp3"
7 Re-enable WiFi	8 Music Player : Next song	9 Return from Time Travel
	O Time Travel	