Time Circuits Display



Destination time programming		
Set date and time mmddyyyyhhMM∙		
Set date	mmddyyyy↔	
Set time	hhMM↔	

Special key sequences		
Disable beep sound	000←	
Enable beep sound	001←	
Enable beep sound (30/60 seconds)	0024/0034	
Toggle Room Condition mode	111+7	
Toggle World Clock mode	112₽	
Toggle both WC and RC mode	113₽	
Show weekday of <i>present time</i> date	33~	
Alarm: Show current setting	11⊷	
Alarm: Set to hh:MM	11hhMM← ⁷	
Timer : Show remaining time	44+³	
Timer : Set timer to MM minutes	44MM+ ⁷	
Timer : Delete timer	440₽	
Reminder : Display reminder	<i>77←</i> ⁷	
Reminder : Display time until	777 <i>+</i> ³	
Reminder : Program reminder	77mmdd+³	
Reminder : Program reminder	77mmddhhMM↔	
Reminder : Delete reminder	<i>77</i> 0 <i>₽</i>	
Music Player : Display curr. played	55 <i>-</i> 7	
Music Player : Shuffle off / on	222 4 / 555 4	
Music Player : Go to song 000	888₽	
Music Player : Go to song xxx	888xxx₽	
Disable / Enable Car Mode	9904/9914	
Enable / disable Exhibition Mode	999₽	
Program Time for Exhibition Mode	99mmddyyyyhhMM⊷	
Restart the Time Circuits	64738₽	

Time Circuits Display



Holding keys for 2 seconds		
1 Toggle Alarm on/off	2 Music Player : Previous song	3 Play "key3.mp3"
4 Toggle Night mode	5 Music Player : Play/Stop	6 Play "key6.mp3"
7 Re-enable WiFi	8 Music Player : Next song	9 Return from Time Travel
	O Time Travel	