Time Circuits Display



Destination time programming		
Set date and time	mmddyyyyhhMM↔	
Set date / time only	mmddyyyy+³ / hhMM+³	

Disable beep sound	000₽
Enable beep sound	001←
Enable beep sound (30/60 seconds)	002€/003€
Toggle Room Condition mode	111+7
Toggle World Clock mode	112₽
Toggle both WC and RC mode	113₽
Show weekday of <i>present time</i> date	33~
Select volume level / Enable knob	300-3194/3994
Alarm : Show current setting	11⊷
Alarm: Set to hh:MM	11hhMM← ⁷
Timer : Show remaining time	44₽
Timer: Set timer to MM minutes	44MM+ ⁷
Timer : Delete timer	440₽
Reminder : Display reminder	<i>77</i> ₽
Reminder : Display time until	<i>777←</i> ⁷
Reminder : Program reminder	77mmdd+³
Reminder : Program reminder	77mmddhhMM+³
Reminder : Delete reminder	770+ ⁷
Music Player : Display curr. played	55₽
Music Player : Shuffle off / on	222 7 / 555 7
Music Player : Go to song 000	888₽
Music Player : Go to song xxx	888xxx <i>₽</i>
Disable / Enable Car Mode	990~ / 991~
Restore user dest./last dep. times	998₽
Enable / disable Exhibition Mode	999₽
Program Time for Exhibition Mode	99mmddyyyyhhMM⊷
Restart the Time Circuits	64738₽

Time Circuits Display



Holding keys for 2 seconds		
1 Toggle Alarm on/off	2 Music Player : Previous song	3 Play "key3.mp3"
4 Toggle Night mode	5 Music Player : Play/Stop	6 Play "key6.mp3"
7 Re-enable WiFi	8 Music Player : Next song	9 Return from Time Travel
	O Time Travel	