## Time Circuits Display



Destination time programming		
Set date and time	mmddyyyyhhMM⁴	
Set date / time only	mmddyyyy⁴ / hhMM+³	

Disable / Enable <b>beep</b> sound	0004/0014
Enable <b>beep</b> sound (30/60 seconds)	0024/0034
Toggle <b>Room Condition mode</b>	111+7
Toggle <b>World Clock mode</b>	112₽
Toggle both WC and RC mode	113₽
Show weekday of <i>present time</i> date	33~
Select volume level / Enable knob	300-3194/3994
Disable / Enable line-out audio	3504/3514
<b>Alarm</b> : Show current setting	11⊷
Alarm: Set to hh:MM	11hhMM← <sup>7</sup>
Timer : Show remaining time	44+³
Timer: Set timer to MM minutes	44MM+ <sup>7</sup>
Timer : Delete timer	440₽
Reminder : Display reminder	<i>77+</i> <sup>7</sup>
Reminder : Display time until	<i>777+</i> <sup>3</sup>
Reminder : Program reminder	77mmdd <i>↔</i>
Reminder : Program reminder	77mmddhhMM+³
Reminder : Delete reminder	770 <i>₽</i>
Music Player : Display curr. played	55₽
Music Player : Shuffle off / on	2224/5554
Music Player : Go to song 000 / xxx	8884 <sup>7</sup> / 888xxx <sup>4</sup>
Disable / Enable <b>Car Mode</b>	9904/9914
Forbid / Allow <b>Remote Control</b>	9924/9934
Restore stored dest./last dep. times	998₽
Toggle <b>Exhibition Mode</b>	999₽
Program Time for <b>Exhibition Mode</b>	99mmddyyyyhhMM⊷
Restart the Time Circuits	64738 <i>₽</i>

## Time Circuits Display



Holding keys for 2 seconds		
<b>1</b> Toggle <b>Alarm</b> on/off	<b>2</b> <b>Music Player</b> : Previous song	<b>3</b> Play "key3.mp3"
4 Toggle Night mode	<b>5</b> <b>Music Player :</b> Play/Stop	<b>6</b> Play "key6.mp3"
7 Re-enable WiFi	<b>8</b> <b>Music Player :</b> Next song	<b>9</b> Return from Time Travel
	O Time Travel	