## Time Circuits Display



Destination time programming		
Set date and time mmddyyyyhhMM↔		
Set date	te mmddyyyy <sup>₊7</sup>	
Set time	hhMM←³	

Special key sequences		
Disable <b>beep</b> sound	000←7	
Enable <b>beep</b> sound	001←7	
Enable <b>beep</b> sound (30/60 seconds)	0024/0034	
Toggle <b>Room Condition mode</b>	111+³	
Toggle <b>World Clock mode</b>	1124	
Toggle both WC and RC mode	113←	
<b>Alarm</b> : Show current setting	11← <sup>7</sup>	
Alarm: Set to hh:MM	11hhMM <i>⊷</i>	
Timer : Show remaining time	44₽	
<b>Timer</b> : Set timer to MM minutes	44MM+ <sup>7</sup>	
Timer : Delete timer	440₽	
Reminder : Display reminder	<i>77←</i> <sup>7</sup>	
Reminder : Display time until	<i>777+</i> ²	
Reminder : Program reminder	77mmdd+³	
Reminder : Program reminder	77mmddhhMM+³	
Reminder : Delete reminder	<i>770₽</i>	
Music Player : Display curr. played	55₽	
Music Player : Shuffle off / on	222 <del>4</del> / 555 <del>4</del>	
Music Player : Go to song 000	888₽	
Music Player : Go to song xxx	888xxx <i>⊷</i>	
Disable / Enable <b>Car Mode</b>	9904/9914	
Enable / disable <b>Exhibition Mode</b>	999~	
Program Time for <b>Exhibition Mode</b>	99mmddyyyyhhMM↔	
Restart the Time Circuits	64738₽	

## Time Circuits Display



Holding keys for 2 seconds		
<b>1</b> Toggle <b>Alarm</b> on/off	<b>2</b> <b>Music Player</b> : Previous song	<b>3</b> Play "key3.mp3"
4 Toggle Night mode	<b>5</b> <b>Music Player :</b> Play/Stop	<b>6</b> Play "key6.mp3"
7 Re-enable WiFi	<b>8</b> <b>Music Player :</b> Next song	<b>9</b> Return from Time Travel
	O Time Travel	