P. L. No. A352

FUEL INJECTOR

Fuel Injector Assembly With Calibration Slide

PLATE A352-2

Ref. No.	Part Number	Number Required					Description
Quantities listed are for one Injector Assembly.							
INJECTOR ASSEMBLY .. Fuel							
* 1	5228815	1	-	-	-	-	INJECTOR ASSEMBLY .. Fuel - .421 diameter plunger - Spherical check valve type - Low output
* 2	5228810	-	1	-	-	-	INJECTOR ASSEMBLY .. Fuel - .421 diameter plunger - Needle valve type - Low output
* 3	5228805	-	-	1	-	-	INJECTOR ASSEMBLY .. Fuel - .421 diameter plunger - Spherical check valve type - Medium output
4	5228800	-	-	-	1	-	INJECTOR ASSEMBLY .. Fuel - .421 diameter plunger - Needle valve type - Medium output
* 5	5228830	-	-	-	-	1	INJECTOR ASSEMBLY .. Fuel - .421 diameter plunger - Needle valve type
BODY ASSEMBLY .. Injector - Includes Calibration Slide							
* 6	5228759	1	1	-	-	-	BODY ASSEMBLY .. Injector - Includes calibration slide
7	5228761	-	-	1	1	1	BODY ASSEMBLY .. Injector - Includes calibration slide
8	5226912	2	2	2	2	2	PLUG .. Injector body
9	5226482	1	1	1	1	1	DOWEL .. Injector locating
10	5226727	1	1	1	1	1	PIN .. Injector rack guide
11	5226484	1	1	1	1	1	STUD .. Fuel connection
12	5228745	1	1	1	1	1	ADAPTER .. Injector body
13	5228758	1	1	1	1	1	SCREW .. Set - No. 8-32 x .220 hex. socket
14	9421614	1	1	1	1	1	SCREW .. Cap - No. 8-32 x 3/8 hex. socket
PLUNGER ASSEMBLY .. Injector							
*15	5227853	1	1	-	-	-	PLUNGER ASY. .. Injector - .421 dia. - Incl. pin and bushing
16	5228236	-	-	1	1	1	PLUNGER ASY. .. Injector - .421 dia. - Incl. pin and bushing
*17	5226450	1	1	-	-	-	PIN .. Bushing guide
18	5228343	-	-	1	1	1	PIN .. Bushing guide
FOLLOWER .. Injector							
19	5228139	1	1	1	1	1	FOLLOWER .. Injector - One piece
20	5227914	1	1	1	1	1	PIN .. Stop - Injector follower
21	5227904	1	1	1	1	1	SPRING .. Stop pin - Injector follower
22	5228184	1	1	1	1	1	RETAINER .. Stop pin - Injector follower
23	5226491	1	1	1	1	1	SPRING .. Injector plunger
NUT .. Injector Valve							
*24	5226573	1	-	1	-	-	NUT .. Injector valve
25	5228545	-	1	-	1	1	NUT .. Injector valve
26	5226571	1	1	1	1	1	SEAL .. Injector nut to body
27	5226574	1	1	1	1	1	DEFLECTOR .. Spill
RACK ASSEMBLY .. Injector							
28	5226496	1	1	1	1	1	RACK ASSEMBLY .. Injector
29	5226497	1	1	1	1	1	RACK .. Injector
30	5227401	1	1	1	1	1	PIN .. Injector rack control
31	5226498	1	1	1	1	1	GEAR .. Injector

P. L. No. A352

FUEL INJECTOR

Fuel Injector Without Calibration Slide

PLATE A352-1

Ref. No.	Part Number	Number Required				Description
						Quantities listed are for one Injector Assembly
						INJECTOR ASSEMBLY .. Fuel
1	5227852	1	-	-	-	INJECTOR ASSEMBLY .. Fuel - .421 dia. plunger - Spherical check valve type - Low output
2	5228565	-	1	-	-	INJECTOR ASSEMBLY .. Fuel - .421 dia. plunger - Needle valve type - Low output
* 3	5228230	-	-	1	-	INJECTOR ASSEMBLY .. Fuel - .421 dia. plunger - Spherical check valve type - Medium output
* 4	5228540	-	-	-	1	INJECTOR ASSEMBLY .. Fuel - .421 dia. plunger - Needle valve type - Medium output
						Spherical check valve type injectors can be converted to needle valve type injectors with use of injector conversion kits 5228716, 5228721 or 5228726; Refer to Page 4.
						BODY ASSEMBLY .. Injector
5	5226726	1	1	-	-	BODY ASSEMBLY .. Injector
* 6	5228245	-	-	1	1	BODY ASSEMBLY .. Injector
7	5226912	2	2	2	2	PLUNGER .. Injector body
8	5226482	1	1	1	1	DOWEL .. Injector locating
* 9	5226727	1	1	1	1	PIN .. Guide - Injector guide
*10	5226484	1	1	1	1	STUD .. Fuel connection
						PLUNGER ASSEMBLY .. Injector
11	5227853	1	1	-	-	PLUNGER ASY. .. Injector - .421 dia. - Includes pin and bushing
*12	5228236	-	-	1	1	PLUNGER ASY. .. Injector - .421 dia. - Includes pin and bushing
13	5226450	1	1	-	-	PIN .. Bushing guide
*14	5228343	-	-	1	1	PIN .. Bushing guide
						FOLLOWER .. Injector
15	5228139	1	1	1	1	FOLLOWER .. Injector - One piece
16	5227914	1	1	1	1	PIN .. Stop - Injector follower
17	5227904	1	1	1	1	SPRING .. Stop pin - Injector follower
18	5228184	1	1	1	1	RETAINER .. Stop pin - Injector follower
19	5226491	1	1	1	1	SPRING .. Injector plunger
						NUT .. Injector Valve
20	5226573	1	-	1	-	NUT .. Injector valve
21	5228545	-	1	-	1	NUT .. Injector valve
22	5226571	1	1	1	1	SEAL .. Injector nut to body
23	5226574	1	1	1	1	DEFLECTOR .. Spill
						RACK ASSEMBLY .. Injector
24	5226496	1	1	1	1	RACK ASSEMBLY .. Injector
25	5226497	1	1	1	1	RACK .. Injector
26	5227401	1	1	1	1	PIN .. Rack control
27	5226498	1	1	1	1	GEAR .. Injector
28	5226499	1	1	1	1	RETAINER .. Injector gear
29	5227273	1	-	1	-	SPACER .. Injector cage
30	5228572	-	1	-	1	SPACER .. Injector cage - Replaces spacer 5228537
31	5228571	-	1	-	1	CAGE .. Injector - Replaces spacer 5228537
32	5226950	-	1	-	1	VALVE .. Injector - Replaces spacer 5228537
33	5227271	1	-	1	-	STOP .. Check valve

P. L. No. A352

FUEL INJECTOR

(Not Illustrated)

Ref. No.	Part Number	No. Req.			Description
KIT .. Injector Conversion					
					The following Injector Conversion Kits are used to convert 5227852 and 5228230 spherical check valve type injectors into 5228565 and 5228540 needle valve type injectors.
50	5228716	1	-	-	KIT .. Injector conversion - Low fuel flow range
51	5228721	-	1	-	KIT .. Injector conversion - Medium fuel flow range - Replaces 5228546 and 5228573
52	5228726	-	-	1	KIT .. Injector conversion - High fuel flow range
53	5228712	1	-	-	TIP ASSEMBLY .. Spray - Ref. No. 41
54	5228713	-	1	-	TIP ASSEMBLY .. Spray - Ref. No. 41
55	5228714	-	-	1	TIP ASSEMBLY .. Spray - Ref. No. 41
56	5228545	1	1	1	NUT .. Injector valve - Ref. No. 21
57	5228539	1	1	1	SPRING .. Injector valve - Ref. No. 35
58	5228538	1	1	1	CAGE .. Spring - Ref. No. 37
59	5228541	1	1	1	SEAT .. Valve spring - Ref. No. 38
60	5228572	1	1	1	SPACER .. Injector cage - Ref. No. 30
61	5228571	1	1	1	CAGE .. Injector - Ref. No. 31
62	5226950	1	1	1	VALVE .. Injector - Ref. No. 32
KIT .. Injector Repair					
					The following Injector Repair Kits are used to repair 5227852 and 5228230 spherical check valve type injectors.
63	5228727	1	-	-	KIT .. Injector repair - Low fuel flow range
64	5228728	-	1	-	KIT .. Injector repair - Medium fuel flow range - Replaces 8200662
65	5228729	-	-	1	KIT .. Injector repair - High fuel flow range
66	5226571	1	1	1	SEAL .. Injector nut to body - Ref. No. 22
67	5227273	1	1	1	SPACER .. Injector cage - Ref. No. 29
68	5226411	1	1	1	VALVE .. Flat check - Ref. No. 39
69	5228702	1	-	-	TIP ASSEMBLY .. Spray - Ref. No. 42
70	5228703	-	1	-	TIP ASSEMBLY .. Spray - Ref. No. 42
71	5228704	-	-	1	TIP ASSEMBLY .. Spray - Ref. No. 42
72	5228016	1	1	1	SPRING .. Check valve - Ref. No. 34
73	5227271	1	1	1	STOP .. Check valve - Ref. No. 33
74	5227274	1	1	1	VALVE ASSEMBLY .. Injector - Includes valve and seat - Ref. No. 40
KIT .. Injector Repair					
					The following Injector Repair Kits are used to repair 5228540 and 5228565 needle valve type injectors.
75	5228707	1	-	-	KIT .. Injector repair - Low fuel flow range
76	5228708	-	1	-	KIT .. Injector repair - Medium fuel flow range
77	5228709	-	-	1	KIT .. Injector repair - High fuel flow range
78	5228712	1	-	-	TIP ASSEMBLY .. Spray - Ref. No. 41
79	5228713	-	1	-	TIP ASSEBMLY .. Spray - Ref. No. 41
80	5228714	-	-	1	TIP ASSEMBLY .. Spray - Ref. No. 41
81	5228572	1	1	1	SPACER .. Injector cage - Ref. No. 30
82	5226950	1	1	1	VALVE .. Injector - Ref. No. 32
83	5228571	1	1	1	CAGE .. Injector - Ref. No. 31
84	5228538	1	1	1	CAGE .. Spring - Ref. No. 37
85	5228539	1	1	1	SPRING .. Injector valve - Ref. No. 35
86	5228541	1	1	1	SEAT .. Injector valve spring - Ref. No. 38

Fuel Injector Without Calibration Slide
PLATE A352-4

Ref. No.	Part Number	No. Req.	Description
INJECTOR ASSEMBLY			
1	5228585	1	INJECTOR ASSEMBLY .. Fuel - .421 dia. plunger - Needle valve type
2	5226726	1	BODY ASSEMBLY .. Injector
3	5226912	2	PLUG .. Injector body
4	5226482	1	DOWEL .. Injector locating
* 5	5226727	1	PIN .. Injector rack guide
* 6	5226484	1	STUD .. Injector fuel connection
PLUNGER ASSEMBLY			
7	5227853	1	PLUNGER ASSEMBLY .. .421 dia. - Includes pin and bushing
8	5226450	1	PIN .. Bushing guide
FOLLOWER .. Injector			
9	5228139	1	FOLLOWER .. Injector - One piece
10	5227914	1	PIN .. Stop - Injector follower
11	5227904	1	SPRING .. Stop pin - Injector follower
12	5228184	1	RETAINER .. Stop pin - Injector follower
13	5226491	1	SPRING .. Injector plunger
NUT .. Injector Valve			
14	5228545	1	NUT .. Injector valve
15	5226571	1	SEAL .. Injector nut to body
16	5226574	1	DEFLECTOR .. Spill
RACK ASSEMBLY .. Injector			
17	5226496	1	RACK ASSEMBLY .. Injector
18	5226497	1	RACK .. Injector
19	5227401	1	PIN .. Injector rack control
20	5226498	1	GEAR .. Injector
21	5226499	1	RETAINER .. Injector gear
22	5228572	1	SPACER .. Injector cage
23	5228571	1	CAGE .. Injector
24	5226950	1	VALVE .. Check
25	5228539	1	SPRING .. Injector valve
26	5228538	1	CAGE .. Injector valve spring
27	5228541	1	SEAT .. Injector valve spring
TIP ASSEMBLY .. Spray			
28	5228562	1	TIP ASSEMBLY .. Spray - Includes spray tip and needle valve
29	5228013	2	ELEMENT .. Filter - Stainless steel
30	5226415	2	SPRING .. Injector filter
31	5226186	2	GASKET .. Injector filter cap
32	5226512	2	CAP .. Injector element
*33	8032718	2	NUT .. Elastic stop - Fuel line to injector
34	5226714	1	BLOCK .. Injector - Shipping and storage
*35	271505	1	NUT .. Hex. - Shipping and storage - Replaces 103027
KIT .. Basic Injector Repair			
*36	5228836	1	KIT .. Basic injector repair
*37	5226571	1	SEAL .. Injector nut to body - Ref. No. 15
*38	5228539	1	SPRING .. Valve - Injector - Ref. No. 25
*39	5226186	2	GASKET .. Filter cap - Ref. No. 31
*40	5228013	2	ELEMENT .. Filter - Stainless steel - Ref. No. 29