Rear Suspension

Bushing Installation -Lower arm No projection No projection Lower arm B 6 ± 0.5 mm $(0.2 \pm 0.02 in)$

Rear Damper

Removal -

- Remove the bolt fixing the brake hose to the damper assembly.
- 2. Peel off the carpet in the luggage compartment, then remove the 10 mm nuts.
- 3. Remove the damper mounting bolt.
- Depress the entire suspension, then remove the damper assembly.

