

- 11. Power Steering (4WS only)

· · · · · · · · · · · · · · · · · · ·						
Number	Tool Number	Description	Qʻty	Remarks		
1	07HAA-SF10100	Lock Nut Socket 36 x 41 mm	1			
2	07HAG-SF10000	4WS Tool Kit	1			
②-1	07HAG-SF10100	Piston Seal Ring Guide	(1)			
②-2	07HAG-SF10200	Piston Seal Ring Sizing Tool	(1)			
②-3	07HAG-SF10300	Pinion Seal Ring Guide	(1)			
②-4	07HAG-SF10400	Pinion Seal Sizing Tool	(1)	-Component tools		
②-5	07HAG-SF10500	Driver Seal Ring Guide	(1)			
②-6	07HAG-SF10600	Tool Box	(1)			
3	07HAJ-SF10100	Rack Adjuster Gauge Holder Set	1			
4	07HAJ-SF10201	Rear Adjuster Center Lock Pin	1			
(5)	07HAJ-SF10300	Stroke Rod Holder Set	1			
6	07HAJ-SF10400	Inspection Adaptor	1 1			
7	07703-0010101	Torx Driver Bit T40	1			
8	07746-0010700	Attachment 24 x 26 mm	1			

12. Suspension ————

_ 12. Suspension ————————————————————————————————————						
Number	Tool Number	Description	Q'ty	Remarks		
1	07GAE-SE00101	Spring Compressor	1	may also be used 07GAE-SE00100		
2	07GAF-SD40700	Hub Dis/Assembly Base	2			
3	07GAF-SE00100	Hub Assembly Pin	1			
② ③ ④ ⑤ ⑥ ⑦ ⑧	07GAF-SE00200	Front Assebmly Driver Attachment	1			
(5)	07GAF-SE00401	Front Hub Base	1			
6	07GAG-SD40700	Ball Joint Boot Clip Installation Guide	1			
7	07GAK-0010100	Wheel Alignment Gauge Attachment	1			
8	07HAD-SF10100	Hub Bearing Driver	1			
9	07HAF-SF10100	Ball Joint Dis/Assebmly Tool Kit	1			
9-1	07HAF-SF10110	Ball Joint Remover Base	(1)	_		
9-2	07HAF-SF10120	Ball Joint Installer Base	(1)	-Component tools		
9-3	07HAF-SF10130	Ball Joint Remover/Installer	(1)	<u>_</u>		
10	07HAF-SF10200	Bearing Supporting Attachment	1			
(1) (12)	07HAJ-SF10201	Rear Steering Center Lock Pin	1			
12	07HGJ-0010000	Toe Inspection Gauge Set	1			
13	07703-0010100	Torx Driver Bit T40	1			
14)	07746-0010400	Attachment, 52 x 55 mm	1			
15	07746-0010500	Attachment, 62 x 68 mm	1			
16	07749-0010000	Driver	1			
17)	07941-6920003	Ball Joint Remover	1			
18	07965-SB00000	Ball Joint Dis/Assembly Tool Set	1			
18-1	07965-SB00100	Ball Joint Remover Base	(1)			
18-2	07965-SB00200	Ball Joint Installer Base	(1)	- Component tools		
18-3	07965-SB00300	Ball Joint Remover/Installer	(1)			
(19)	07965-SD90100	Supporting Base	1			
(19) (20)	07965-6920201	Front Hub Dis/Assembly Tool, B	1			
(1)	07974-SA50700	Ball Joint Boot Clip Installation Guide	1			
22	07974-SA50800	Ball Joint Boot Clip Installation Guide	1			