

Recirculation Control Motor -

- Connect the battery positive to the 3 terminal of the recirculation control motor connector and negative to 1 terminal.
- Using a jumper wire connect the 1 terminal and 2 or 4 terminal.
 - On the recirculation door REC position, the motor should turn with the 1 terminal connected to 4 terminal.
 - On the door FRESH position, the motor should turn with the 1 terminal connected to 2 terminal.
- 4. The motor automatically stops after half turn with the jumper wire connected.

