Seats

Front Disassembly

Disassemble in numbered sequence.

HEADREST

FLAT-TIP SCREWDRIVER

HEADREST GUIDE

⑤ SEAT BACK

SIDE SUPPORT KNOB

LUMBAR SUPPORT KNOB

④ PIVOT NUT
22 N·m (2.2 kg-m, 16 lb-ft)

⑤ SEAT CUSHION

CONTROL UNIT
(Heated seat only)

③ CENTER COVER

⑤ SEAT TRACK

④ RECLINING ADJUSTER
MOUNTING NUTS
22 N·m (2.2 kg-m, 16 lb-ft)

④ SEAT BACK
MOUNTING BOLTS
10 x 1.25 mm
43 N·m (4.3 kg-m, 31 lb-ft)

③ ADJUSTER COVER

⑤ RECLINING ADJUSTER

⑤ SEAT TRACK

④ SEAT CUSHION
MOUNTING BOLT
10 x 1.25 mm
43 N·m (4.3 kg-m, 31 lb-ft)

② SEAT TRACK
MOUNTING BOLTS
10 x 1.25 mm
32 N·m (3.2 kg-m, 23 lb-ft)

④ RECLINING ADJUSTER, MOUNTING BOLT
8 x 1.25 mm
22 N·m (2.2 kg-m, 16 lb-ft)