

Air Cleaner Air Cleaner Element Replacement **AIR FLOW TUBE AIR CLEANER ELEMENT** • EC: Replace every 2 years or 40,000 km (24,000 miles) whichever comes first. • Others: Replace every 1 year or 20,000 km (12,000 miles) whichever comes first. BREATHER HOSE - AIR CLEANER CASE