Trunk

Lid Replacement/Adjustment -

- 1. Remove the trunk lid hinge bolts, then lift off the lid.
- 2. Remove the torsion bar using a release tool.
- 3. Remove the rear shelf.
- 4. Remove the hinge bracket mounting bolts, then remove the hinges from the trunk.
- 5. Assemble in the reverse order.

NOTE: Before tightening the hinge bolts, check the adjustments shown below:

