
Bleeding

ALB

Air Bleeding with ALB Checker -

NOTE: Do not depress the brake pedal while using the ALB checker to bleed air from the system.


- Fill the modulator reservoir with brake fluid up to the MAX level.
- Disconnect the 6P coupler (PNK) from the cover mounted in front of the console and connect it to the ALB checker.



CAUTION: Place the car on level ground with the wheels blocked. Shift the transmission to ${\bf P}$ or Nutral.


- 3. Start the engine.
- 4. Release the parking brake.
- 5. Turn the power switch of ALB checker ON.






- 6. Turn the mode selector switch to 1.
- 7. Press the start switch.
- 8. Make sure that the motor runs.
- 9. Wait for the motor to stop.

10. Turn the mode switch to 2.



- 11. Press the start switch.
- Brake fluid in the reservoir will bubble briskly for 20 seconds after the switch is pressed. Wait for 4 to 5 minutes until the brake fluid stops bubbling.
- 13. Turn the mode switch to 6.
- 14. Repeat steps 11 and 12.
- 15. Repeat steps 10 through 14 two or three times.
- 16. Fill the reservoir with brake fluid up to the MAX level.



- 17. install the cap.
- Check the ALB function in all modes (page 13-44).
 There should be kickback in modes 2 through 6.

CAUTION: If the kickback is weak, re-bleed air from the system.