Software Installation

- Work instruction

Revision History				
Rev	ECO	Changes	Author	
1	N/A	Initial release	DSK	

Template: QMS-40-003-TEM, Rev.001 Page 1 of 3

Table of Contents

1	Scope/Purpose	2
2	References	2
3	Installation of software on the Allen-Bradley CompactLogix 5370 PLC	2
4	Installation of software on the Allen-Bradley PanelView 800 4" TFT touch screen	3
1	Scope/Purpose	

The purpose of the present document is to provide instructions on how to place the correct software on the PLC and HMI of the AAU Pandemic Ventilator

2 References

- **Ref 1.** VENT-40-004-BIN PLC (Executable)
- Ref 2. VENT-40-006-BIN HMI (Executable)
- 3 Installation of software on the Allen-Bradley CompactLogix 5370 PLC
 - 1) Power off PLC.
 - 2) Retrieve the [VENT-40-004-BIN PLC (Executable)] zip file and unpack it.
 - 3) Place the unpacked contents of [VENT-40-004-BIN PLC (Executable)] to a SD card
 - 4) Insert SD card in PLC where indicated in figure below.
 - 5) Power on device and installation starts automatically.



- 4 Installation of software on the Allen-Bradley PanelView 800 4" TFT touch screen
 - 1) Power off PLC and screen.
 - 2) Unpack the [VENT-40-006-BIN HMI (Executable)] zip file and place its contents on an USB stick.
 - 3) Insert the USB stick as indicated in figure below.
 - 4) Power on device and installation starts automatically.





Template: QMS-40-003-TEM, Rev.001