Assembly: SOURCE PIN -> DESTINATION PIN / 3

Every canonical row is shown exactly once. INTERNAL_VERIFY is an existing module bond to inspect, not a wire to add.

E2 DESIGN HOLD | Physical connections unapproved | Generic ports require actual-part mapping | 08 Nov 2026

W045	**TB_GND.BUS -> DRV_L.B-** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W046	**DRV_L.B- -> DRV_L.GND** GND | INTERNAL_VERIFY | 0 V reference; returns sized by branch	PROVISIONAL
W047	**TB_GND.BUS -> DRV_R.B-** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W048	**DRV_R.B- -> DRV_R.GND** GND | INTERNAL_VERIFY | 0 V reference; returns sized by branch	PROVISIONAL
W049	**TB_GND.BUS -> DRV_A.GND** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W050	**BUCK2.OUT- -> US_F.GND** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W051	**BUCK2.OUT- -> US_L.GND** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W052	**BUCK2.OUT- -> US_R.GND** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W053	**BUCK2.OUT- -> U1.10 (GND)** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W054	**U1.10 (GND) -> U1.1 (1OE_N)** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W055	**U1.10 (GND) -> U1.19 (2OE_N)** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W056	**TB_GND.BUS -> K1.A2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W057	**K1.A2 -> Z_COIL.A2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W058	**ESP1.GND -> R24.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W059	**ESP1.GND -> R26.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W060	**ESP1.GND -> R28.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W061	**U1.10 (GND) -> R1.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W062	**U1.10 (GND) -> R2.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W063	**U1.10 (GND) -> R3.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W064	**U1.10 (GND) -> R4.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W065	**U1.10 (GND) -> R5.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W066	**U1.10 (GND) -> R6.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL

Red +supply | Black GND | Blue control | Green sensor | Orange motor | Thick = high-current | Dashed = missing/blocked

Net labels join across sheets. Crossings alone do not join. No component footprint / connector orientation is implied.