Assembly: SOURCE PIN -> DESTINATION PIN / 4

Every canonical row is shown exactly once. INTERNAL_VERIFY is an existing module bond to inspect, not a wire to add.

E2 DESIGN HOLD | Physical connections unapproved | Generic ports require actual-part mapping | 08 Nov 2026

W067	**U1.10 (GND) -> R7.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W068	**U1.10 (GND) -> R8.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W069	**DRV_A.GND -> R9.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W070	**DRV_A.GND -> R10.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W071	**DRV_A.GND -> R11.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W072	**DRV_A.GND -> R12.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W073	**DRV_L.GND -> R13.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W074	**DRV_L.GND -> R14.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W075	**DRV_R.GND -> R15.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W076	**DRV_R.GND -> R16.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W077	**DRV_A.GND -> R17.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W078	**DRV_A.GND -> R18.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W079	**DRV_L.GND -> R19.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W080	**DRV_L.GND -> R20.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W081	**DRV_R.GND -> R21.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W082	**DRV_R.GND -> R22.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W083	**ESP1.GND -> R29.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W084	**U1.10 (GND) -> C_U1.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W085	**US_F.GND -> C_F.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W086	**US_L.GND -> C_L.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W087	**US_R.GND -> C_R.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W088	**DRV_L.B- -> C_BL.-** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL

Red +supply | Black GND | Blue control | Green sensor | Orange motor | Thick = high-current | Dashed = missing/blocked

Net labels join across sheets. Crossings alone do not join. No component footprint / connector orientation is implied.