Assembly: SOURCE PIN -> DESTINATION PIN / 5

Every canonical row is shown exactly once. INTERNAL_VERIFY is an existing module bond to inspect, not a wire to add.

E2 DESIGN HOLD | Physical connections unapproved | Generic ports require actual-part mapping | 08 Nov 2026

W089	**DRV_R.B- -> C_BR.-** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W090	**DRV_A.GND -> C_BA.-** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W091	**BUCK1.OUT- -> OV1.GND** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W092	**BUCK2.OUT- -> OV2.GND** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W093	**DRV_L.B- -> Z_L.-** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W094	**DRV_R.B- -> Z_R.-** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W095	**DRV_A.GND -> Z_A.-** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W096	**ESP1.GND -> U2.4 (GND)** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W097	**U2.4 (GND) -> C_U2.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W098	**ESP1.GND -> R30.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W099	**ESP1.GND -> R31.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W100	**ESP1.GND -> R32.2** GND | WIRE | 0 V reference; returns sized by branch	PROVISIONAL
W101	**BT1.BAL_CELL0 -> P1.CELL0** CELL0 | WIRE | Cell-stack potential; order TBD	BLOCKED_RATING
W102	**BT1.BAL_CELL1 -> P1.CELL1** CELL1 | WIRE | Cell-stack potential; order TBD	BLOCKED_RATING
W103	**BT1.BAL_CELL2 -> P1.CELL2** CELL2 | WIRE | Cell-stack potential; order TBD	BLOCKED_RATING
W104	**BT1.BAL_CELL3 -> P1.CELL3** CELL3 | WIRE | Cell-stack potential; order TBD	BLOCKED_RATING
W105	**FK.OUT -> OV1.PG_COM** COIL_FUSED | WIRE | Pack voltage; K1 coil compatibility TBD	BLOCKED_RATING
W106	**S2.COIL_NC -> S3.COM** COIL_STOP_CHAIN | WIRE | Coil supply when stop released	BLOCKED_MISSING
W107	**S2.COIL_NC -> K1.AUX_HOLD_COM** COIL_STOP_CHAIN | WIRE | Coil supply when stop released	BLOCKED_MISSING
W108	**S3.NO -> K1.AUX_HOLD_NO** COIL_HOLD | WIRE | Coil supply when manually latched	BLOCKED_MISSING
W109	**S3.NO -> K1.A1** COIL_HOLD | WIRE | Coil supply when manually latched	BLOCKED_MISSING
W110	**S3.NO -> Z_COIL.A1** COIL_HOLD | WIRE | Coil supply when manually latched	BLOCKED_MISSING

Red +supply | Black GND | Blue control | Green sensor | Orange motor | Thick = high-current | Dashed = missing/blocked

Net labels join across sheets. Crossings alone do not join. No component footprint / connector orientation is implied.