SerialPortManager

SerialPortManager Quick Guide

Version 0.3.0-rc.6 - Edition 2026-10-09

Copyright © 2026 Fation Coga. All rights reserved.

SerialPortManager is proprietary software of Fation Coga, licensed per PC (see LICENSE.md). This manual is part of the product: no part of it may be reproduced or distributed without the written permission of the copyright owner.

Contents

1. What it is 3

2. Install and first start 3

3. Open a port 4

4. Send 4

5. Read the console 4

6. Auto replies, periodic messages, forwarding, files 5

7. Right-click a message: analysis 5

8. The Protocols window 6

9. More tools 7

10. License 7

11. Help and support 7

12. Legal notices 7

Copyright © 2026 Fation Coga. All rights reserved.

Version 0.3.0 - SerialPortManager (SerialPM) for Windows.

Copyright (C) 2026 Fation Coga. All rights reserved.


1. What it is

SerialPortManager (SerialPM) is a Windows tool for serial ports: COM ports, USB-serial adapters, RS-232 / RS-422 / RS-485 converters. It shows everything received and sent, sends data typed in hexadecimal or text, replies automatically, sends periodic messages, forwards data between ports, transfers files, and analyses bytes: checksums and CRCs, numbers in every byte order, Modbus and NMEA frames, and the waveform on the wires.

Several ports work at the same time: each one has its own tab with its own port, console and automation. This guide covers the essentials; the **User Manual** (**Help > User Manual**, F1) describes every feature.

2. Install and first start

1. Copy the program folder to a place where you can write (not *Program Files*) and start **SerialPortManager.exe**. No installer is needed.
2. At the first start the program creates the folder **SerialPortManager data** next to the exe. It holds the settings (AppSettings.txt), the event database (events.db), the log (log.txt), the language files and the license. **Settings > Open Data Folder** opens it.
3. The 14-day trial starts: every feature is available. The status bar shows **Trial: N day(s) left**.
4. Optional: **Settings > Language...** (English / Italiano) and **Settings > Theme...** (Light / Dark). The program asks **Restart now**, **Use now**, **Save for next start** or **Cancel**.



The main window

The main window has the menus **File**, **Serial**, **Tools**, **Settings**, **Help**; one tab per port; the **Application log** at the bottom; and a status bar with messages, the port state of the selected tab and the license state.

3. Open a port

1. Choose **Serial > Serial Ports...** to set **How many serial ports to control:** (one tab each, at most the number of ports present) and a **Name:** for each; **Configure...** sets the port of each slot. For one tab only, click **Settings...** in the tab.
2. In the **Serial Port** dialog choose **Port** (**Refresh** reads the list again), **Baud rate**, **Data bits**, **Parity**, **Stop bits**, **Flow control** and the timeouts. The default is 9600 8N1, no flow control.
3. Click **Open Port**. The LED turns green and the button becomes **Close Port**.

A port belongs to one tab only: a port used elsewhere is listed as **(already used by Slot N)**; choosing it asks **Detach and use here** or **Abort**.

Inter-byte timeout (ms) decides when a received message ends: bytes are grouped into one console line until the line is quiet for that time. Increase it if messages appear split, decrease it if several messages appear merged.

Receive: Edit... in the tab cuts messages differently - by a delimiter (CR LF), a fixed length, a length field or Modbus RTU timing - and can check the checksum / CRC of every received message (**[CRC-16/MODBUS ok]** green, **WRONG** red).

The port row also has the control lines: **RTS** and **DTR** (outputs, remembered), the LEDs **CTS**, **DSR**, **DCD**, **RI** (inputs) and **Break** (250 ms). If a USB adapter is unplugged, the port is closed and opened again when it comes back (orange LED, **Stop Waiting**). The port list shows what each device is, for example *COM3 (USB-SERIAL CH340)*.

4. Send

The **Send** box has three notations:

Notation	Example
Hex	`01 03 00 0A` (spaces are added for you)
ASCII	`HELLO` (printable characters only)
Mixed	`OK//0x0D//0x0A` (text, and `//0x` + two hex digits for any byte)

Type the data and press **Enter** or click **Send**. Clicking another notation converts the text; the bytes stay the same. **Insert character...** opens a table of all 256 byte values: double-click adds a character and closes the table, right-click adds it and keeps the table open. A mistake is shown in red under the text, for example **Character 7: only hex digits (0-9, A-F) are allowed.**

Append: adds **CR**, **LF** or **CR and LF** to every message sent, without showing it in the text. **Counter / CRC...** inserts an incrementing counter (1-8 bytes, step per send, little- or big-endian) and a checksum / CRC (any algorithm of the Byte Analyzer), each at the place you choose: last, before the last byte, first... - the dialog previews the next message, for example `01 03 00 00 00 01 [07] {4B A1} 0D 0A`.

Up / **Down** in the text bring back the messages sent. **Commands** next to **Send**: saved commands sent with one click, **Save the text as a command...**, and the history.

5. Read the console

Every message is one line of the console:

```
14:03:21.512  RX (5)  HELLO        48 45 4C 4C 4F
```

Time, label and byte count and the bytes as text (control bytes as `[0D=CR]`, bytes above 7E as `[HH]`) on the left; the same bytes in hex in the right pane, line for line - the two panes scroll together. Labels and colours: **RX** blue (received), **TX** orange (sent by you), **TX auto "name"** purple (auto reply), **TX periodic**

Copyright © 2026 Fation Coga. All rights reserved.

"name" green, **TX fwd "tab"** teal (forwarded), file transfer lines amber, errors red.


Options above the console: **Time**, **Hex too** (the hex pane), **Format characters** (CR, LF and CR LF start a new line, tabs become spaces - **Tab width...**), **Follow newest** (both panes; turn it off to read older lines while data arrives) and **Clear**.

Right-click menu of the console, besides the analysis: **Export console...** (text or CSV), **Find...** (Ctrl-F: find bar, **Only matching lines**), **Show** (received / sent / notes), **Highlight rules...** (a text or bytes on a colour), **Time since the previous message (delta)**, **Statistics...**. In the File box: **Capture...** the traffic to a file (`*.spmcap` with times, or raw `*.bin`), **Replay...** a capture, **Export Console...**.

6. Auto replies, periodic messages, forwarding, files

- **Auto replies**: **Edit...** next to the switch (or **Serial > Auto Replies...**), **Add...**: **When these bytes are received**, **Reply with**, **Delay before replying (ms):**. Tick the rule and the **Auto replies** switch.
- **Periodic messages**: **Edit...** next to the switch, **Add...**: **Send every (ms):** and the **Message**. Tick it and the **Periodic messages** switch.
- Both messages can contain **incrementing values** (counters written over the bytes at their index) and a **checksum** (SUM, XOR, LRC, CRC-8, CRC-16/MODBUS, CRC-32...) inserted where you choose. The preview shows the first messages.
- **Forward received to:** sends everything this port receives out of another tab's port.
- **File**: **Send File...**, **Sending Options...** (chunk size; pause after each chunk, or burst mode waiting for a confirmation; start prefix, end marker, recovery), **Send**. On the receiving side **Catch File...** writes the received file to the output file. **Use the recommended value** on every command makes two SerialPortManager installations understand each other.

7. Right-click a message: analysis



The console right-click menu

Copyright © 2026 Fation Coga. All rights reserved.


Right-click a message in the console - or select some of its bytes, in the text or in the hex part, also across lines, and right-click the selection. The menu shows **Message of N bytes** or **N selected bytes**, then:

- **Checksums / CRC...**, **Integers and floats (byte order)...**, **Signal simulation (waveform)...**, **Interpret as protocol (Modbus, NMEA...)...**: each opens a **Byte Analyzer** on that page;
- **Quick values (click to copy)**: CRC-16/MODBUS (with its two bytes, low byte first), CRC-16/CCITT-FALSE, CRC-16/XMODEM, CRC-32, CRC-8, XOR, SUM8, LRC; for 2, 4 or 8 bytes also the integer and float values in BE, LE and CDAB order. Click one to copy it;
- **Copy**, **Copy bytes as hex**, **Select all**, **Clear console**, **Protocols (info and simulation)...**.

Tools > Byte Analyzer... (Ctrl-B) opens an analyzer on the bytes of the send box. Several analyzers can be open at once; the bytes at the top can be edited. Its pages:

- **Checksums / CRC**: about 50 sums and CRCs with their published parameters, the bytes to append (big-endian and little-endian), **Message ends with it** (green when the message already ends with that checksum - this finds the checksum a device uses), **Used by**, and **Any CRC (Rocksoft parameters)**.
- **Integers / floats**: every type from Int8 to UInt64, Int24, Float16/32/64 and BCD at an **Offset**, in byte order ABCD, DCBA, BADC or CDAB, with **Scale x**; and **Value to bytes**, which finds a value in the message.
- **Signal**: the waveform of the bytes, starting from the port's baud rate, data bits, parity and stop bits.
- **Protocol**: **Automatic**, **Modbus RTU**, **Modbus ASCII**, **NMEA 0183** or **Bytes one by one**; each field with its byte range, correct checks in green, wrong ones in red.

8. The Protocols window



The Protocols window, CAN tab

Tools > Protocols (info and simulation)... (Ctrl-P) opens an independent window, **Standard communication protocols - information and simulation**. The **Overview** tab compares the protocols;

Copyright © 2026 Fation Coga. All rights reserved.

one tab each explains and simulates **UART (TTL)**, **RS-232**, **RS-422**, **RS-485**, **SPI**, **I2C**, **1-Wire**, **CAN**, **LIN**, **JTAG** and **NRZ / Manchester**:

- left: signals needed (minimum and maximum), levels, speeds, distances, frame, error checks;
- right: **Data:** and every parameter of the protocol, and the live waveform.

The waveform shows a time ruler, a **Fields** row (each character in a box, alternately red and green; protocol fields in blue), one row per wire with the meaning of its levels, 0 / 1 over every bit and the role of protocol bits under it (ST, SP, PAR, ACK, NAK, STF...). The wheel scrolls sideways, Shift + wheel up and down, Ctrl + wheel zooms at the mouse; the buttons minus, **+**, **Fit** and **1:1** set the zoom. The line under the view tells time, field, level and bit under the mouse.

9. More tools

- **Tools > Modbus Master...** (Ctrl-M): reads and writes coils and registers of a Modbus RTU / ASCII slave through a tab's port - functions 01-06, 15, 16, once or **Poll every N ms**; values as 16 / 32-bit integers or floats; a log with answers, exceptions and timeouts.
- **Tools > Serial Plotter...** (Ctrl-L): draws the numbers a device prints, one line per sample (`21.5,40` or `temp:21.5 hum:40`), one colour per value; **Pause**, scale, **Export CSV...**.
- **Tools > Test Sequences...** (Ctrl-T): a script - `send "AT\r\n"`, `expect "OK" within 500`, `delay 100`, `repeat 3` ... `end` - run against the device; every expectation PASS / FAIL, the run **PASSED** or **FAILED**.
- **File > Export Profile...** / **Import Profile...**: the whole setup of the ports (settings, automation, receive options, commands, highlights) in a file.

10. License

- The 14-day trial includes every feature. Afterwards, without a license, the program still opens ports and shows and logs everything received (and the Byte Analyzer and Protocols window keep working); sending (also commands, replay, the Modbus master and test sequences), auto replies, periodic messages, file transfer and forwarding need a license.
- Licenses are per PC. Open **Help > License...** (Ctrl-K): it shows the state, the features and **This PC's unique ID (UID):** with **Copy**.
- To get a license, send the UID - or the request file from **Save Request...** (also in the data folder as license-request.txt) - to the license issuer.
- Install the license you receive with **Load License...**, **Paste License**, or by dropping the file on the License window. **Remove License** keeps a copy as license.lic.bak.

11. Help and support

- **Help > User Manual** (F1): the complete manual, in the language in use. **Help > Quick Guide**: this guide. Both are PDF files in the **manuals** folder next to the exe.
- **Help > Version Info...**: version, build, data folder and version history. **Help > About...**: copyright and libraries.
- For support, set **Settings > Log Level...** to Debug, repeat the problem and send log.txt from the data folder (**Settings > Open Data Folder**) to the licensor, Fation Coga, together with the version shown in **Version Info...**.

12. Legal notices

Copyright © 2026 Fation Coga. All rights reserved.

Copyright (C) 2026 Fation Coga. All rights reserved. SerialPortManager and this guide are the property of Fation Coga. SerialPortManager is proprietary software licensed per PC under its License Agreement (LICENSE.md). No part of this guide may be reproduced or distributed without the written permission of the copyright owner.

Third-party components, each under its own licence (notices in THIRD-PARTY-NOTICES.md, shipped next to the exe): wxWidgets (wxWindows Library Licence, the wxWidgets team), SQLite (public domain), serial (CogaF fork of wjwwood/serial, MIT licence), TweetNaCl (public domain).

Microsoft and Windows are trademarks of Microsoft Corporation. SQLite is a registered trademark of Hipp, Wyrick & Company, Inc. Modbus is a registered trademark of Schneider Electric USA, Inc. I²C is a trademark of NXP B.V. 1-Wire and iButton are registered trademarks of Maxim Integrated Products, Inc. (now Analog Devices, Inc.). CAN is standardised in ISO 11898, developed by Robert Bosch GmbH; LIN is standardised in ISO 17987; NMEA 0183 is a standard of the National Marine Electronics Association. JTAG is standardised in IEEE 1149.1. Arm and CoreSight are trademarks of Arm Limited. All other names belong to their owners and are used only to identify the products and protocols.