WELCOME NOTE

Thank you for choosing MythToy. We are dedicated to crafting intimate experiences that blend elegance with peak performance. Your journey to pleasure starts here.

PRODUCT ANATOMY

- Vibration Head: Medical-grade silicone, fully flexible.
- LCD Display: Shows battery life, vibration mode, and speed level.
- Control Panel:
- (+) Button: Increase Speed
- (⏻) Power Button: Power On/Off & Mode Switch
- (-) Button: Decrease Speed
- Charging Port: Type-C USB (Located at the base).

HOW TO USE

1. **Power On/Off:** Press and hold the **Power Button (⏻)** for 1.5 seconds. The LCD screen will light up.
2. **Change Modes:** Short press the **Power Button** to cycle through **10 vibration patterns**.
3. **Adjust Intensity:**
    - Press **(+)** to increase intensity.
    - Press **(-)** to decrease intensity.
    - There are **4 speed levels** available for each pattern.

CHARGING

- Cable Type: USB Type-C (Included).
- How to Charge: Insert the Type-C cable into the port at the bottom of the wand. Connect the other end to a 5V USB adapter or computer.
- Status: The indicator/screen will flash while charging and remain solid when fully charged.
- Charging Time: Approx. 3 Hours.
- Usage Time: Approx. 2 Hours (depending on intensity).
- Note: For safety, the device cannot be turned on while charging.

SPECIFICATIONS

- Model: The Scepter (Smart Wand)
- Materials: Body-Safe Silicone + ABS
- Size: 300mm x 53mm (11.8" x 2.1")
- Noise Level: < 60dB
- Modes: 10 Patterns x 4 Speeds
- Input: 5V / 410mA
- Water Resistance: IPX6 (Splash-proof. Do not submerge in water).

CLEANING & CARE

1. **Clean:** Wash the silicone head with warm water and antibacterial soap or toy cleaner before and after use.
2. **Dry:** Wipe with a lint-free cloth or allow to air dry.
3. **Store:** Keep in the included velvet pouch or a dust-free environment. Avoid direct sunlight.

SAFETY WARNINGS

- Do not use on swollen or inflamed skin.
- Stop use immediately if you feel discomfort.
- Keep out of reach of children.
- Avoid using silicone-based lubricants as they may damage the surface. Water-based lubricant is recommended.
- Do not boil or wash with boiling water.

WARRANTY

MythToy provides a 1-year warranty against manufacturing defects.

Contact: support@mythtoy.com