TEENSY ADAPTER / CONTINUOUS WIRING

Same circuit and PCB pin numbers | One sheet, no electrical net labels | Review copy 21 Oct 2026

Dots join wires. Crossings without dots do not join. Connector units are parts of the SAME physical socket.

TEENSY 4.1 SOCKETS

01 DIGITAL OUTPUTS / 3.3 V GPIO -> 3to5V SHIFTERS -> 5 V backplane

MEGA-PATTERN SOCKET / BACKPLANE

04 POWER / SAME SHARED RAILS

02 PHOTOSENSORS / backplane -> divider + filter -> Teensy ADC

03 MICROPHONES / direct analog input + 1 nF shunt

U1-U4: SN74LV4T125PWR | RDx: 100K pulldown | PWR_FLAG symbols retained from original; no physical parts.

f1-f3 = female 1-3; m1-m2 = male 1-2. Wire captions are plain text, not electrical connections.

05 SPARE GPIO / TEST POINTS

06 UNUSED SOCKET CONTACTS / X = NO CONNECTION

Reading copy: same circuit; original schematic and PCB retained

Colocoy of Mobiles

Sheet: /

File: teensy-adapter-wired.kicad_sch

Title: Teensy adapter / continuous wiring / reading copy

Size: A1	Date: 2026-10-21	Rev: B shifters
KiCad E.D.A. 9.0.7		Id: 1/1