



# DRM Integration Framework User Guide

Version 1.4

Broadcom 1320 Ridder Park Drive San Jose, California 95131 broadcom.com

This document contains information that is confidential and proprietary to Broadcom Limited and may not be reproduced in any form without express written consent of Broadcom Limited. No transfer or licensing of technology is implied by this document.

Broadcom Limited Proprietary and Confidential. © 2016 Broadcom Limited. All rights reserved.

## **Table of Contents**

1	Revision History	3
	,	
2	Introduction	3
_		_
3	Building playback_dif example	
3	3.1 Environment variable settings	3
3	3.2 Building DIF library and playback_dif example	4
4	Runtime environment setup	5
4	l.1 Preparing drm.bin, playready.bin and playready3x.bin	5
4	J.2 Mounting the build and setting up runtime environment	6
5	Running playback_dif example	7
5	i.1 Play CENC media	7
5	i.2 Play PIFF media	8
	s.3 Mosaic mode with CENC files	
5	4 Mosaic mode with PIFF files	10

# 1 Revision History

Issue	Date	Ву	Change
1.0	10/15/2015	Yuichi Aiba	Initial release
1.1	10/29/2015	Yuichi Aiba	Added a step to section 3.2 for correcting the system time on the board
1.2	12/4/2015	Yuichi Aiba	Added single process mode
1.3	2/8/2016	Yuichi Aiba	Updated command line options with Sage 2.8  Added mosaic mode with playback dif
1.4	7/13/2016	Yuichi Aiba	Added PlayreadyPK 3.0 support

## 2 Introduction

DRM Integration Framework (DIF) provides APIs that simplifies playback application development with DRM with SAGE/SVP support. Currently it supports Playready and Widevine.

We provide a sample application playback\_dif which is a simple example to utilize the DIF APIs.

This document outlines how to build and run playback\_dif example.

# 3 Building playback\_dif example

## 3.1 Environment variable settings

1) Define URSR\_TOP to point at the root folder of your URSR sources. This is optional and absolute path can be used to replace \$(URSR\_TOP). It is used in this document for convenience. For example:

```
export URSR_TOP=/projects/stbdev/$USER/repos/URSR_baseline
```

2) Set these platform specific environment variables:

```
export NEXUS_PLATFORM=<Platform_ID>
export BCHP_VER=<Revision>
```

Below is needed only if your board has a subtype like SV, VMS\_SFF, C, DBS....etc.)

```
export NEXUS_USE_<ChipID>_<BoardSubType>=y
```

3) The following variables need to be set:

```
export NEXUS_MODE=proxy
export LINUX=<Kernel_path>
export PATH=<Toolchain_path>:$PATH
export MSDRM_PRDY_SUPPORT=y
```

Below is required if the chip is ARM processor.

```
export B_REFSW_ARCH=arm-linux
```

DIF will be built with SAGE/SVP support using the below setting. If you want to build without SAGE/SVP support, please set it "n":

```
export SAGE SUPPORT=y
```

Currently multi-process mode is the default build. If you want to build single process mode, please set NXCLIENT SUPPORT to "n":

```
export NXCLIENT_SUPPORT=n
```

# 3.2 Building DIF library and playback\_dif example

You can build DIF library and playback\_dif example at the same time using the following commands:

```
cd $URSR_TOP/BSEAV/lib/security/dif
make examples
```

An executable file "playback\_dir" will be copied to \$(URSR\_TOP)/obj.\$(NEXUS\_PLATFORM)/nexus/bin together with libdif.so and other required libraries.

**Note**: Under some networks, you may get an error similar to the following (full path will be shown instead of \$(URSR\_TOP)):

```
====== Downloading OPENSSL tarball to
$(URSR_TOP)/obj.97439/BSEAV/lib/protobuf/arm-linux.debug
$(URSR_TOP)/BSEAV/lib/protobuf/protobuf-2.5.0
$(URSR TOP)/obj.97439/BSEAV/lib/protobuf/arm-linux.debug
--2015-08-20 11:21:59-- https://protobuf.googlecode.com/files/protobuf-
2.5.0.tar.bz2
Resolving protobuf.googlecode.com... 74.125.20.82, 2607:f8b0:400e:c05::52
Connecting to protobuf.googlecode.com|74.125.20.82|:443... connected.
ERROR: cannot verify protobuf.googlecode.com's certificate, issued by
`/C=US/O=Google Inc/CN=Google Internet Authority G2':
Unable to locally verify the issuer's authority.
To connect to protobuf.googlecode.com insecurely, use `--no-check-
certificate'.
Unable to establish SSL connection.
Tarball $(URSR TOP)/obj.97439/BSEAV/lib/protobuf/arm-linux.debug/protobuf-
2.5.0.tar.bz2 is missing
Makefile:98: recipe for target 'source' failed
make: *** [source] Error 1
```

As a workaround, you can use curl as follows and then proceed with the build command again.

```
curl https://protobuf.googlecode.com/files/protobuf-2.5.0.tar.bz2 >
$(URSR_ROP)/obj.97439/BSEAV/lib/protobuf/arm-linux.debug/protobuf-
2.5.0.tar.bz2
```

## 4 Runtime environment setup

# 4.1 Preparing drm.bin, playready.bin and playready3x.bin

Please prepare appropriate drm.bin and playready.bin for your board. If DIF was built with SAGE\_SUPPORT=y, prepare playready3x.bin as well. Then copy them to the directory where playback diff executable exists.

You need version 3.1.0 or higher of the DRM Utility to generate a proper "drm.bin" and "playready.bin" files. drm.bin needs to be generated with a "WIDEVINE\_PLAYBACK" key and playready.bin needs to include PRDY\_2.5 key while playready3x.bin needs PRDY\_3.0. You can generate a single bin file with all keys and copy it to drm.bin and playready.bin (and playready3x.bin).

Note that these binary files generated with older versions of the DRM utility will not work properly. Also these bin files for SAGE/SVP support cannot be used for a build without SAGE/SVP support.

Obtaining OTP ID for your board (optional)

If you need to obtain drm.bin for your board, please follow the instructions here, otherwise, jump to the next section. This section describes how to obtain OTP ID for your board which is needed for getting appropriate drm.bin. However, it is assumed that you have instructions on how to obtain the drm.bin.

OTP can be retrieved with 2 steps below

a. Build otpgetchipid – The commands below build Nexus along with the app otpgetchipid.

```
cd nexus/examples/security/otp/nexus
plat <Platform_ID> <Revision>
unset SAGE_SUPPORT
unset NEXUS_SECURITY_SUPPORT
```

b. Run otpgetchipid on your board.

Boot the board up to the shell prompt.

```
mount -t nfs NFS_SERVER_IP:/<path-to-built-nexus-and-otpgetchipid>
/mnt/nfs
./nexus otpgetchipid
```

Note the OTP id Displayed on the console.

drm.bin can then be requested as per the OTP ID and board type.

## 4.2 Mounting the build and setting up runtime environment

Copy the build (contents of \$(URSR\_TOP)/obj.\$(NEXUS\_PLATFORM)/nexus/bin) to your NFS server and mount it from your board using the following example. The example below assumes that it is mounted under /mnt/nfs on the device (Here '#' is a command prompt on the terminal of the board).

```
#mount -o nolock NFS_SERVER_IP:/<path-to-built-nexus-bin> /mnt/nfs
```

Make sure that the directory <path-to-built-nexus-bin> containing Nexus, required libs (such as libdif.so, libwvcdm.so, libplayreadypk\_host.so, libcmndrm\*.so, etc.) and playback\_dif is mounted using nfs from the device. Also the permissions of these files must be properly set for the runtime user's access. The <path-to-built-nexus-bin> directory must be writable to the runtime user.

Make sure that drm.bin and playready.bin are present with at least read permission for the runtime user in the current directory.

```
#cd /mnt/nfs
# ls -l drm.bin playready.bin playready3x.bin
```

```
-r--r-- 1 15176 841 24016 Jul 13 17:18 drm.bin
-r--r-- 1 15176 841 24016 Jul 13 17:19 playready.bin
-r--r-- 1 15176 841 24016 Jul 13 17:20 playready3x.bin
```

If not running playback\_dif from /mnt/nfs, set up your PATH to include the directory where playback\_dif exists.

```
# PATH=$PATH:/mnt/nfs
# which playback_dif
/mnt/nfs/playback_dif
```

Make sure the system time is correct. The below example shows a wrong system time.

```
# date
Thu Jan 1 00:04:34 UTC 1970
```

An easy way to set the correct time is to run ntpd command for example:

```
# ntpd -p us.pool.ntp.org
```

But the above command only runs the ntpd daemon and the system time is not updated immediately. Please wait for a few seconds and then confirm the system time gets synchronized.

For multi process mode, start Nexus server. This step is not required for single process mode.

```
#cd /mnt/nfs
#./nexus nxserver -memconfig videoDecoder,svp,all,s -memconfig
display,svp,all,s &
```

# 5 Running playback\_dif example

Make sure that Environment is setup according to <u>section 3</u>.

## 5.1 Play CENC media

- 1. From host machine, visit http://dash-mse-test.appspot.com/media.html from browser.
- 2. Scroll down to "OOPS\_CENC" secion and download a CENC media file such as oops\_cenc-20121114-142.mp4 and copy it to the directory in your NFS server where playback\_dif exists. Make sure the read permission is set for the runtime user.

The first 6 files (numbering from 142 to 146) include only video data and the following 3 files (numbering from 148 to 150) include only audio data. oops cenc-20121114-161.mp4 is video only.

These CENC media can't be played with Playready 3.0 because the license server doesn't support it.

3. Run playback dif with Playready 2.5 DRM

#### Multi-process mode:

```
# ./nexus.client playback_dif -secure -pr oops_cenc-20121114-145.mp4
Single process mode:
```

```
# ./nexus playback dif -secure -pr oops cenc-20121114-145.mp4
```

NOTE: If you built DIF with SAGE\_SUPPORT=n, please remove "-secure" option from the command line. The same condition is applied for all the examples in this document.

4. Run playback\_dif with Widevine DRM

### Multi-process mode:

```
# ./nexus.client playback_dif -secure -wv oops_cenc-20121114-145.mp4
Single process mode:
```

```
# ./nexus playback_dif -secure -wv oops_cenc-20121114-145.mp4
```

5. Run playback\_dif without DRM option. This will select a DRM that is found in the first PSSH box in the media file (below results in Widevine DRM).

#### Multi-processmode:

```
# ./nexus.client playback_dif -secure oops_cenc-20121114-145.mp4
Single processmode:
```

# ./nexus playback\_dif -secure oops\_cenc-20121114-145.mp4

# 5.2 Play PIFF media

- 1. From host machine, visit http://playready.directtaps.net/smoothstreaming.
- 2. Scroll down to "SSW 720p H264 PLAYREADY (SuperSpeedWay, 720p, H264 AAC, with encryption)" section and download an ISMV file such as SSWSS720H264PR/SuperSpeedway\_720\_2962.ismv and copy it to the directory in your NFS server where playback\_dif exists. Make sure the read permission is set for the runtime user.

Those files include both audio and video data and playback dif can play the video with audio.

3. Run playback\_dif with Playready 2.5 DRM

## Multi-process mode:

- # ./nexus.client playback\_dif -secure -pr SuperSpeedway\_720\_2962.ismv
- Single process mode:
- # ./nexus playback\_dif -secure -pr SuperSpeedway\_720\_2962.ismv
- 4. Following command will result in Playready DRM (same as above)

#### Multi-process mode:

- # ./nexus.client playback\_dif -secure SuperSpeedway\_720\_2962.ismv
- Single process mode:
- # ./nexus playback\_dif -secure SuperSpeedway\_720\_2962.ismv
- 5. Run playback\_dif with Playready 3.0 DRM

## Multi-process mode:

# ./nexus.client playback\_dif -secure -pr30
SuperSpeedway\_720\_2962.ismv

#### Single process mode:

- # ./nexus playback\_dif -secure -pr30 SuperSpeedway\_720\_2962.ismv
- 6. If you specify a DRM that is not supported in the media, playback\_dif will ask if you want to continue with the default DRM (=Playready). You can enter 'y' or 'n'.
  - # ./nexus.client playback\_dif -secure -wv SuperSpeedway\_720\_2962.ismv
  - \*\*\* 00:00:00.015 playback\_dif: PiffParser was initialized for SuperSpeedway\_720\_2962.ismv
  - ### 00:00:00.015 playback\_dif: DRM Type: 2 was not found in the stream.
  - ### 00:00:00.015 playback\_dif: Do you want to play it with its default DRM type: 3? [y/n]

## 5.3 Mosaic mode with CENC files

This feature is only supported in multi-process mode. Up to 8 videos can be played with playready 2.5 and widevine mixed.

- 1. From host machine, visit http://dash-mse-test.appspot.com/media.html from browser.
- 2. Scroll down to "OOPS\_CENC" section and download low resolution CENC media files such as oops\_cenc-20121114-142.mp4 and oops\_cenc-20121114-161.mp4, and copy them to the directory in your NFS server where playback\_dif exists. Make sure the read permission is set for the runtime user.
- 3. Run playback dif with several cenc files

Below example plays 4 videos, two of which are played with Widevine and the others played with Playready 2.5:

```
# ./nexus.client playback_dif -secure oops_cenc-20121114-142.mp4 -pr
oops_cenc-20121114-142.mp4 oops_cenc-20121114-161.mp4 -pr oops_cenc-
20121114-161.mp4
```

Below example plays 5 videos where Playready 2.5 and Widevine are placed alternately:

```
# ./nexus.client playback_dif -secure -pr oops_cenc-20121114-161.mp4
oops_cenc-20121114-142.mp4 -n 5
```

## 5.4 Mosaic mode with PIFF files

This feature is only supported in multi-process mode. Up to 8 videos can be played, but currently only one video can be played with Playready 3.0. Please combine multiple playready 2.5 and just one 3.0.

- 1. From host machine, visit http://playready.directtaps.net/smoothstreaming.
- 2. Scroll down to "SSW 720p H264 PLAYREADY (SuperSpeedWay, 720p, H264 AAC, with encryption)" section and download low resolution ISMV files such as SSWSS720H264PR/SuperSpeedway\_720\_230.ismv and SSWSS720H264PR/SuperSpeedway\_720\_331.ismv. Copy them to the directory in your NFS server where playback\_dif exists. Make sure the read permission is set for the runtime user.
- 3. Run playback\_dif with several PIFF files

Below example plays 2 videos, one of which is played with Playready 3.0 and the other played with Playready 2.5:

```
# ./nexus.client playback_dif -secure -pr30 SuperSpeedway_720_230.ismv
SuperSpeedway_720_331.ismv
```

Below example plays 4 videos. Only first one of is played with Playready 3.0 and the others played with Playready 2.5:

# ./nexus.client playback\_dif -secure -pr30 SuperSpeedway\_720\_230.ismv SuperSpeedway\_720\_331.ismv SuperSpeedway\_720\_230.ismv SuperSpeedway\_720\_331.ismv