



Steven Hartley
July 2015

CHANGES FOR 15.3


- NetApp Moved to new home in the Unified Reference Software Release (URSR)
 - New Home: BSEAV/connectivity
- Built by BSEAV/connectivity/Makefile
 - make -j <num CPU's> examples
- Target (build output) moved to obj.\$(NEXUS_PLATFORM)/BSEAV/bin
- Running NetApp (similar to 15.2):

```
mkdir -p /mnt/nfs
mount -t nfs ${TFTP_SERVER}:${PATH_ON_TFTP_SERVER}/obj.$(NEXUS_PLATFORM)/BSEAV/bin /mnt/nfs
cd /mnt/nfs/bin
export NETAPP_DEBUG=y
source netapp_target_prep.sh
./NetAppTester -i
```

CHANGES FOR 15.3

Split Up of Functionality

- Detach Platform functionality (~45%) from API/App (~55%)
- NetApp-Platform is hidden underneath NetApp-API (netapp folder)
- IMPORTANT: NO changes to NetApp API (netapp.h) or build process (netapp.inc) for customers
 - Use the NetApp API as before.



SPLIT UP NETAPP


NetApp-Platform

- Becomes the Hardware Abstraction Layer (HAL)
- Charter
 - Bundle Connectivity drivers with URSR
 - Builds all components in the connectivity packages
 - Drivers
 - dhd, wl, cfg80211, btusb, bthid
 - userspace apps
 - btdl, dhd, wl
 - libraries
 - wps, wpscli, HSL, bsa, bsaserver, nfa, etc...
 - Maintains NVRAM and platform configurations
 - GPIO configuration
 - HW detection & loading of the drivers
 - Thin Platform API for upper layer application SW
 - Used only by NetApp-API and not to be used by customers

• Migration of:

- netapp/wlan
- netapp/bluetooth
- netapp/nfa
- parts of netapp/src source (platform specific components)

Platform Loader Module



SPLIT UP NETAPP

NetApp-API

- Platform independent code
 - No more NEXUS dependencies
 - No more Platform/HW dependencies
 - Requires netapp-platform
- Functionality
 - Connection management
 - Database backend
 - IEEE1905
 - DHCP Server/client
 - Discovery
 - Ping, ntp, dnslookup
- App integration
- No API Changes
 - same nomenclature as before

