MILITARY SPECIFICATION

LOCK, COMBINATION, ASSEMBLY

1. SCOPE

1.1 Scope. This specification covers one type of combination lock, designated Lock, Combination, Assembly, which is used for multipurpose applications in the WADS program.

2. APPLICABLE DOCUMENTS

2.1 Government documents.

2.1.1 Standards. Unless otherwise specified, the following standards of the issue listed in that issue of the Department of Defense Index of Specifications and Standards (DoDISS), specified in the solicitation, form a part of this specification to the extent specified herein.

STANDARDS

MILITARY

MIL-STD-105 - Sampling Procedures and Tables for Inspection by Attributes.

2.1.2 Other Government documents, drawings, and publications. The following other Government documents, drawings, and publications form a part of this specification to the extent specified herein.

Beneficial comments (recommendations, additions, deletions) and any pertinent data which may be of use in improving this document should be addressed to: Commander, U.S. Army Armament, Munitions and Chemical Command, Attn: AMSMC-QA, Picatinny Arsenal, New Jersey 07806-5000 by using the self-addressed Standardization Document Improvement Proposal (DD Form 1426) appearing at the end of this document or by letter.

AMSC N/A
FSC 5340
DISTRIBUTION STATEMENT A. Approved for public release; distribution is unlimited.

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

PRODUCT DRAWINGS

U.S. ARMY ARMAMENT RESEARCH, DEVELOPMENT AND ENGINEERING CENTER

9349430 - Cover.
9349431 - Wheel, Code.
9349432 - Guide, Bolt.
9349433 - Bolt.
9349434 - Base.
9349435 - Lock, Combination, Assembly
9378103 - Shield, Lock.

PACKAGING DATA SHEETS

U.S. ARMY ARMAMENT RESEARCH, DEVELOPMENT AND ENGINEERING CENTER

P9349435 Lock, Combination, Assembly
P9354312 Kit, Lock Installation

Copies of specifications, standards, drawings, and publications required by manufacturers in connection with specific acquisition functions, should be obtained from the contracting activity or as directed by the contracting officer.

2.2 Other publications. The following document forms a part of this specification to the extent specified herein. The issue of the document, which is indicated as DoD adopted, shall be the issue listed in the current DoDISS and supplements thereto, if applicable.

AMERICAN SOCIETY FOR TESTING AND MATERIALS (ASTM)

ASTM D 3951 - Standard Practice for Commercial Packaging.

Application for copies of ASTM publications should be addressed to the American Society for Testing and Materials, 1916 Race Street, Philadelphia, PA 19103.

2.3 Order of precedence. In the event of a conflict between the text of this specification and the references cited herein, the text of this specification shall take precedence.

3. REQUIREMENTS

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

3.1 Materials and components. Materials shall conform to applicable specifications and drawings. Each component shall conform to all dimensions and tests specified on the component drawing. The contractor shall have available verifiable proof (i.e., objective evidence (see 6.2.1)) that materials and components were fabricated, inspected, and tested under controllable conditions as set forth in the contractor's quality control or inspection procedures.

3.2 Assembly. The combination lock assembly shall comply with all requirements specified on drawing (dwg.) 9349435, with all requirements specified herein, and with the requirements of applicable specifications to the extent specified on the drawings and herein.

3.3 Combination selection. All procurement actions for this combination lock assembly should be based on achieving a broad mix and the least number of duplications of three-letter combination codes within the total lot being procured. For example, in a lot of 3000 combination locks, there should be no more than three locks in the lot with the same code. If fewer than 1300 locks are procured in any one lot, the combination lock part numbers (dash numbers) shall be selected from the total range of 1331 available numbers. This should be accomplished by selecting every other dash number, or every third dash number, or every fourth dash number, etc., as appropriate, to obtain the broadest mix of codes within the lot size being procured. The listing of combination lock dash numbers, and associated three-letter combination codes, is specified in the Appendix. The following 12 combination codes shall never be used, regardless of lot size (they are included in the Appendix to maintain continuity of the combination lock dash numbers): ABC, AAA, BBB, CCC, DDD, EEE, FFF, GGG, HHH, III, JJJ, and KKK.

3.4 First article. When specified, sample locks shall be subjected to first article inspection (see 4.3 and 6.1.1).

3.5 Functioning and operational torque. The lock shall be functioned five times by unlocking, extending the bolt, retracting the bolt, and locking. Each of the three code wheels shall then be rotated, three full turns in both directions, and the maximum torque required to turn each code wheel for one full turn, in both the CW and CCW directions, shall be between 2 - 10 inch-pounds. During this test, the lock shall not fail to function, and each code wheel shall be capable of being rotated smoothly in each direction of rotation without seizing or binding. Testing shall be as specified in 4.5.1.

3.6 High temperature. The lock shall withstand a high temperature of 130° + 5°F, for a minimum period of 4 hours, without evidence of deterioration or damage that may impair its intended operation. While at the high temperature (at the end of the high-temperature exposure period), the lock shall comply with the functioning and operational torque requirements of 3.5. Testing shall be as specified in 4.5.2.

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

3.7 Low temperature. The lock shall withstand a low temperature of -25° ± 5°F for a minimum period of 4 hours, without evidence of deterioration or damage that may impair its intended operation. While at the low temperature (at the end of the low-temperature exposure period), the lock shall comply with the functioning and operational torque requirements of 3.5. Testing shall be as specified in 4.5.3.

3.8 Humidity. The lock shall withstand a relative humidity of 95 ± 5 percent and a temperature of 130° ± 5°F without evidence of corrosion and without evidence of deterioration or damage that may impair its intended operation. After this test (at room temperature), the lock shall comply with the functional and operational torque requirments of 3.5. The lock shall be disassembled, and each part shall be visually inspected. There shall be no evidence of corrosion and no evidence of deterioration or damage that may impair its intended operation. The lock shall then be reassembled, and it shall comply with the functional and operational torque requirements of 3.5. Testing shall be as specified in 4.5.4.

3.9 Serialization. Not applicable.

3.10 Workmanship. All parts and accessories shall be constructed, assembled, and finished in a thoroughly workmanlike manner. Particular attention shall be given to neatness, marking, cleaning, and freedom of the parts from burrs and sharp edges which may affect performance or result in injury during handling. All parts shall be free of chips, dirt, grease, rust, and other foreign material. The cleaning method shall not be injurious to any of the parts, nor shall the parts be contaminated by the cleaning agents.

4. QUALITY ASSURANCE PROVISIONS

4.1 Responsiblity for inspection. Unless otherwise specified in the contract or purchase order, the supplier is responsible for the performance of all inspection requirements as specified herein. Except as otherwise specified in the contract or order, the supplier may use his own or any other facilities suitable for the performance of the inspection requirements specified herein, unless disapproved by the Government. The Government reserves the right to perform any of the inspections set forth in the specification where such inspections are deemed necessary to ensure supplies and services conform to prescribed requirements.

4.2 Classification of inspection. The inspection requirements specified herein are classified as follows:

a. First article inspection (see 4.3)

b. Quality conformance inspection (see 4.4)

Source: https://assist.dla.mil -- Downloaded: 202640-26T04:27Z
Check the source to verify that this is the current version before use.

4.3 First article inspection.

4.3.1 Submission. When the contract requires first article inspection, the contractor shall submit three consecutively produced locks to the testing facility designated in the invitation for bids or request for proposal.

4.3.2 Inspection and testing to be performed. The first article inspection samples shall be inspected for the defects specified in 4.4.2.1, using inspection methods contained therein, and for all the requirements of Section 3. The test requirements of Section 3 are listed in Table I, and the locks shall be tested using the test methods specified in 4.5. Inspection and testing shall be performed with the acceptance inspection equipment specified in 4.4.4. The locks shall be tested in the order specified in Table I. If any lock fails to comply with any of the applicable requirements, the first article samples shall be rejected. The Government reserves the right to terminate its inspections upon any failure of the first article samples to comply with the stated requirements. This series of tests is not considered destructive, and samples so tested may be returned to the lot.

TABLE I. First article tests.

	Test	Requirement paragraph
a.	Functioning and operational torque	3.5
b.	High temperature	3.6
c.	Low temperature	3.7
d.	Humidity	3.8

4.4 Quality conformance inspection.

4.4.1 Inspection lot. A lot or batch and its formation, size, and presentation is described in MIL-STD-105, Section 5. Accordingly, a lot shall mean an inspection lot, and a batch shall mean an inspection batch for the purposes of this specification. The manner in which each inspection lot or batch is to be presented and identified by the contractor shall be designated or approved by the Government representative.

4.4.2 Product inspection examination. A sample shall be selected at random from each inspection lot in accordance with the major defect or other minor defect table as applicable (see Table II). Any defect found in the sample, selected for the major or minor classification, shall reject the lot. Inspection of major defect 102, of the code wheel (see 4.4.2.1.1), shall be conducted on a 100 percent basis. If any code wheel fails to

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

requirements of major defect 102, the code wheel shall be removed from the lot. The sequence of inspections for the classification of defects need not be followed so long as all the defect inspections are performed. If any component is produced by tool manufacture control (see 6.4), inspection sampling may be as specified in 6.4.

TABLE II. Inspection lot sampling.

Major defect table		Minor defect table	
Lot size	Sample size	Lot size	Sample size
1-10	all	1-10	all
11-20	10	11-20	8
21-35	19	21-35	13
36-50	26	36-50	16
51-70	30	51-70	17
71-90	33	71-90	18
91-120	35	91-120	19
121-150	37	121-150	20
151-200	39	151-200	21
201 and over	41	201 and over	22

4.4.2.1 Classification of defects. Critical, major, and minor defects are defined in MIL-STD-105.

4.4.2.1.1 Bolt (see dwg. 9349433).

Categories	Defects	Method of inspection
Critical:	None defined	
Major:		
101.	Length, Min	Gage
102.	Thickness, min.	Gage
103.	Width of tooth at left side of bolt, min. (2 teeth).	Gage
104.	Width of tooth at right side of bolt, min	Gage
105.	Height of tooth near left end of bolt, min	Gage
106.	Height of tooth near right end of bolt, min. (2 teeth)	Gage
107.	Location of larger hole	Gage
108.	Diameter of larger hole, min.	Gage
109.	Chamfer of tooth incorrect (4 places, 3 teeth).	Gage

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Minor:

201.	Chamfer missing or improper (on bottom of bolt and on right end)	Visual
202.	Protective finish inadequate or improper	Visual
203.	Evidence of poor workmanship (see 3.10)	Visual

4.4.2.1.2 Wheel, Code (see dwg. 9349431).

Categories	Defects	Method of inspection
Critical:	None defined.	
Major:		
101.	Depth of blind slot, min (see table) (11 blind slots)	Gage
102.	Code letter sequence, letter position, and through slot position incorrect (as applicable to each of the 12 part number configurations) 1/	Visual/Gage

1/ Inspection of defect 102 is to be conducted on a 100 percent basis.

Minor:		
201.	Knurl incomplete or improper (around circumference of wheel)	Visual
202.	Protective finish inadequate or improper	Visual
203.	Marking missing, improper, or illegible	Visual
204.	Evidence of poor workmanship (see 3.10)	Visual

4.4.2.1.3 Cover (see dwg. 9349430).

Categories	Defects	Method of inspection
Critical:	None defined.	
Major:	None defined.	
Minor:		
201.	Large chamfer on left side missing, incomplete, or improper	Visual
202.	Protective finish inadequate or improper	Visual
203.	Evidence of poor workmanship (see 3.10)	Visual

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

4.4.2.1.4 Base (see dwg. 9349434).

Categories	Defects	Method of Inspection
Critical:	None defined.	
Major:		
	101. Location of threaded hole (4 holes)	Gage
	102. Pitch diameter of threaded hole (4 holes)	Gage
	103. Minor diameter of threaded hole, max. (4 holes)	Gage
	104. Location of hole at 6 o'clock position	Gage
Minor:		
	201. Protective finish inadequate or improper	Visual
	202. Evidence of poor workmanship (see 3.10)	Visual

4.4.2.1.5 Guide, Bolt (see dwg. 9349432).

Categories	Defects	Method of Inspection
Critical:	None defined.	
Major:	None defined.	
Minor:		
	201. Chamfer, on end of guide, missing or improper	Visual
	202. Protective finish inadequate or improper	Visual
	203. Evidence of poor workmanship (see 3.10)	Visual

4.4.2.1.6 Shield, Lock (see dwg. 9378103).

Categories	Defects	Method of Inspection
Critical:	None defined.	
Major:		
	101. Welded plate missing, improper, or improperly attached (2 plates)	Visual
	102. Configuration of shield improper (including radii of sides)	Visual
Minor:		
	201. Protective finish inadequate or improper	Visual
	202. Evidence of poor workmanship (see 3.10)	Visual

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

4.4.2.1.7 Lock, Combination, Assembly (see dwg. 9349435).

Categories	Defects	Method of Inspection
Critical:	None defined.	
Major:		
101.	Spring pin in base missing, improper, or improperly assembled	Visual
102.	Dowel pin in cover missing, improper or improperly installed (2 pins)	Visual
103.	Dowel pin in base missing, improper, or improperly installed (2 pins)	Visual
104.	Dowel pin setscrew missing, improper, or improperly assembled (2 setscrews in cover; 2 setscrews in base)	Visual
105.	Lock shield missing, improper, or improperly assembled (including torsion spring, spring pin, and bumper)	Visual
106.	Combination code marking on base missing, improper, or illegible	Visual
107.	Spring pin in collar missing, improper or improperly assembled	Visual
Minor:		
201.	Protective finish inadequate, improper, or damaged (exposing base metal) (refer to applicable part drawing)	Visual
202.	Marking missing, improper, or illegible (refer to applicable part drawing)	Visual
203.	Evidence of poor workmanship (see 3.10)	Visual

4.4.3 Quality conformance inspection testing. The quality conformance test for the lock shall consist of the functioning and operational torque test (see 3.5). Each lock shall be subjected to this test, and if any lock fails to comply with the applicable requirements, it shall be classified defective and be removed from the lot. This is a major category test.

4.4.4 Acceptance inspection equipment (AIE).

4.4.4.1 Major defect and tests. Inspection and testing shall be performed with the acceptance inspection equipment, operating instructions, and calibration procedures designed or specified by the contractor (see 6.1.2). The contractor shall obtain approval of such equipment designs, operating instructions, and calibration procedures prior to use on the contract (see 6.3).

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

4.4.4.2 Minor defects. Not applicable.

4.5 Methods of inspection. The tolerances specified in this specification are absolute with no allowance for test equipment inaccuracy. The tolerances used by the manufacturer shall be equal to the absolute tolerances less the accuracy tolerances of the test equipment used. Unless otherwise specified, the tests shall be conducted at room temperature (77° + 10°F). NOTE: (1) During environmental testing, the lock shall be securely mounted, in a horizontal position, to a test fixture/stand which will provide adequate support to the lock while in environmental test chambers. (2) During the high- and low-temperature tests (see 4.5.2 and 4.5.3), the lock may be removed from the temperature chamber for testing at the end of the high- and low-temperature exposure period; however, the exposure to room temperature shall not exceed 7 minutes. The lock shall be replaced in the temperature chamber, within 7 minutes after removal, for a minimum period of 30 minutes before each subsequent 7-minute measuring period.

4.5.1 Functioning and operational torque. The lock shall be unlocked by aligning the combination (marked on the lock base) between the two index marks. The bolt shall be extended to its maximum extension and retracted into the lock. Each code wheel shall be turned at least one full turn, to the diamond symbol, to lock the device. This operation constitutes one cycle, and the lock shall be subjected to five such cycles. After this test, the torque required to turn each code wheel shall be obtained. This is accomplished by the following procedure (which is listed in a suggested sequence of testing):

(a) Clamp the lock shield in a suitable test fixture so that the shield is opened (rotated 90°) and the lock is in the vertical position (lock bolt uppermost).
(b) Condition the lock by turning each code wheel at least three revolutions, in both the CW and the CCW directions.
(c) Attach an appropriate torque measuring device to a code wheel.
(d) Measure the maximum torque while turning the code wheel in a smooth, even manner for one complete revolution in the CW direction.
(e) Repeat step (d) twice (for a total of three torque measurements).
(f) Repeat the torque-measuring procedure, in steps (d) and (e), for the CCW direction.
(g) The average value of the three maximum torque readings, obtained for each direction of rotation, shall be considered the maximum torque.
(h) Repeat this torque-measuring procedure (steps (c) to (g)) for the other two code wheels.

The lock shall comply with the requirements of 3.5 during this test.

Source: https://assist.dla.mil -- Downloaded: 202640-26T04:27Z
Check the source to verify that this is the current version before use.

4.5.2 High temperature. The lock shall be placed into a test chamber, and the temperature of the chamber shall be raised to 130°F. The lock shall remain at this temperature for a minimum period of 4 hours, and it shall then be tested as specified in 4.5.1 while at the high temperature (see 4.5, Note 2). The lock shall comply with the requirements of 3.6 during this test.

4.5.3 Low temperature. The lock shall be placed into a test chamber, and the temperature of the chamber shall be lowered to -25°F. The locks shall remain at this temperature for a minimum period of 4 hours, and it shall then be tested as specified in 4.5.1 while at the low temperature (see 4.5, Note 2). The lock shall comply with the requirements of 3.7 during this test.

4.5.4 Humidity. The lock shall be placed into a dry oven and conditioned at a temperature of 130°F for a minimum period of 24 hours. At the end of this conditioning period, the lock shall be subjected to the following humidity cycle:

(a) Condition the lock at 75° ± 5°F and 50 ± 5 percent relative humidity for 24 hours.
(b) Gradually raise the internal chamber temperature to 105° ± 5°F and 90 percent relative humidity in 2 hours.
(c) Maintain the internal chamber temperature at 105°F and 90 percent relative humidity for 16 hours.
(d) Gradually decrease the internal chamber temperature to 70° ± 5°F and increase the relative humidity to a minimum of 95 percent in 2 hours.
(e) Maintain the internal chamber temperature at 70°F and at 95 percent relative humidity for 4 hours.
(f) Repeat steps (b), (c), (d), and (e) for a total of 20 cycles (480 hours).

After completion of the 20 humidity cycles, the lock shall be removed from the test chamber and allowed to stabilize at room temperature for a minimum period of 4 hours. After this 4-hour period, the lock shall be tested as specified in 4.5.1. The lock shall then be disassembled, visually inspected as specified in 3.8, and reassembled. The lock shall then be tested as specified in 4.5.1. The lock shall comply with requirements of 3.8 during this test.

5. PACKAGING

5.1 Combination lock assemblies for interplant shipment (see 6.2.2).

5.1.1 Preservation, packaging, packing, and marking. The combination lock assembly shall be preserved, packaged, packed, and marked in accordance with ASTM-D-3951 or as specified in the contract or purchase order.

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

5.2 Combination lock assemblies for initial issue or for spare (repair) parts.

5.2.1 Preservation, packaging, packing, and marking. The combination lock assembly shall be preserved, packaged, packed, and marked in accordance with Packaging Data Sheet P9349435 or as specified in the contract or purchase order.

6. NOTES

6.1 Ordering data.

6.1.1 Acquisition requirements. Acquisition documents should specify (a) the title, number, and date of this specification; (b) applicable methods of packaging and packing; and (c) first article sample requirements.

6.1.2 Contract data requirements. Contractor engineering documentation shall be developed as specified by an approved Data Item Description (DID) (DD Form 1664) when specified on a Contract Data Requirements List (DD Form 1423) incorporated into the contract or purchase order. Deliverable data required by this specification is cited in the following paragraph:

Paragraph No.	Data requirement	Applicable DID No.
4.4.4.1	Quality Engineering Acceptance Inspection Equipment Descriptive Documentation.	DID-R-1714

Copies of data item descriptions, required by the contractor in connection with specific acquisition functions, should be obtained from the procuring activity or as directed by the contracting officer.

6.2 Definitions.

6.2.1 Objective evidence. Records of the contractor's quality control and inspections which can be verified.

6.2.2 Interplant shipments. Shipments of an item from a manufacturer, or from a supply source, to a receiving activity for use of the item (a) in the next higher assembly (during end item production) or (b) for packaging of the item for initial issue or for use as spare (repair) parts.

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

6.3 Acceptance inspection equipment. The contractor shall obtain approval of equipment designs, operating instructions, and calibration procedures from Commander, U.S. Army Armament Research, Development and Engineering Center, ATTN: AMSMC-QAN-I(D), Picatinny Arsenal, New Jersey 07806-5000.

6.4 Tool manufacture control. When a component, or part of a component, is produced by tool manufacture control, the manufacturing tool setup (e.g., stamping die, automatic tape control machine, etc.) may be used to accept the parts being manufactured if approved by the Government representative responsible for acceptance inspection. Two consecutive parts, which comply with all drawing dimensions, shall constitute proper initial tool control acceptance. During production, one part shall be inspected for its classification of defects at the start and at the end of each of each day's production. In addition, two consecutive parts shall be examined for all drawing dimensions whenever the manufacturing tool requires maintenance.

Custodian:
Army AR

Preparing Activity
Army AR

Project No. 5340-A043

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

APPENDIX

LOCK, COMBINATION ASSY, CODES

10 SCOPE

10.1 Scope. This Appendix covers a total of 1331 combination lock assembly part numbers which identify all of the three-letter codes (combinations) that can be formed for this lock. Each of the 1331 combinations is listed, along with the associated part number of each of the three individuals code wheels. The dash numbers (example "-0001") are for reference only and are not to be stamped on the locks.

20 APPLICABLE DOCUMENTS

This section is not applicable to this appendix

30 REQUIREMENTS

30.1 Intended use. This appendix is intended for use by each of the following:

(a) The lock manufacturer (contractor) in the selection of series of combination lock part numbers (dash numbers) as specified in 30.2.

(b) The Government representative, responsible for acceptance inspection, to verify that the selection of the series of combination lock part numbers, within each procured lot, is in accordance with 30.2.

30.2 Combination selection. All procurement actions for this combination lock assembly should be based on achieving a broad mix and the least number of duplications of three-letter combination codes within the total lot being procured. For example, in a lot of 3000 combination locks, there should be no more than three locks in the lot with the same code. If fewer than 1300 locks are procured in any one lot, the combination lock part numbers (dash numbers) shall be selected from the total range of 1331 available numbers. This should be accomplished by selecting every other dash number, or every third dash number, or every fourth dash number, etc., as appropriate, to obtain the broadest mix of codes within the lot size being procured. The following 12 combination codes shall never be used, regardless of lot size (they are included in this supplement to maintain continuity of the combination lock dash numbers): ABC, AAA, BBB, CCC, DDD, EEE, FFF, GGG, HHH, III, JJJ, and KKK.

Source: https://assist.dla.mil -- Downloaded: 202610-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0001	9349431-001	9349431-001	9349431-001	AAA*
-0002	-001	-001	-002	AAB
-0003	-001	-001	-003	AAC
-0004	-001	-001	-004	AAD
-0005	-001	-001	-005	AAE
-0006	-001	-001	-006	AAF
-0007	-001	-001	-007	AAG
-0008	-001	-001	-008	AAH
-0009	-001	-001	-009	AAI
-0010	-001	-001	-010	AAJ
-0011	-001	-001	-011	AAK
-0012	-001	-002	-001	ABA
-0013	-001	-002	-002	ABB
-0014	-001	-002	-003	ABC*
-0015	-001	-002	-004	ABD
-0016	-001	-002	-005	ABE
-0017	-001	-002	-006	ABF
-0018	-001	-002	-007	ABG
-0019	-001	-002	-008	ABH
-0020	-001	-002	-009	ABI
-0021	-001	-002	-010	ABJ
-0022	-001	-002	-011	ABK
-0023	-001	-003	-001	ACA
-0024	-001	-003	-002	ACB
-0025	-001	-003	-003	ACC
-0026	-001	-003	-004	ACD
-0027	-001	-003	-005	ACE
-0028	-001	-003	-006	ACF
-0029	-001	-003	-007	ACG
-0030	-001	-003	-008	ACH
-0031	-001	-003	-009	ACI
-0032	-001	-003	-010	ACJ
-0033	-001	-003	-011	ACK
-0034	-001	-004	-001	ADA
-0035	-001	-004	-002	ADB
-0036	-001	-004	-003	ADC
-0037	-001	-004	-004	ADD
-0038	-001	-004	-005	ADE
-0039	-001	-004	-006	ADF
-0040	-001	-004	-007	ADG
-0041	-001	-004	-008	ADH
-0042	-001	-004	-009	ADI
-0043	-001	-004	-010	ADJ
-0044	-001	-004	-011	ADK
-0045	-001	-005	-001	AEA
-0046	-001	-005	-002	AEB
-0047	-001	-005	-003	AEC
-0048	-001	-005	-004	AED
-0049	-001	-005	-005	AEE
-0050	-001	-005	-006	AEF

* Do not use (see 30.2).

Source: https://assist.dla.mil -- Downloaded: 2026l0-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0051	9349431-001	9349431-005	9349431-007	AEG
-0052	-001	-005	-008	AEH
-0053	-001	-005	-009	AEI
-0054	-001	-005	-010	AEJ
-0055	-001	-005	-011	AEK
-0056	-001	-006	-001	AFA
-0057	-001	-006	-002	AFB
-0058	-001	-006	-003	AFC
-0059	-001	-006	-004	AFD
-0060	-001	-006	-005	AFE
-0061	-001	-006	-006	AFF
-0062	-001	-006	-007	AFG
-0063	-001	-006	-008	AFH
-0064	-001	-006	-009	AFI
-0065	-001	-006	-010	AFJ
-0066	-001	-006	-011	AFK
-0067	-001	-007	-001	AGA
-0068	-001	-007	-002	AGB
-0069	-001	-007	-003	AGC
-0070	-001	-007	-004	AGD
-0071	-001	-007	-005	AGE
-0072	-001	-007	-006	AGF
-0073	-001	-007	-007	AGG
-0074	-001	-007	-008	AGH
-0075	-001	-007	-009	AGI
-0076	-001	-007	-010	AGJ
-0077	-001	-007	-011	AGK
-0078	-001	-008	-001	AHA
-0079	-001	-008	-002	AHB
-0080	-001	-008	-003	AHC
-0081	-001	-008	-004	AHD
-0082	-001	-008	-005	AHE
-0083	-001	-008	-006	AHF
-0084	-001	-008	-007	AHG
-0085	-001	-008	-008	AHH
-0086	-001	-008	-009	AHI
-0087	-001	-008	-010	AHJ
-0088	-001	-008	-011	AHK
-0089	-001	-009	-001	AIA
-0090	-001	-009	-002	AIB
-0091	-001	-009	-003	AIC
-0092	-001	-009	-004	AID
-0093	-001	-009	-005	AIE
-0094	-001	-009	-006	AIF
-0095	-001	-009	-007	AIG
-0096	-001	-009	-008	AIH
-0097	-001	-009	-009	AII
-0098	-001	-009	-010	AIJ
-0099	-001	-009	-011	AIK
-0100	-001	-010	-001	AJA

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0101	9349431-001	9349431-010	9349431-002	AJB
-0102	-001	-010	-003	AJC
-0103	-001	-010	-004	AJD
-0104	-001	-010	-005	AJE
-0105	-001	-010	-006	AJF
-0106	-001	-010	-007	AJG
-0107	-001	-010	-008	AJH
-0108	-001	-010	-009	AJI
-0109	-001	-010	-010	AJJ
-0110	-001	-010	-011	AJK
-0111	-001	-011	-001	AKA
-0112	-001	-011	-002	AKB
-0113	-001	-011	-003	AKC
-0114	-001	-011	-004	AKD
-0115	-001	-011	-005	AKE
-0116	-001	-011	-006	AKF
-0117	-001	-011	-007	AKG
-0118	-001	-011	-008	AKH
-0119	-001	-011	-009	AKI
-0120	-001	-011	-010	AKJ
-0121	-001	-011	-011	AKK
-0122	-002	-001	-001	BAA
-0123	-002	-001	-002	BAB
-0124	-002	-001	-003	BAC
-0125	-002	-001	-004	BAD
-0126	-002	-001	-005	BAE
-0127	-002	-001	-006	BAF
-0128	-002	-001	-007	BAG
-0129	-002	-001	-008	BAH
-0130	-002	-001	-009	BAI
-0131	-002	-001	-010	BAJ
-0132	-002	-001	-011	BAK
-0133	-002	-002	-001	BBA
-0134	-002	-002	-002	BBB*
-0135	-002	-002	-003	BBC
-0136	-002	-002	-004	BBD
-0137	-002	-002	-005	BBE
-0138	-002	-002	-006	BBF
-0139	-002	-002	-007	BBG
-0140	-002	-002	-008	BBH
-0141	-002	-002	-009	BBI
-0142	-002	-002	-010	BBJ
-0143	-002	-002	-011	BBK
-0144	-002	-003	-001	BCA
-0145	-002	-003	-002	BCB
-0146	-002	-003	-003	BCC
-0147	-002	-003	-004	BCD
-0148	-002	-003	-005	BCE
-0149	-002	-003	-006	BCF
-0150	-002	-003	-007	BCG

* Do not use (see 30.2).

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0151	9349431-002	9349431-003	9349431-008	BCH
-0152	-002	-003	-009	BCI
-0153	-002	-003	-010	BCJ
-0154	-002	-003	-011	BCK
-0155	-002	-004	-001	BDA
-0156	-002	-004	-002	BDB
-0157	-002	-004	-003	BDC
-0158	-002	-004	-004	BDD
-0159	-002	-004	-005	BDE
-0160	-002	-004	-006	BDF
-0161	-002	-004	-007	BDG
-0162	-002	-004	-008	BDH
-0163	-002	-004	-009	BDI
-0164	-002	-004	-010	BDJ
-0165	-002	-004	-011	BDK
-0166	-002	-005	-001	BEA
-0167	-002	-005	-002	BEB
-0168	-002	-005	-003	BEC
-0169	-002	-005	-004	BED
-0170	-002	-005	-005	BEE
-0171	-002	-005	-006	BEF
-0172	-002	-005	-007	BEG
-0173	-002	-005	-008	BEH
-0174	-002	-005	-009	BEI
-0175	-002	-005	-010	BEJ
-0176	-002	-005	-011	BEK
-0177	-002	-006	-001	BFA
-0178	-002	-006	-002	BFB
-0179	-002	-006	-003	BFC
-0180	-002	-006	-004	BFD
-0181	-002	-006	-005	BFE
-0182	-002	-006	-006	BFF
-0183	-002	-006	-007	BFG
-0184	-002	-006	-008	BFH
-0185	-002	-006	-009	BFI
-0186	-002	-006	-010	BFJ
-0187	-002	-006	-011	BFK
-0188	-002	-007	-001	BGA
-0189	-002	-007	-002	BGB
-0190	-002	-007	-003	BGC
-0191	-002	-007	-004	BGD
-0192	-002	-007	-005	BGE
-0193	-002	-007	-006	BGF
-0194	-002	-007	-007	BGG
-0195	-002	-007	-008	BGH
-0196	-002	-007	-009	BGI
-0197	-002	-007	-010	BGJ
-0198	-002	-007	-011	BGK
-0199	-002	-008	-001	BHA
-0200	-002	-008	-002	BHB

Source: https://assist.dla.mil -- Downloaded: 202610-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0201	9349431-002	9349431-008	9349431-003	BHC
-0202	-002	-008	-004	BHD
-0203	-002	-008	-005	BHE
-0204	-002	-008	-006	BHF
-0205	-002	-008	-007	BHG
-0206	-002	-008	-008	BHH
-0207	-002	-008	-009	BHI
-0208	-002	-008	-010	BHJ
-0209	-002	-008	-011	BHK
-0210	-002	-009	-001	BIA
-0211	-002	-009	-002	BIB
-0212	-002	-009	-003	BIC
-0213	-002	-009	-004	BID
-0214	-002	-009	-005	BIE
-0215	-002	-009	-006	BIF
-0216	-002	-009	-007	BIG
-0217	-002	-009	-008	BIH
-0218	-002	-009	-009	BII
-0219	-002	-009	-010	BIJ
-0220	-002	-009	-011	BIK
-0221	-002	-010	-001	BJA
-0222	-002	-010	-002	BJB
-0223	-002	-010	-003	BJC
-0224	-002	-010	-004	BJD
-0225	-002	-010	-005	BJE
-0226	-002	-010	-006	BJF
-0227	-002	-010	-007	BJG
-0228	-002	-010	-008	BJH
-0229	-002	-010	-009	BJI
-0230	-002	-010	-010	BJJ
-0231	-002	-010	-011	BJK
-0232	-002	-011	-001	BKA
-0233	-002	-011	-002	BKB
-0234	-002	-011	-003	BKC
-0235	-002	-011	-004	BKD
-0236	-002	-011	-005	BKE
-0237	-002	-011	-006	BKF
-0238	-002	-011	-007	BKG
-0239	-002	-011	-008	BKH
-0240	-002	-011	-009	BKI
-0241	-002	-011	-010	BKJ
-0242	-002	-011	-011	BKK
-0243	-003	-001	-001	CAA
-0244	-003	-001	-002	CAB
-0245	-003	-001	-003	CAC
-0246	-003	-001	-004	CAD
-0247	-003	-001	-005	CAE
-0248	-003	-001	-006	CAF
-0249	-003	-001	-007	CAG
-0250	-003	-001	-008	CAH

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0251	9349431-003	9349431-001	9349431-009	CAI
-0252	-003	-001	-010	CAJ
-0253	-003	-001	-011	CAK
-0254	-003	-002	-001	CBA
-0255	-003	-002	-002	CBB
-0256	-003	-002	-003	CBC
-0257	-003	-002	-004	CBD
-0258	-003	-002	-005	CBE
-0259	-003	-002	-006	CBF
-0260	-003	-002	-007	CBG
-0261	-003	-002	-008	CBH
-0262	-003	-002	-009	CBI
-0263	-003	-002	-010	CBJ
-0264	-003	-002	-011	CBK
-0265	-003	-003	-001	CCA
-0266	-003	-003	-002	CCB
-0267	-003	-003	-003	CCC*
-0268	-003	-003	-004	CCD
-0269	-003	-003	-005	CCE
-0270	-003	-003	-006	CCF
-0271	-003	-003	-007	CCG
-0272	-003	-003	-008	CCH
-0273	-003	-003	-009	CCI
-0274	-003	-003	-010	CCJ
-0275	-003	-003	-011	CCK
-0276	-003	-004	-001	CDA
-0277	-003	-004	-002	CDB
-0278	-003	-004	-003	CDC
-0279	-003	-004	-004	CDD
-0280	-003	-004	-005	CDE
-0281	-003	-004	-006	CDF
-0282	-003	-004	-007	CDG
-0283	-003	-004	-008	CDH
-0284	-003	-004	-009	CDI
-0285	-003	-004	-010	CDJ
-0286	-003	-004	-011	CDK
-0287	-003	-005	-001	CEA
-0288	-003	-005	-002	CEB
-0289	-003	-005	-003	CEC
-0290	-003	-005	-004	CED
-0291	-003	-005	-005	CEE
-0292	-003	-005	-006	CEF
-0293	-003	-005	-007	CEG
-0294	-003	-005	-008	CEH
-0295	-003	-005	-009	CEI
-0296	-003	-005	-010	CEJ
-0297	-003	-005	-011	CEK
-0298	-003	-006	-001	CFA
-0299	-003	-006	-002	CFB
-0300	-003	-006	-003	CFC

* Do not use (see 30.2).

Source: https://assist.dla.mil -- Downloaded: 202610-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0301	9349431-003	9349431-006	9349431-004	CFD
-0302	-003	-006	-005	CFE
-0303	-003	-006	-006	CFF
-0304	-003	-006	-007	CFG
-0305	-003	-006	-008	CFH
-0306	-003	-006	-009	CFI
-0307	-003	-006	-010	CFJ
-0308	-003	-006	-011	CFK
-0309	-003	-007	-001	CGA
-0310	-003	-007	-002	CGB
-0311	-003	-007	-003	CGC
-0312	-003	-007	-004	CGD
-0313	-003	-007	-005	CGE
-0314	-003	-007	-006	CGF
-0315	-003	-007	-007	CGG
-0316	-003	-007	-008	CGH
-0317	-003	-007	-009	CGI
-0318	-003	-007	-010	CGJ
-0319	-003	-007	-011	CGK
-0320	-003	-008	-001	CHA
-0321	-003	-008	-002	CHB
-0322	-003	-008	-003	CHC
-0323	-003	-008	-004	CHD
-0324	-003	-008	-005	CHE
-0325	-003	-008	-006	CHF
-0326	-003	-008	-007	CHG
-0327	-003	-008	-008	CHH
-0328	-003	-008	-009	CHI
-0329	-003	-008	-010	CHJ
-0330	-003	-008	-011	CHK
-0331	-003	-009	-001	CIA
-0332	-003	-009	-002	CIB
-0333	-003	-009	-003	CIC
-0334	-003	-009	-004	CID
-0335	-003	-009	-005	CIE
-0336	-003	-009	-006	CIF
-0337	-003	-009	-007	CIG
-0338	-003	-009	-008	CIH
-0339	-003	-009	-009	CII
-0340	-003	-009	-010	CIJ
-0341	-003	-009	-011	CIK
-0342	-003	-010	-001	CJA
-0343	-003	-010	-002	CJB
-0344	-003	-010	-003	CJC
-0345	-003	-010	-004	CJD
-0346	-003	-010	-005	CJE
-0347	-003	-010	-006	CJF
-0348	-003	-010	-007	CJG
-0349	-003	-010	-008	CJH
-0350	-003	-010	-009	CJI

Source: https://assist.dla.mil -- Downloaded: 20261O-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0351	9349431-003	9349431-010	9349431-010	CJJ
-0352	-003	-010	-011	CJK
-0353	-003	-011	-001	CKA
-0354	-003	-011	-002	CKB
-0355	-003	-011	-003	CKC
-0356	-003	-011	-004	CKD
-0357	-003	-011	-005	CKE
-0358	-003	-011	-006	CKF
-0359	-003	-011	-007	CKG
-0360	-003	-011	-008	CKH
-0361	-003	-011	-009	CKI
-0362	-003	-011	-010	CKJ
-0363	-003	-011	-011	CKK
-0364	-004	-001	-001	DAA
-0365	-004	-001	-002	DAB
-0366	-004	-001	-003	DAC
-0367	-004	-001	-004	DAD
-0368	-004	-001	-005	DAE
-0369	-004	-001	-006	DAF
-0370	-004	-001	-007	DAG
-0371	-004	-001	-008	DAH
-0372	-004	-001	-009	DAI
-0373	-004	-001	-010	DAJ
-0374	-004	-001	-011	DAK
-0375	-004	-002	-001	DBA
-0376	-004	-002	-002	DBB
-0377	-004	-002	-003	DBC
-0378	-004	-002	-004	DBD
-0379	-004	-002	-005	DBE
-0380	-004	-002	-006	DBF
-0381	-004	-002	-007	DBG
-0382	-004	-002	-008	DBH
-0383	-004	-002	-009	DBI
-0384	-004	-002	-010	DBJ
-0385	-004	-002	-011	DBK
-0386	-004	-003	-001	DCA
-0387	-004	-003	-002	DCB
-0388	-004	-003	-003	DCC
-0389	-004	-003	-004	DCD
-0390	-004	-003	-005	DCE
-0391	-004	-003	-006	DCF
-0392	-004	-003	-007	DCG
-0393	-004	-003	-008	DCH
-0394	-004	-003	-009	DCI
-0395	-004	-003	-010	DCJ
-0396	-004	-003	-011	DCK
-0397	-004	-004	-001	DDA
-0398	-004	-004	-002	DDB
-0399	-004	-004	-003	DDC
-0400	-004	-004	-004	DDD*

* Do not use (see 30.2).

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0401	9349431-004	9349431-004	9349431-005	DDE
-0402	-004	-004	-006	DDF
-0403	-004	-004	-007	DDG
-0404	-004	-004	-008	DDH
-0405	-004	-004	-009	DDI
-0406	-004	-004	-010	DDJ
-0407	-004	-004	-011	DDK
-0408	-004	-005	-001	DEA
-0409	-004	-005	-002	DEB
-0410	-004	-005	-003	DEC
-0411	-004	-005	-004	DED
-0412	-004	-005	-005	DEE
-0413	-004	-005	-006	DEF
-0414	-004	-005	-007	DEG
-0415	-004	-005	-008	DEH
-0416	-004	-005	-009	DEI
-0417	-004	-005	-010	DEJ
-0418	-004	-005	-011	DEK
-0419	-004	-006	-001	DFA
-0420	-004	-006	-002	DFB
-0421	-004	-006	-003	DFC
-0422	-004	-006	-004	DFD
-0423	-004	-006	-005	DFE
-0424	-004	-006	-006	DFF
-0425	-004	-006	-007	DFG
-0426	-004	-006	-008	DFH
-0427	-004	-006	-009	DFI
-0428	-004	-006	-010	DFJ
-0429	-004	-006	-011	DFK
-0430	-004	-007	-001	DGA
-0431	-004	-007	-002	DGB
-0432	-004	-007	-003	DGC
-0433	-004	-007	-004	DGD
-0434	-004	-007	-005	DGE
-0435	-004	-007	-006	DGF
-0436	-004	-007	-007	DGG
-0437	-004	-007	-008	DGH
-0438	-004	-007	-009	DGI
-0439	-004	-007	-010	DGJ
-0440	-004	-007	-011	DGK
-0441	-004	-008	-001	DHA
-0442	-004	-008	-002	DHB
-0443	-004	-008	-003	DHC
-0444	-004	-008	-004	DHD
-0445	-004	-008	-005	DHE
-0446	-004	-008	-006	DHF
-0447	-004	-008	-007	DHG
-0448	-004	-008	-008	DHH
-0449	-004	-008	-009	DHI
-0450	-004	-008	-010	DHJ

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0451	9349431-004	9349431-008	9349431-011	DHK
-0452	-004	-009	-001	DIA
-0453	-004	-009	-002	DIB
-0454	-004	-009	-003	DIC
-0455	-004	-009	-004	DID
-0456	-004	-009	-005	DIE
-0457	-004	-009	-006	DIF
-0458	-004	-009	-007	DIG
-0459	-004	-009	-008	DIH
-0460	-004	-009	-009	DII
-0461	-004	-009	-010	DIJ
-0462	-004	-009	-011	DIK
-0463	-004	-010	-001	DJA
-0464	-004	-010	-002	DJB
-0465	-004	-010	-003	DJC
-0466	-004	-010	-004	DJD
-0467	-004	-010	-005	DJE
-0468	-004	-010	-006	DJF
-0469	-004	-010	-007	DJG
-0470	-004	-010	-008	DJH
-0471	-004	-010	-009	DJI
-0472	-004	-010	-010	DJJ
-0473	-004	-010	-011	DJK
-0474	-004	-011	-001	DKA
-0475	-004	-011	-002	DKB
-0476	-004	-011	-003	DKC
-0477	-004	-011	-004	DKD
-0478	-004	-011	-005	DKE
-0479	-004	-011	-006	DKF
-0480	-004	-011	-007	DKG
-0481	-004	-011	-008	DKH
-0482	-004	-011	-009	DKI
-0483	-004	-011	-010	DKJ
-0484	-004	-011	-011	DKK
-0485	-005	-001	-001	EAA
-0486	-005	-001	-002	EAB
-0487	-005	-001	-003	EAC
-0488	-005	-001	-004	EAD
-0489	-005	-001	-005	EAE
-0490	-005	-001	-006	EAF
-0491	-005	-001	-007	EAG
-0492	-005	-001	-008	EAH
-0493	-005	-001	-009	EAI
-0494	-005	-001	-010	EAJ
-0495	-005	-001	-011	EAK
-0496	-005	-002	-001	EBA
-0497	-005	-002	-002	EBB
-0498	-005	-002	-003	EBC
-0499	-005	-002	-004	EBD
-0500	-005	-002	-005	EBE

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0501	9349431-005	9349431-002	9349431-006	EBF
-0502	-005	-002	-007	EBG
-0503	-005	-002	-008	EBH
-0504	-005	-002	-009	EBI
-0505	-005	-002	-010	EBJ
-0506	-005	-002	-011	EBK
-0507	-005	-003	-001	ECA
-0508	-005	-003	-002	ECB
-0509	-005	-003	-003	ECC
-0510	-005	-003	-004	ECD
-0511	-005	-003	-005	ECE
-0512	-005	-003	-006	ECF
-0513	-005	-003	-007	ECG
-0514	-005	-003	-008	ECH
-0515	-005	-003	-009	ECI
-0516	-005	-003	-010	ECJ
-0517	-005	-003	-011	ECK
-0518	-005	-004	-001	EDA
-0519	-005	-004	-002	EDB
-0520	-005	-004	-003	EDC
-0521	-005	-004	-004	EDD
-0522	-005	-004	-005	EDE
-0523	-005	-004	-006	EDF
-0524	-005	-004	-007	EDG
-0525	-005	-004	-008	EDH
-0526	-005	-004	-009	EDI
-0527	-005	-004	-010	EDJ
-0528	-005	-004	-011	EDK
-0529	-005	-005	-001	EEA
-0530	-005	-005	-002	EEB
-0531	-005	-005	-003	EEC
-0532	-005	-005	-004	EED
-0533	-005	-005	-005	EEE*
-0534	-005	-005	-006	EEF
-0535	-005	-005	-007	EEG
-0536	-005	-005	-008	EEH
-0537	-005	-005	-009	EEI
-0538	-005	-005	-010	EEJ
-0539	-005	-005	-011	EEK
-0540	-005	-006	-001	EFA
-0541	-005	-006	-002	EFB
-0542	-005	-006	-003	EFC
-0543	-005	-006	-004	EFD
-0544	-005	-006	-005	EFE
-0545	-005	-006	-006	EFF
-0546	-005	-006	-007	EFG
-0547	-005	-006	-008	EFH
-0548	-005	-006	-009	EFI
-0549	-005	-006	-010	EFJ
-0550	-005	-006	-011	EFK

* Do not use (see 30.2).

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0551	9349431-005	9349431-007	9349431-001	EGA
-0552	-005	-007	-002	EGB
-0553	-005	-007	-003	EGC
-0554	-005	-007	-004	EGD
-0555	-005	-007	-005	EGE
-0556	-005	-007	-006	EGF
-0557	-005	-007	-007	EGG
-0558	-005	-007	-008	EGH
-0559	-005	-007	-009	EGI
-0560	-005	-007	-010	EGJ
-0561	-005	-007	-011	EGK
-0562	-005	-008	-001	EHA
-0563	-005	-008	-002	EHB
-0564	-005	-008	-003	EHC
-0565	-005	-008	-004	EHD
-0566	-005	-008	-005	EHE
-0567	-005	-008	-006	EHF
-0568	-005	-008	-007	EHG
-0569	-005	-008	-008	EHH
-0570	-005	-008	-009	EHI
-0571	-005	-008	-010	EHJ
-0572	-005	-008	-011	EHK
-0573	-005	-009	-001	EIA
-0574	-005	-009	-002	EIB
-0575	-005	-009	-003	EIC
-0576	-005	-009	-004	EID
-0577	-005	-009	-005	EIE
-0578	-005	-009	-006	EIF
-0579	-005	-009	-007	EIG
-0580	-005	-009	-008	EIH
-0581	-005	-009	-009	EII
-0582	-005	-009	-010	EIJ
-0583	-005	-009	-011	EIK
-0584	-005	-010	-001	EJA
-0585	-005	-010	-002	EJB
-0586	-005	-010	-003	EJC
-0587	-005	-010	-004	EJD
-0588	-005	-010	-005	EJE
-0589	-005	-010	-006	EJF
-0590	-005	-010	-007	EJG
-0591	-005	-010	-008	EJH
-0592	-005	-010	-009	EJI
-0593	-005	-010	-010	EJJ
-0594	-005	-010	-011	EJK
-0595	-005	-011	-001	EKA
-0596	-005	-011	-002	EKB
-0597	-005	-011	-003	EKC
-0598	-005	-011	-004	EKD
-0599	-005	-011	-005	EKE
-0600	-005	-011	-006	EKF

Source: https://assist.dla.mil -- Downloaded: 202610-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0601	9349431-005	9349431-011	9349431-007	EKG
-0602	-005	-011	-008	EKH
-0603	-005	-011	-009	EKI
-0604	-005	-011	-010	EKJ
-0605	-005	-011	-011	EKK
-0606	-006	-001	-001	FAA
-0607	-006	-001	-002	FAB
-0608	-006	-001	-003	FAC
-0609	-006	-001	-004	FAD
-0610	-006	-001	-005	FAE
-0611	-006	-001	-006	FAF
-0612	-006	-001	-007	FAG
-0613	-006	-001	-008	FAH
-0614	-006	-001	-009	FAI
-0615	-006	-001	-010	FAJ
-0616	-006	-001	-011	FAK
-0617	-006	-002	-001	FBA
-0618	-006	-002	-002	FBB
-0619	-006	-002	-003	FBC
-0620	-006	-002	-004	FBD
-0621	-006	-002	-005	FBE
-0622	-006	-002	-006	FBF
-0623	-006	-002	-007	FBG
-0624	-006	-002	-008	FBH
-0625	-006	-002	-009	FBI
-0626	-006	-002	-010	FBJ
-0627	-006	-002	-011	FBK
-0628	-006	-003	-001	FCA
-0629	-006	-003	-002	FCB
-0630	-006	-003	-003	FCC
-0631	-006	-003	-004	FCD
-0632	-006	-003	-005	FCE
-0633	-006	-003	-006	FCF
-0634	-006	-003	-007	FCG
-0635	-006	-003	-008	FCH
-0636	-006	-003	-009	FCI
-0637	-006	-003	-010	FCJ
-0638	-006	-003	-011	FCK
-0639	-006	-004	-001	FDA
-0640	-006	-004	-002	FDB
-0641	-006	-004	-003	FDC
-0642	-006	-004	-004	FDD
-0643	-006	-004	-005	FDE
-0644	-006	-004	-006	FDF
-0645	-006	-004	-007	FDG
-0646	-006	-004	-008	FDH
-0647	-006	-004	-009	FDI
-0648	-006	-004	-010	FDJ
-0649	-006	-004	-011	FDK
-0650	-006	-005	-001	FEA

Source: https://assist.dla.mil -- Downloaded: 202610-26T04:27Z
Check the source to verify that this is the currentversion before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0651	9349431-006	9349431-005	9349431-002	FEB
-0652	-006	-005	-003	FEC
-0653	-006	-005	-004	FED
-0654	-006	-005	-005	FEE
-0655	-006	-005	-006	FEF
-0656	-006	-005	-007	FEG
-0657	-006	-005	-008	FEH
-0658	-006	-005	-009	FEI
-0659	-006	-005	-010	FEJ
-0660	-006	-005	-011	FEK
-0661	-006	-006	-001	FFA
-0662	-006	-006	-002	FFB
-0663	-006	-006	-003	FFC
-0664	-006	-006	-004	FFD
-0665	-006	-006	-005	FFE
-0666	-006	-006	-006	FFF*
-0667	-006	-006	-007	FFG
-0668	-006	-006	-008	FFH
-0669	-006	-006	-009	FFI
-0670	-006	-006	-010	FFJ
-0671	-006	-006	-011	FFK
-0672	-006	-007	-001	FGA
-0673	-006	-007	-002	FGB
-0674	-006	-007	-003	FGC
-0675	-006	-007	-004	FGD
-0676	-006	-007	-005	FGE
-0677	-006	-007	-006	FGF
-0678	-006	-007	-007	FGG
-0679	-006	-007	-008	FGH
-0680	-006	-007	-009	FGI
-0681	-006	-007	-010	FGJ
-0682	-006	-007	-011	FGK
-0683	-006	-008	-001	FHA
-0684	-006	-008	-002	FHB
-0685	-006	-008	-003	FHC
-0686	-006	-008	-004	FHD
-0687	-006	-008	-005	FHE
-0688	-006	-008	-006	FHF
-0689	-006	-008	-007	FHG
-0690	-006	-008	-008	FHH
-0691	-006	-008	-009	FHI
-0692	-006	-008	-010	FHJ
-0693	-006	-008	-011	FHK
-0694	-006	-009	-001	FIA
-0695	-006	-009	-002	FIB
-0696	-006	-009	-003	FIC
-0697	-006	-009	-004	FID
-0698	-006	-009	-005	FIE
-0699	-006	-009	-006	FIF
-0700	-006	-009	-007	FIG

* Do not use (see 30.2).

Source: https://assist.dla.mil -- Downloaded: 202610-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0701	9349431-006	9349431-009	9349431-008	FIH
-0702	-006	-009	-009	FII
-0703	-006	-009	-010	FIJ
-0704	-006	-009	-011	FIK
-0705	-006	-010	-001	FJA
-0706	-006	-010	-002	FJB
-0707	-006	-010	-003	FJC
-0708	-006	-010	-004	FJD
-0709	-006	-010	-005	FJE
-0710	-006	-010	-006	FJF
-0711	-006	-010	-007	FJG
-0712	-006	-010	-008	FJH
-0713	-006	-010	-009	FJI
-0714	-006	-010	-010	FJJ
-0715	-006	-010	-011	FJK
-0716	-006	-011	-001	FKA
-0717	-006	-011	-002	FKB
-0718	-006	-011	-003	FKC
-0719	-006	-011	-004	FKD
-0720	-006	-011	-005	FKE
-0721	-006	-011	-006	FKF
-0722	-006	-011	-007	FKG
-0723	-006	-011	-008	FKH
-0724	-006	-011	-009	FKI
-0725	-006	-011	-010	FKJ
-0726	-006	-011	-011	FKK
-0727	-007	-001	-001	GAA
-0728	-007	-001	-002	GAB
-0729	-007	-001	-003	GAC
-0730	-007	-001	-004	GAD
-0731	-007	-001	-005	GAE
-0732	-007	-001	-006	GAF
-0733	-007	-001	-007	GAG
-0734	-007	-001	-008	GAH
-0735	-007	-001	-009	GAI
-0736	-007	-001	-010	GAJ
-0737	-007	-001	-011	GAK
-0738	-007	-002	-001	GBA
-0739	-007	-002	-002	GBB
-0740	-007	-002	-003	GBC
-0741	-007	-002	-004	GBD
-0742	-007	-002	-005	GBE
-0743	-007	-002	-006	GBF
-0744	-007	-002	-007	GBG
-0745	-007	-002	-008	GBH
-0746	-007	-002	-009	GBI
-0747	-007	-002	-010	GBJ
-0748	-007	-002	-011	GBK
-0749	-007	-003	-001	GCA
-0750	-007	-003	-002	GCB

Source: https://assist.dla.mil -- Downloaded: 202610-26T04:27Z
Check the source to verify that this is the currentversion before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0751	9349431-007	9349431-003	9349431-003	GCC
-0752	-007	-003	-004	GCD
-0753	-007	-003	-005	GCE
-0754	-007	-003	-006	GCF
-0755	-007	-003	-007	GCG
-0756	-007	-003	-008	GCH
-0757	-007	-003	-009	GCI
-0758	-007	-003	-010	GCJ
-0759	-007	-003	-011	GCK
-0760	-007	-004	-001	GDA
-0761	-007	-004	-002	GDB
-0762	-007	-004	-003	GDC
-0763	-007	-004	-004	GDD
-0764	-007	-004	-005	GDE
-0765	-007	-004	-006	GDF
-0766	-007	-004	-007	GDG
-0767	-007	-004	-008	GDH
-0768	-007	-004	-009	GDI
-0769	-007	-004	-010	GDJ
-0770	-007	-004	-011	GDK
-0771	-007	-005	-001	GEA
-0772	-007	-005	-002	GEB
-0773	-007	-005	-003	GEC
-0774	-007	-005	-004	GED
-0775	-007	-005	-005	GEE
-0776	-007	-005	-006	GEF
-0777	-007	-005	-007	GEG
-0778	-007	-005	-008	GEH
-0779	-007	-005	-009	GEI
-0780	-007	-005	-010	GEJ
-0781	-007	-005	-011	GEK
-0782	-007	-006	-001	GFA
-0783	-007	-006	-002	GFB
-0784	-007	-006	-003	GFC
-0785	-007	-006	-004	GFD
-0786	-007	-006	-005	GFE
-0787	-007	-006	-006	GFF
-0788	-007	-006	-007	GFG
-0789	-007	-006	-008	GFH
-0790	-007	-006	-009	GFI
-0791	-007	-006	-010	GFJ
-0792	-007	-006	-011	GFK
-0793	-007	-007	-001	GGA
-0794	-007	-007	-002	GGB
-0795	-007	-007	-003	GGC
-0796	-007	-007	-004	GGD
-0797	-007	-007	-005	GGE
-0798	-007	-007	-006	GGF
-0799	-007	-007	-007	GGG*
-0800	-007	-007	-008	GGH

* Do not use (see 30.2).

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0801	9349431-007	9349431-007	9349431-009	GGI
-0802	-007	-007	-010	GGJ
-0803	-007	-007	-011	GGK
-0804	-007	-008	-001	GHA
-0805	-007	-008	-002	GHB
-0806	-007	-008	-003	GHC
-0807	-007	-008	-004	GHD
-0808	-007	-008	-005	GHE
-0809	-007	-008	-006	GHF
-0810	-007	-008	-007	GHG
-0811	-007	-008	-008	GHH
-0812	-007	-008	-009	GHI
-0813	-007	-008	-010	GHJ
-0814	-007	-008	-011	GHK
-0815	-007	-009	-001	GIA
-0816	-007	-009	-002	GIB
-0817	-007	-009	-003	GIC
-0818	-007	-009	-004	GID
-0819	-007	-009	-005	GIE
-0820	-007	-009	-006	GIF
-0821	-007	-009	-007	GIG
-0822	-007	-009	-008	GIH
-0823	-007	-009	-009	GII
-0824	-007	-009	-010	GIJ
-0825	-007	-009	-011	GIK
-0826	-007	-010	-001	GJA
-0827	-007	-010	-002	GJB
-0828	-007	-010	-003	GJC
-0829	-007	-010	-004	GJD
-0830	-007	-010	-005	GJE
-0831	-007	-010	-006	GJF
-0832	-007	-010	-007	GJG
-0833	-007	-010	-008	GJH
-0834	-007	-010	-009	GJI
-0835	-007	-010	-010	GJJ
-0836	-007	-010	-011	GJK
-0837	-007	-011	-001	GKA
-0838	-007	-011	-002	GKB
-0839	-007	-011	-003	GKC
-0840	-007	-011	-004	GKD
-0841	-007	-011	-005	GKE
-0842	-007	-011	-006	GKF
-0843	-007	-011	-007	GKG
-0844	-007	-011	-008	GKH
-0845	-007	-011	-009	GKI
-0846	-007	-011	-010	GKJ
-0847	-007	-011	-011	GKK
-0848	-008	-001	-001	HAA
-0849	-008	-001	-002	HAB
-0850	-008	-001	-003	HAC

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0851	9349431-008	9349431-001	9349431-004	HAD
-0852	-008	-001	-005	HAE
-0853	-008	-001	-006	HAF
-0854	-008	-001	-007	HAG
-0855	-008	-001	-008	HAH
-0856	-008	-001	-009	HAI
-0857	-008	-001	-010	HAJ
-0858	-008	-001	-011	HAK
-0859	-008	-002	-001	HBA
-0860	-008	-002	-002	HBB
-0861	-008	-002	-003	HBC
-0862	-008	-002	-004	HBD
-0863	-008	-002	-005	HBE
-0864	-008	-002	-006	HBF
-0865	-008	-002	-007	HBG
-0866	-008	-002	-008	HBH
-0867	-008	-002	-009	HBI
-0868	-008	-002	-010	HBJ
-0869	-008	-002	-011	HBK
-0870	-008	-003	-001	HCA
-0871	-008	-003	-002	HCB
-0872	-008	-003	-003	HCC
-0873	-008	-003	-004	HCD
-0874	-008	-003	-005	HCE
-0875	-008	-003	-006	HCF
-0876	-008	-003	-007	HCG
-0877	-008	-003	-008	HCH
-0878	-008	-003	-009	HCI
-0879	-008	-003	-010	HCJ
-0880	-008	-003	-011	HCK
-0881	-008	-004	-001	HDA
-0882	-008	-004	-002	HDB
-0883	-008	-004	-003	HDC
-0884	-008	-004	-004	HDD
-0885	-008	-004	-005	HDE
-0886	-008	-004	-006	HDF
-0887	-008	-004	-007	HDG
-0888	-008	-004	-008	HDH
-0889	-008	-004	-009	HDI
-0890	-008	-004	-010	HDJ
-0891	-008	-004	-011	HDK
-0892	-008	-005	-001	HEA
-0893	-008	-005	-002	HEB
-0894	-008	-005	-003	HEC
-0895	-008	-005	-004	HED
-0896	-008	-005	-005	HEE
-0897	-008	-005	-006	HEF
-0898	-008	-005	-007	HEG
-0899	-008	-005	-008	HEH
-0900	-008	-005	-009	HEI

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0901	9349431-008	9349431-005	9349431-010	HEJ
-0902	-008	-005	-011	HEK
-0903	-008	-006	-001	HFA
-0904	-008	-006	-002	HFB
-0905	-008	-006	-003	HFC
-0906	-008	-006	-004	HFD
-0907	-008	-006	-005	HFE
-0908	-008	-006	-006	HFF
-0909	-008	-006	-007	HFG
-0910	-008	-006	-008	HFH
-0911	-008	-006	-009	HFI
-0912	-008	-006	-010	HFJ
-0913	-008	-006	-011	HFK
-0914	-008	-007	-001	HGA
-0915	-008	-007	-002	HGB
-0916	-008	-007	-003	HGC
-0917	-008	-007	-004	HGD
-0918	-008	-007	-005	HGE
-0919	-008	-007	-006	HGF
-0920	-008	-007	-007	HGG
-0921	-008	-007	-008	HGH
-0922	-008	-007	-009	HGI
-0923	-008	-007	-010	HGJ
-0924	-008	-007	-011	HGK
-0925	-008	-008	-001	HHA
-0926	-008	-008	-002	HHB
-0927	-008	-008	-003	HHC
-0928	-008	-008	-004	HHD
-0929	-008	-008	-005	HHE
-0930	-008	-008	-006	HHF
-0931	-008	-008	-007	HHG
-0932	-008	-008	-008	HHH*
-0933	-008	-008	-009	HHI
-0934	-008	-008	-010	HHJ
-0935	-008	-008	-011	HHK
-0936	-008	-009	-001	HIA
-0937	-008	-009	-002	HIB
-0938	-008	-009	-003	HIC
-0939	-008	-009	-004	HID
-0940	-008	-009	-005	HIE
-0941	-008	-009	-006	HIF
-0942	-008	-009	-007	HIG
-0943	-008	-009	-008	HIH
-0944	-008	-009	-009	HII
-0945	-008	-009	-010	HIJ
-0946	-008	-009	-011	HIK
-0947	-008	-010	-001	HJA
-0948	-008	-010	-002	HJB
-0949	-008	-010	-003	HJC
-0950	-008	-010	-004	HJD

* Do not use (see 30.2).

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-0951	9349431-008	9349431-010	9349431-005	HJE
-0952	-008	-010	-006	HJF
-0953	-008	-010	-007	HJG
-0954	-008	-010	-008	HJH
-0955	-008	-010	-009	HJI
-0956	-008	-010	-010	HJJ
-0957	-008	-010	-011	HJK
-0958	-008	-011	-001	HKA
-0959	-008	-011	-002	HKB
-0960	-008	-011	-003	HKC
-0961	-008	-011	-004	HKD
-0962	-008	-011	-005	HKE
-0963	-008	-011	-006	HKF
-0964	-008	-011	-007	HKG
-0965	-008	-011	-008	HKH
-0966	-008	-011	-009	HKI
-0967	-008	-011	-010	HKJ
-0968	-008	-011	-011	HKK
-0969	-009	-001	-001	IAA
-0970	-009	-001	-002	IAB
-0971	-009	-001	-003	IAC
-0972	-009	-001	-004	IAD
-0973	-009	-001	-005	IAE
-0974	-009	-001	-006	IAF
-0975	-009	-001	-007	IAG
-0976	-009	-001	-008	IAH
-0977	-009	-001	-009	IAI
-0978	-009	-001	-010	IAJ
-0979	-009	-001	-011	IAK
-0980	-009	-002	-001	IBA
-0981	-009	-002	-002	IBB
-0982	-009	-002	-003	IBC
-0983	-009	-002	-004	IBD
-0984	-009	-002	-005	IBE
-0985	-009	-002	-006	IBF
-0986	-009	-002	-007	IBG
-0987	-009	-002	-008	IBH
-0988	-009	-002	-009	IBI
-0989	-009	-002	-010	IBJ
-0990	-009	-002	-011	IBK
-0991	-009	-003	-001	ICA
-0992	-009	-003	-002	ICB
-0993	-009	-003	-003	ICC
-0994	-009	-003	-004	ICD
-0995	-009	-003	-005	ICE
-0996	-009	-003	-006	ICF
-0997	-009	-003	-007	ICG
-0998	-009	-003	-008	ICH
-0999	-009	-003	-009	ICI
-1000	-009	-003	-010	ICJ

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-1001	9349431-009	9349431-003	9349431-011	ICK
-1002	-009	-004	-001	IDA
-1003	-009	-004	-002	IDB
-1004	-009	-004	-003	IDC
-1005	-009	-004	-004	IDD
-1006	-009	-004	-005	IDE
-1007	-009	-004	-006	IDF
-1008	-009	-004	-007	IDG
-1009	-009	-004	-008	IDH
-1010	-009	-004	-009	IDI
-1011	-009	-004	-010	IDJ
-1012	-009	-004	-011	IDK
-1013	-009	-005	-001	IEA
-1014	-009	-005	-002	IEB
-1015	-009	-005	-003	IEC
-1016	-009	-005	-004	IED
-1017	-009	-005	-005	IEE
-1018	-009	-005	-006	IEF
-1019	-009	-005	-007	IEG
-1020	-009	-005	-008	IEH
-1021	-009	-005	-009	IEI
-1022	-009	-005	-010	IEJ
-1023	-009	-005	-011	IEK
-1024	-009	-006	-001	IFA
-1025	-009	-006	-002	IFB
-1026	-009	-006	-003	IFC
-1027	-009	-006	-004	IFD
-1028	-009	-006	-005	IFE
-1029	-009	-006	-006	IFF
-1030	-009	-006	-007	IFG
-1031	-009	-006	-008	IFH
-1032	-009	-006	-009	IFI
-1033	-009	-006	-010	IFJ
-1034	-009	-006	-011	IFK
-1035	-009	-007	-001	IGA
-1036	-009	-007	-002	IGB
-1037	-009	-007	-003	IGC
-1038	-009	-007	-004	IGD
-1039	-009	-007	-005	IGE
-1040	-009	-007	-006	IGF
-1041	-009	-007	-007	IGG
-1042	-009	-007	-008	IGH
-1043	-009	-007	-009	IGI
-1044	-009	-007	-010	IGJ
-1045	-009	-007	-011	IGK
-1046	-009	-008	-001	IHA
-1047	-009	-008	-002	IHB
-1048	-009	-008	-003	IHC
-1049	-009	-008	-004	IHD
-1050	-009	-008	-005	IHE

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-1051	9349431-009	9349431-008	9349431-006	IHF
-1052	-009	-008	-007	IHG
-1053	-009	-008	-008	IHH
-1054	-009	-008	-009	IHI
-1055	-009	-008	-010	IHJ
-1056	-009	-008	-011	IHK
-1057	-009	-009	-001	IIA
-1058	-009	-009	-002	IIB
-1059	-009	-009	-003	IIC
-1060	-009	-009	-004	IID
-1061	-009	-009	-005	IIE
-1062	-009	-009	-006	IIF
-1063	-009	-009	-007	IIG
-1064	-009	-009	-008	IIH
-1065	-009	-009	-009	III*
-1066	-009	-009	-010	IIJ
-1067	-009	-009	-011	IIK
-1068	-009	-010	-001	IJA
-1069	-009	-010	-002	IJB
-1070	-009	-010	-003	IJC
-1071	-009	-010	-004	IJD
-1072	-009	-010	-005	IJE
-1073	-009	-010	-006	IJF
-1074	-009	-010	-007	IJG
-1075	-009	-010	-008	IJH
-1076	-009	-010	-009	IJI
-1077	-009	-010	-010	IJJ
-1078	-009	-010	-011	IJK
-1079	-009	-011	-001	IKA
-1080	-009	-011	-002	IKB
-1081	-009	-011	-003	IKC
-1082	-009	-011	-004	IKD
-1083	-009	-011	-005	IKE
-1084	-009	-011	-006	IKF
-1085	-009	-011	-007	IKG
-1086	-009	-011	-008	IKH
-1087	-009	-011	-009	IKI
-1088	-009	-011	-010	IKJ
-1089	-009	-011	-011	IKK
-1090	-010	-001	-001	JAA
-1091	-019	-001	-002	JAB
-1092	-019	-001	-003	JAC
-1093	-010	-001	-004	JAD
-1094	-010	-001	-005	JAE
-1095	-010	-001	-006	JAF
-1096	-010	-001	-007	JAG
-1097	-010	-001	-008	JAH
-1098	-010	-001	-009	JAI
-1099	-010	-001	-010	JAJ
-1100	-010	-001	-011	JAK

* Do not use (see 30.2).

Source: https://assist.dla.mil -- Downloaded: 202610-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-1101	9349431-010	9349431-002	9349431-001	JBA
-1102	-010	-002	-002	JBB
-1103	-010	-002	-003	JBC
-1104	-010	-002	-004	JBD
-1105	-010	-002	-005	JBE
-1106	-010	-002	-006	JBF
-1107	-010	-002	-007	JBG
-1108	-010	-002	-008	JBH
-1109	-010	-002	-009	JBI
-1110	-010	-002	-010	JBJ
-1111	-010	-002	-011	JBK
-1112	-010	-003	-001	JCA
-1113	-010	-003	-002	JCB
-1114	-010	-003	-003	JCC
-1115	-010	-003	-004	JCD
-1116	-010	-003	-005	JCE
-1117	-010	-003	-006	JCF
-1118	-010	-003	-007	JCG
-1119	-010	-003	-008	JCH
-1120	-010	-003	-009	JCI
-1121	-010	-003	-010	JCJ
-1122	-010	-003	-011	JCK
-1123	-010	-004	-001	JDA
-1124	-010	-004	-002	JDB
-1125	-010	-004	-003	JDC
-1126	-010	-004	-004	JDD
-1127	-010	-004	-005	JDE
-1128	-010	-004	-006	JDF
-1129	-010	-004	-007	JDG
-1130	-010	-004	-008	JDH
-1131	-010	-004	-009	JDI
-1132	-010	-004	-010	JDJ
-1133	-010	-004	-011	JDK
-1134	-010	-005	-001	JEA
-1135	-010	-005	-002	JEB
-1136	-010	-005	-003	JEC
-1137	-010	-005	-004	JED
-1138	-010	-005	-005	JEE
-1139	-010	-005	-006	JEF
-1140	-010	-005	-007	JEG
-1141	-010	-005	-008	JEH
-1142	-010	-005	-009	JEI
-1143	-010	-005	-010	JEJ
-1144	-010	-005	-011	JEK
-1145	-010	-006	-001	JFA
-1146	-010	-006	-002	JFB
-1147	-010	-006	-003	JFC
-1148	-010	-006	-004	JFD
-1149	-010	-006	-005	JFE
-1150	-010	-006	-006	JFF

Source: https://assist.dla.mil -- Downloaded: 20261O-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-1151	9349431-010	9349431-006	9349431-007	JFG
-1152	-010	-006	-008	JFH
-1153	-010	-006	-009	JFI
-1154	-010	-006	-010	JFJ
-1155	-010	-006	-011	JFK
-1156	-010	-007	-001	JGA
-1157	-010	-007	-002	JGB
-1158	-010	-007	-003	JGC
-1159	-010	-007	-004	JGD
-1160	-010	-007	-005	JGE
-1161	-010	-007	-006	JGF
-1162	-010	-007	-007	JGG
-1163	-010	-007	-008	JGH
-1164	-010	-007	-009	JGI
-1165	-010	-007	-010	JGJ
-1166	-010	-007	-011	JGK
-1167	-010	-008	-001	JHA
-1168	-010	-008	-002	JHB
-1169	-010	-008	-003	JHC
-1170	-010	-008	-004	JHD
-1171	-010	-008	-005	JHE
-1172	-010	-008	-006	JHF
-1173	-010	-008	-007	JHG
-1174	-010	-008	-008	JHH
-1175	-010	-008	-009	JHI
-1176	-010	-008	-010	JHJ
-1177	-010	-008	-011	JHK
-1178	-010	-009	-001	JIA
-1179	-010	-009	-002	JIB
-1180	-010	-009	-003	JIC
-1181	-010	-009	-004	JID
-1182	-010	-009	-005	JIE
-1183	-010	-009	-006	JIF
-1184	-010	-009	-007	JIG
-1185	-010	-009	-008	JIH
-1186	-010	-009	-009	JII
-1187	-010	-009	-010	JIJ
-1188	-010	-009	-011	JIK
-1189	-010	-010	-001	JJA
-1190	-010	-010	-002	JJB
-1191	-010	-010	-003	JJC
-1192	-010	-010	-004	JJD
-1193	-010	-010	-005	JJE
-1194	-010	-010	-006	JJF
-1195	-010	-010	-007	JJG
-1196	-010	-010	-008	JJH
-1197	-010	-010	-009	JJI
-1198	-010	-010	-010	JJJ*
-1199	-010	-010	-011	JJK
-1200	-010	-011	-001	JKA

* Do not use (see 30.2).

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-1201	9349431-010	9349431-011	9349431-002	JKB
-1202	-010	-011	-003	JKC
-1203	-010	-011	-004	JKD
-1204	-010	-011	-005	JKE
-1205	-010	-011	-006	JKF
-1206	-010	-011	-007	JKG
-1207	-010	-011	-008	JKH
-1208	-010	-011	-009	JKI
-1209	-010	-011	-010	JKJ
-1210	-010	-011	-011	JKK
-1211	-011	-001	-001	KAA
-1212	-011	-001	-002	KAB
-1213	-011	-001	-003	KAC
-1214	-011	-001	-004	KAD
-1215	-011	-001	-005	KAE
-1216	-011	-001	-006	KAF
-1217	-011	-001	-007	KAG
-1218	-011	-001	-008	KAH
-1219	-011	-001	-009	KAI
-1220	-011	-001	-010	KAJ
-1221	-011	-001	-011	KAK
-1222	-011	-002	-001	KBA
-1223	-011	-002	-002	KBB
-1224	-011	-002	-003	KBC
-1225	-011	-002	-004	KBD
-1226	-011	-002	-005	KBE
-1227	-011	-002	-006	KBF
-1228	-011	-002	-007	KBG
-1229	-011	-002	-008	KBH
-1230	-011	-002	-009	KBI
-1231	-011	-002	-010	KBJ
-1232	-011	-002	-011	KBK
-1233	-011	-003	-001	KCA
-1234	-011	-003	-002	KCB
-1235	-011	-003	-003	KCC
-1236	-011	-003	-004	KCD
-1237	-011	-003	-005	KCE
-1238	-011	-003	-006	KCF
-1239	-011	-003	-007	KCG
-1240	-011	-003	-008	KCH
-1241	-011	-003	-009	KCI
-1242	-011	-003	-010	KCJ
-1243	-011	-003	-011	KCK
-1244	-011	-004	-001	KDA
-1245	-011	-004	-002	KDB
-1246	-011	-004	-003	KDC
-1247	-011	-004	-004	KDD
-1248	-011	-004	-005	KDE
-1249	-011	-004	-006	KDF
-1250	-011	-004	-007	KDG

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-1251	9349431-011	9349431-004	9349431-008	KDH
-1252	-011	-004	-009	KDI
-1253	-011	-004	-010	KDJ
-1254	-011	-004	-011	KDK
-1255	-011	-005	-001	KEA
-1256	-011	-005	-002	KEB
-1257	-011	-005	-003	KEC
-1258	-011	-005	-004	KED
-1259	-011	-005	-005	KEE
-1260	-011	-005	-006	KEF
-1261	-011	-005	-007	KEG
-1262	-011	-005	-008	KEH
-1263	-011	-005	-009	KEI
-1264	-011	-005	-010	KEJ
-1265	-011	-005	-011	KEK
-1266	-011	-006	-001	KFA
-1267	-011	-006	-002	KFB
-1268	-011	-006	-003	KFC
-1269	-011	-006	-004	KFD
-1270	-011	-006	-005	KFE
-1271	-011	-006	-006	KFF
-1272	-011	-006	-007	KFG
-1273	-011	-006	-008	KFH
-1274	-011	-006	-009	KFI
-1275	-011	-006	-010	KFJ
-1276	-011	-006	-011	KFK
-1277	-011	-007	-001	KGA
-1278	-011	-007	-002	KGB
-1279	-011	-007	-003	KGC
-1280	-011	-007	-004	KGD
-1281	-011	-007	-005	KGE
-1282	-011	-007	-006	KGF
-1283	-011	-007	-007	KGG
-1284	-011	-007	-008	KGH
-1285	-011	-007	-009	KGI
-1286	-011	-007	-010	KGJ
-1287	-011	-007	-011	KGK
-1288	-011	-008	-001	KHA
-1289	-011	-008	-002	KHB
-1290	-011	-008	-003	KHC
-1291	-011	-008	-004	KHD
-1292	-011	-008	-005	KHE
-1293	-011	-008	-006	KHF
-1294	-011	-008	-007	KHG
-1295	-011	-008	-008	KHH
-1296	-011	-008	-009	KHI
-1297	-011	-008	-010	KHJ
-1298	-011	-008	-011	KHK
-1299	-011	-009	-001	KIA
-1300	-011	-009	-002	KIB

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

Combination lock assembly part No.	Code wheel A part No.	Code wheel B part No.	Code wheel C part No.	Code ref.
9349435-1301	9349431-011	9349431-009	9349431-003	KIC
-1302	-011	-009	-004	KID
-1303	-011	-009	-005	KIE
-1304	-011	-009	-006	KIF
-1305	-011	-009	-007	KIG
-1306	-011	-009	-008	KIH
-1307	-011	-009	-009	KII
-1308	-011	-009	-010	KIJ
-1309	-011	-009	-011	KIK
-1310	-011	-010	-001	KJA
-1311	-011	-010	-002	KJB
-1312	-011	-010	-003	KJC
-1313	-011	-010	-004	KJD
-1314	-011	-010	-005	KJE
-1315	-011	-010	-006	KJF
-1316	-011	-010	-007	KJG
-1317	-011	-010	-008	KJH
-1318	-011	-010	-009	KJI
-1319	-011	-010	-010	KJJ
-1320	-011	-010	-011	KJK
-1321	-011	-011	-001	KKA
-1322	-011	-011	-002	KKB
-1323	-011	-011	-003	KKC
-1324	-011	-011	-004	KKD
-1325	-011	-011	-005	KKE
-1326	-011	-011	-006	KKF
-1327	-011	-011	-007	KKG
-1328	-011	-011	-008	KKH
-1329	-011	-011	-009	KKI
-1330	-011	-011	-010	KKJ
-1331	-011	-011	-011	KKK*

* Do not use (see 30.2).

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

INSTRUCTIONS: In a continuing effort to make our standardization documents better, the DoD provides this form for use in submitting comments and suggestions for improvements. All users of military standardization documents are invited to provide suggestions. This form may be detached, folded along the lines indicated, taped along the loose edge *(DO NOT STAPLE)*, and mailed. In block 5, be as specific as possible about particular problem areas such as wording which required interpretation, was too rigid, restrictive, loose, ambiguous, or was incompatible, and give proposed wording changes which would alleviate the problems. Enter in block 6 any remarks not related to a specific paragraph of the document. If block 7 is filled out, an acknowledgement will be mailed to you within 30 days to let you know that your comments were received and are being considered.

NOTE: This form may not be used to request copies of documents, nor to request waivers, deviations, or clarification of specification requirements on current contracts. Comments submitted on this form do not constitute or imply authorization to waive any portion of the referenced document*(s)* or to amend contractual requirements.

(Fold along this line)

(Fold along this line)

DEPARTMENT OF THE ARMY

NO POSTAGE NECESSARY IF MAILED IN THE UNITED STATES

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE $300

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 12062 WASHINGTON D C

POSTAGE WILL BE PAID BY THE DEPARTMENT OF THE ARMY

COMMANDER
US ARMY ARDEC
ATTN: AMSMC-QA
PICATINNY ARSENAL, NJ 07806-5000

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.

(TO DETACH THIS FORM, CUT ALONG THIS LINE.)

STANDARDIZATION DOCUMENT IMPROVEMENT PROPOSAL

(See Instructions – Reverse Side)

1. DOCUMENT NUMBER	2. DOCUMENT TITLE
MIL-L-63953	LOCK, COMBINATION, ASSEMBLY

3a. NAME OF SUBMITTING ORGANIZATION	4. TYPE OF ORGANIZATION *(Mark one)*
	☐ VENDOR
b. ADDRESS *(Street, City, State, ZIP Code)*	☐ USER
	☐ MANUFACTURER
	☐ OTHER *(Specify)*: _____

5. PROBLEM AREAS

a. Paragraph Number and Wording:

b. Recommended Wording:

c. Reason/Rationale for Recommendation:

6. REMARKS

7a. NAME OF SUBMITTER *(Last, First, MI)* – Optional	b. WORK TELEPHONE NUMBER *(Include Area Code)* – Optional
c. MAILING ADDRESS *(Street, City, State, ZIP Code)* – Optional	8. DATE OF SUBMISSION *(YYMMDD)*

DD FORM 82 MAR 1426 PREVIOUS EDITION IS OBSOLETE.

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T04:27Z
Check the source to verify that this is the current version before use.