MILITARY STANDARD

AUTOMATED ENGINEERING

DOCUMENT PREPARATION SYSTEM

AMPLIFIERS

TO ALL HOLDERS OF MIL-STD-35-103(MI):

1. THE FOLLOWING PAGE OF MIL-STD-35-103(MI) HAVE BEEN REVISED AND SUPERSEDE THE PAGES LISTED:

NEW PAGE	DATE	SUPERSEDED PAGE	DATE
15	30 June 1976	(REPRINTED WITHOUT CHANGE)	
16	18 November 1976	16	30 June 1976
17	18 November 1976	17	30 June 1976
18	18 November 1976	18	30 June 1976
75	30 June 1976	(REPRINTED WITHOUT CHANGE)	
76	18 November 1976	76	30 June 1976
121	18 November 1976	121 and 122	30 June 1976
159	18 November 1976	159	30 June 1976
160	18 November 1976	160	30 June 1976
161	18 November 1976	161	30 June 1976
162	18 November 1976	162	30 June 1976
163	18 November 1976	163	30 June 1976
164	18 November 1976	164	30 June 1976
165	18 November 1976	165	30 June 1976
166	18 November 1976	166	30 June 1976
167	18 November 1976	167	30 June 1976
168	18 November 1976	168	30 June 1976
169	18 November 1976	169	30 June 1976
170	18 November 1976	170	30 June 1976
171	18 November 1976	171	30 June 1976
172	18 November 1976	172	30 June 1976
173	18 November 1976	173	30 June 1976
174	18 November 1976	174	30 June 1976
175	18 November 1976	175	30 June 1976
176	18 November 1976	176	30 June 1976

2. RETAIN THIS NOTICE PAGE AND INSERT BEFORE THE TABLE OF CONTENTS.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

3. Holders of MIL-STD-35-103(MI) will verify that page changes and additions indicated above have been entered. The notice page will be retained as a check sheet. This issuance, together with appended pages is a separate publication. Each notice is to be retained by stocking points until the Military Standard is completely revised or canceled.

Custodians:
Army - MI

Review activities:
Army - AT
Army - AV
Army - EL
Army - ME
Army - MR
Army - SG
Army - WC

User activity:
Army - MU

Preparing activity:
Army - MI

(Project EDS-A198)

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

"GROUP A INSPECTION. GROUP A INSPECTION SHALL BE PERFORMED AS SPECIFIED IN THE SPECIFICATION REFERENCED IN 3.1 EXCEPT THERMAL SHOCK SHALL BE 175 DEG C HIGH TEMP."

The test method per 1006 code and requirements per 1006 code from the same test shall not be used together. This condition would indicate no exception is being specified. If a test method code(s) has been selected, it is mandatory that a requirement code be selected; and if a requirement code has been selected, it is mandatory that a test method code(s) be selected.

5.5 Approved Item Name Code

The approved item name code to be entered on the SRS with Code 1007 for an Amplifier is selected from the following list:

APPROVED ITEM NAME	ITEM NAME CODE
Audio Frequency Amplifier	00511
Direct Current Amplifier	19692
Electronic Control Amplifier	00096
Intermediate Frequency Amplifier	00885
Radio Frequency Amplifier	00446
Trigger Pulse Amplifier	00094
Video Amplifier	00095
Unapproved Name	77777

Only the Item Name Code number is entered on the SRS with Code 1007.

Reprinted without change.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

5.6 Dimensions and Figures

All specification requirements for dimensions and figures described in MIL-STD-35 are applicable.

The figures applicable to Amplifiers are contained in Section 7. It is mandatory to enter, on the SRS, Code 1009 and a figure number.

5.7 Applicable Documents

The documents listed in the Applicable Document List of Section 5 of MIL-STD-35 and appropriate codes from Table B of MIL-STD-35 shall be entered on the SRS. In addition, the appropriate documents shown in the matrix below and the applicable codes from Table B of MIL-STD-35 shall be entered on the SRS when the codes in the TEST columns are used to specify design tests. Shown in the TEST columns are the names of the applicable tests. A document designation, with a code from Table B, is entered on the SRS only once.

DOCUMENT \ TEST	Bandwidth and Center Frequency - Code 1617	Endurance Code - 1715	Fidelity - Code 1730	Frequency Response - Code 1743	Gain - Code 1757	Impedance - Code 1800	Linearity - Code 1807	Power - Code 1836	Pulse Response - Code 1851	Spurious Outputs - Code 1907	Stability - Code 1942
MIL-A-6589								X			
MIL-A-8026		X						X			
MIL-A-11976								X			X
MIL-A-13290				X	X			X		X	
MIL-A-14819				X				X		X	

Supersedes page 16 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

DOCUMENT	TEST: Bandwidth and Center Frequency - Code 1617	Endurance Code 1715	Fidelity - Code 1730	Frequency Response - Code 1743	Gain - Code 1757	Impedance - Code 1800	Linearity - Code 1807	Power - Code 1836	Pulse Response - Code 1851	Spurious Outputs - Code 1907	Stability - Code 1942
MIL-A-14878					X			X	X		
MIL-A-16294		X		X		X		X		X	X
MIL-A-23088				X		X		X		X	
MIL-A-23595				X	X	X	X	X		X	X
MIL-A-24181			X					X			
MIL-A-25546				X						X	
MIL-A-28716				X						X	
MIL-A-28988						X		X		X	
MIL-A-45112	X				X			X			
MIL-A-45130					X			X			X
MIL-A-45136					X			X			
MIL-A-45606					X			X		X	
MIL-A-45610									X		
MIL-A-45652	X				X			X			
MIL-A-45781								X			X
MIL-A-46330									X		

Supersedes page 17 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

DOCUMENT \ TEST	Bandwidth and Center Frequency - Code 1617	Endurance Code 1715	Fidelity - Code 1730	Frequency Response - Code 1743	Gain - Code 1757	Impedance - Code 1800	Linearity - Code 1807	Power - Code 1836	Pulse Response - Code 1851	Spurious Outputs - Code 1907	Stability - Code 1942
MIL-A-46804					X			X		X	
MIL-A-46813					X			X			X
MIL-A-46836	X				X			X			
MIL-A-46841								X			
MIL-A-48316									X		
MIL-A-55129				X		X		X		X	
MIL-A-55218	X				X				X	X	
MIL-A-60100	X				X						
MIL-A-60146								X			
MIL-A-83162					X			X			

The documents listed in the Applicable Document List of Section 5 of MIL-STD-35 and appropriate codes from Table B of MIL-STD-35 shall be entered on the SRS. In addition, the appropriate documents shown in the DOCUMENTS column below and the applicable codes from Table B of MIL-STD-35

Supersedes page 18 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 202610-23T21:02Z
Check the source to verify that this is the current version before use.

COLUMN	CODE USE (Cont)
17,18,19,20	Response or output voltage values, including polarity, units of measure, tolerance in percentage, and whether min or max. Due to space limitations, use min or max.
21	Maximum output power limits in plus or minus decibels.
22	Maximum percentage of signal output distortion.

Code 1910 from the SRL and a value, entered on the SRS, will specify the RF modulation level measurement in percent of the carrier.

Codes 1912 and 1913 specify the rated audio frequency power output in watts and an audio frequency input in milliwatts while determining the signal to noise ratio.

Codes 1914 and 1915 specify the audio frequency input in volts ac at a frequency in kilohertz for the measurement of signal to noise ratio. If Code 1914 is used, it is mandatory that Code 1915 be used.

Code 1916 is the requirement code (see 5.4).

Code 1917 is the except requirement code (see 5.4).

To detail requirements per Table VIII, Code 1918 is mandatory. Requirements are specified with applicable codes from columns 17 thru 22.

Code 1918 and an "X", entered on the SRS, will specify that the requirements are specified using codes from the SPURIOUS OUTPUTS TABLE, Table VIII in Section 8.

Code 1919 and a value, entered on the SRS, will specify the minimum third order intermodulation distortion limits in decibels.

Codes 1920 and 1921 and values, entered on the SRS, will specify the maximum envelope distortion in percent at a modulation level in percent. If Code 1920 is used, it is mandatory that Code 1921 be used.

Reprinted without change.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

Code 1922 and an "X", entered on the SRS, will specify that the output sine wave shall have no spurious oscillations but with partial clipping acceptable.

Code 1923 and a value, entered on the SRS, will specify the minimum decibels that all nonharmonic spurious outputs shall be down from the desired output level.

Code 1924 and a value, entered on the SRS, will specify the minimum attenuation in decibels of all harmonically related signals.

Codes 1925, 1926, and 1927 and values, will specify the bipolar noise amplitude in volts peak to peak, a tolerance of plus and minus volts peak to peak, with an output in microamperes, respectively. If Code 1925 is used, it is mandatory that Codes 1926 and 1927 be used.

Codes 1928 and 1929 and values, entered on the SRS, will specify the maximum percentage increase in noise amplitude as the output varies in plus or minus microamperes. If Code 1928 is used, it is mandatory that Code 1929 be used.

Code 1930 and a value, entered on the SRS, will specify the minimum decibels that the hum and noise output shall be below the output level of either of two equal amplitude tones modulating the transmitter to rated peak envelope RF power.

Code 1931 and a value, entered on the SRS, will specify the minimum signal to noise ratio in decibels.

The codes from Table VIII and values entered on the SRS in Example 14 specify the following:

Code 3500 specifies that the amplifier shall be operated under standard test conditions for a distortion test.

Codes 3545, 3546, 3548, and 3549 specify that the applied voltage shall be 0.22 volts rms at a frequency of 1000 hertz.

Codes 3639 and 3715 specify that with a load impedance of 100 ohms the distortion shall not exceed five percent.

Codes 3644 and 3721 specify that with a load impedance of 600 ohms the distortion shall not exceed ten percent.

Supersedes page 76 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 20260-23T21:02Z
Check the source to verify that this is the current version before use.

SPECIFICATION REQUIREMENTS LIST (SRL)

REF PARA	CHARACTERISTIC	
	NAME	CODE
5.29	Moisture Resistance	
	*Test Methods (Select one)	
	Per 1006 document (see 5.4).	1390
	Per 1006 document except (see 5.4) ____	1391
	Per MIL-STD-202, Method 106.	1397
	Loading voltage (select one)	
	(Vdc)	4981
	(Vac)	4980
	Step 7a not applicable.	4985
	Step 7b not applicable.	4986
	Mount in accordance with document from 5.7 (doc des)	1449
	Perform dielectric withstanding voltage test at high humidity.	4983
	Perform dielectric withstanding voltage test after drying.	4984
	*Requirements (Select one)	
	Per 1006 document (see 5.4).	1399
	Per 1006 document except (see 5.4) ____	1400

Supersedes pages 121 and 122 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE I. GAIN
(See 5.9)

GAIN TABLE

REF NO.	CONDITION	APPLIED: SIGNAL VOLTAGE: PLRT AND VALUE	SIGNAL VOLTAGE: UNITS	SIGNAL VOLTAGE: PCT TOL	FREQUENCY DISCRETE: VALUE	FREQUENCY DISCRETE: UNITS	FREQUENCY DISCRETE: TOL +OR- (HZ)
1	2700	2701	2702	2703	2704	2705	2706
2	2707	2708	2709	2710	2711	2712	2713
3	2714	2715	2716	2717	2718	2719	2720
4	2721	2722	2723	2724	2725	2726	2727
5	2728	2729	2730	2731	2732	2733	2734
	*10	*6	*10	*4	*6	*10	*4
COL 1	2	3	4	5	6	7	8

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. The table will appear in Section 3 of the MSE.

Supersedes page 159 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE I. GAIN (CONT)
(See 5.9)

GAIN TABLE (CONT)

	RESPONSE						
	SIGNAL VOLTAGE						
REF NO.	PLRT AND VALUE	UNITS	PCT TOL	MIN OR MAX	DB (+ OR -) MIN	DB (+ OR -) MAX	STAB TIME MILLISEC
1	2735	2736	2737	2738	2739	2740	2741
2	2742	2743	2744	2745	2746	2747	2748
3	2749	2750	2751	2752	2753	2754	2755
4	2756	2757	2758	2759	2760	2761	2762
5	2763	2764	2765	2766	2767	2768	2769
	*6	*10	*4	*3	*4	*4	*8
COL 1	9	10	11	12	13	14	15

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. The table will appear in Section 3 of the MSE.

Supersedes page 160 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE II. POWER
(See 5.10)

POWER TABLE

REF NO.	TERMINALS INP	TERMINALS OUT	APPLIED: SIGNAL VOLTAGE: PLRT AND VALUE	SIGNAL VOLTAGE: UNITS	SIGNAL VOLTAGE: PCT TOL	FREQUENCY DISCRETE: VALUE	FREQUENCY DISCRETE: UNITS	FREQUENCY DISCRETE: TOL +OR- (HZ)	LOAD OHMS
1	2990	2991	2992	2993	2994	2995	2996	2997	2998
2	2999	3000	3001	3002	3003	3004	3005	3006	3007
3	3008	3009	3010	3011	3012	3013	3014	3015	3016
4	3017	3018	3019	3020	3021	3022	3023	3024	3025
5	3026	3027	3028	3029	3030	3031	3032	3033	3034
6	3035	3036	3037	3038	3039	3040	3041	3042	3043
7	3044	3045	3046	3047	3048	3049	3050	3051	3052
8	3053	3054	3055	3056	3057	3058	3059	3060	3061
9	3062	3063	3064	3065	3066	3067	3068	3069	3070
10	3071	3072	3073	3074	3075	3076	3077	3078	3079
	*5	*5	*5	*10	*4	*6	*10	*4	*4
COL	1 2	3	4	5	6	7	8	9	10

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. The table will appear in Section 3 of the MSE.

Supersedes page 161 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE II. POWER (CONT)

(See 5.10)

POWER TABLE (CONT)

	RESPONSE OUTPUT						
	POWER		SIGNAL VOLTAGE				
REF NO.	VALUE	UNITS	PLRT AND VALUE	UNITS	PCT TOL	MAX UNB V	MIN OR MAX
1	3080	3081	3082	3083	3084	3085	3086
2	3088	3089	3090	3091	3092	3093	3094
3	3096	3097	3098	3099	3100	3101	3102
4	3104	3105	3106	3107	3108	3109	3110
5	3112	3113	3114	3115	3116	3117	3118
6	3120	3121	3122	3123	3124	3125	3126
7	3128	3129	3130	3131	3132	3133	3134
8	3136	3137	3138	3139	3140	3141	3142
9	3144	3145	3146	3147	3148	3149	3150
10	3152	3153	3154	3155	3156	3157	3158
	*5	*10	*5	*10	*4	*4	*3
COL 1	11	12	13	14	15	16	17

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. The table will appear in Section 3 of the MSE.

Supersedes page 162 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 20260-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE III. CONNECTORS

(See 5.11.8)

CONNECTORS TABLE

INPUT OR OUTPUT	TYPE OR SERIES	SPECIFICATION	FIGURE SIDE NO.	FIGURE END NO.	FIGURE CYL SURFACE
3900	3901	3902	3903	3904	3905
3906	3907	3908	3909	3910	3911
3912	3913	3914	3915	3916	3917
3918	3919	3920	3921	3922	3923
3924	3925	3926	3927	3928	3929
*6	*6	*13	*4	*4	*7
COL 1	2	3	4	5	6

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. The table will appear in Section 3 of the MSE.

Supersedes page 163 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE IV. FREQUENCY RESPONSE
(See 5.20)

FREQUENCY RESPONSE TABLE

REF NO.	CHANNEL	TONE CONT	VEL RNG SW POS	APPLIED TEST VOLTAGE: PLRT AND VALUE	APPLIED TEST VOLTAGE: UNITS	APPLIED TEST VOLTAGE: PCT TOL
1	2500	2501	2502	2503	2504	2505
2	2506	2507	2508	2509	2510	2511
3	2512	2513	2514	2515	2516	2517
4	2518	2519	2520	2521	2522	2523
5	2524	2525	2526	2527	2528	2529
6	2530	2531	2532	2533	2534	2535
7	2536	2537	2538	2539	2540	2541
8	2542	2543	2544	2545	2546	2547
9	2548	2549	2550	2551	2552	2553
10	2554	2555	2556	2557	2558	2559
	*18	*8	*7	*6	*13	*4
COL 1	2	3	4	5	6	7

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. Columns 1-15 will appear in Section 4 of the MSE and columns 1 and 16-20 will appear in Section 3 of the MSE.

Supersedes page 164 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 202610-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE IV. FREQUENCY RESPONSE (CONT)

(See 5.20)

FREQUENCY RESPONSE TABLE (CONT)

	APPLIED						
	FREQUENCY DISCRETE			FREQUENCY RANGE			
				FROM		TO	
REF NO.	VAL	UNITS	TOL	VAL	UNITS	VAL	UNITS
1	2560	2561	2562	2563	2564	2565	2566
2	2567	2568	2569	2570	2571	2572	2573
3	2574	2575	2576	2577	2578	2579	2580
4	2581	2582	2583	2584	2585	2586	2587
5	2588	2589	2590	2591	2592	2593	2594
6	2595	2596	2597	2598	2599	2600	2601
7	2602	2603	2604	2605	2606	2607	2608
8	2609	2610	2611	2612	2613	2614	2615
9	2616	2617	2618	2619	2620	2621	2622
10	2623	2624	2625	2626	2627	2628	2629
	*4	*9	*4	*4	*9	*4	*9
COL 1	8	9	10	11	12	13	14

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. Columns 1-15 will appear in Section 4 of the MSE and columns 1 and 16-20 will appear in Section 3 of the MSE.

Supersedes page 165 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 202610-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE IV. FREQUENCY RESPONSE (CONT)
(See 5.20)

FREQUENCY RESPONSE TABLE (CONT)

		RESPONSE				
		SIGNAL VOLTAGE				
REF NO.	LOAD OHMS	PLRT AND VALUE	UNITS	PCT TOL	DB (+ OR -) MIN	MAX
1	2630	2631	2632	2633	2634	2635
2	2636	2637	2638	2639	2640	2641
3	2642	2643	2644	2645	2646	2647
4	2648	2649	2650	2651	2652	2653
5	2654	2655	2656	2657	2658	2659
6	2660	2661	2662	2663	2664	2665
7	2666	2667	2668	2669	2670	2671
8	2672	2673	2674	2675	2676	2677
9	2678	2679	2680	2681	2682	2683
10	2684	2685	2686	2687	2688	2689
	*4	*6	*10	*4	*4	*4
COL 1	15	16	17	18	19	20

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. Columns 1-15 will appear in Section 4 of the MSE and columns 1 and 16-20 will appear in Section 3 of the MSE.

Supersedes page 166 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE V. IMPEDANCE
(See 5.25)

IMPEDANCE TABLE

	APPLIED						RESPONSE		
	SIGNAL VOLTAGE			FREQUENCY DISCRETE					
REF NO.	PLRT AND VALUE	UNITS	PCT TOL	VALUE	UNITS	TOL	IMPD OHMS	INP OR OUT	MAX VSWR
1	2800	2801	2802	2803	2804	2805	2806	2807	2808
2	2809	2810	2811	2812	2813	2814	2815	2816	2817
3	2818	2819	2820	2821	2822	2823	2824	2825	2826
4	2827	2828	2829	2830	2831	2832	2833	2834	2835
5	2836	2837	2838	2839	2840	2841	2842	2843	2844
6	2845	2846	2847	2848	2849	2850	2851	2852	2853
	*6	*10	*4	*5	*10	*4	*4	*6	*4
COL	1 2	3	4	5	6	7	8	9	10

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. Columns 1-7 will appear in Section 4 of the MSE and columns 1 and 8-10 will appear in Section 3.

Supersedes page 167 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE VI. LINEARITY

(See 5.27)

LINEARITY TABLE

	APPLIED						
	SIGNAL VOLTAGE			FREQUENCY DISCRETE			
REF NO.	PLRT AND VALUE	UNITS	PCT TOL	VALUE	UNITS	TOL	LOAD OHMS
1	2900	2901	2902	2903	2904	2905	2906
2	2907	2908	2909	2910	2911	2912	2913
3	2914	2915	2916	2917	2918	2919	2920
4	2921	2922	2923	2924	2925	2926	2927
5	2928	2929	2930	2931	2932	2933	2934
	*6	*10	*4	*5	*10	*4	*4
COL 1	2	3	4	5	6	7	8

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. Columns 1-8 will appear in Section 4 of the MSE and columns 1 and 9-11 will appear in Section 3 of the MSE.

Supersedes page 168 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE VI. LINEARITY (CONT)
(See 5.27)

LINEARITY TABLE (CONT)

REF NO.	RESPONSE SIGNAL VOLTAGE PLRT AND VALUE	UNITS	PCT TOL
1	2935	2936	2937
2	2938	2939	2940
3	2941	2942	2943
4	2944	2945	2946
5	2947	2948	2949
	*6	*10	*4
COL 1	9	10	11

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. Columns 1-8 will appear in Section 4 of the MSE and columns 1 and 9-11 will appear in Section 3 of the MSE.

Supersedes page 169 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE VII. PULSE RESPONSE

(See 5.30)

PULSE RESPONSE TABLE

		APPLIED PULSE AMPLITUDE				
REF NO.	TEST NAME	VOLTS + OR -	1 or 0 LOGIC	CURRENT MILLIAMP	CURRENT MICROAMP	PCT TOL
1	3200	3210	3220	3230	3240	3250
2	3201	3211	3221	3231	3241	3251
3	3202	3212	3222	3232	3242	3252
4	3203	3213	3223	3233	3243	3253
5	3204	3214	3224	3234	3244	3254
6	3205	3215	3225	3235	3245	3255
7	3206	3216	3226	3236	3246	3256
8	3207	3217	3227	3237	3247	3257
9	3208	3218	3228	3238	3248	3258
10	3209	3219	3229	3239	3249	3259
	*12	*6	*6	*8	*8	*4
COL 1	2	3	4	5	6	7

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. Columns 1-14 will appear in Section 4 of the MSE and columns 1 and 15-22 will appear in Section 3 of the MSE.

Supersedes page 170 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE VII. PULSE RESPONSE (CONT)

(See 5.29)

PULSE RESPONSE TABLE (CONT)

	APPLIED PULSE						
	WIDTH			PULSE RATE FREQUENCY			
REF NO	MICROSEC	NANOSEC	PCT TOL	VALUE	UNITS	PCT TOL	PT OF APPL
1	3260	3270	3280	3290	3300	3310	3320
2	3261	3271	3281	3291	3301	3311	3321
3	3262	3272	3282	3292	3302	3312	3322
4	3263	3273	3283	3293	3303	3313	3323
5	3264	3274	3284	3294	3304	3314	3324
6	3265	3275	3285	3295	3305	3315	3325
7	3266	3276	3286	3296	3306	3316	3326
8	3267	3277	3287	3297	3307	3317	3327
9	3268	3278	3288	3298	3308	3318	3328
10	3269	3279	3289	3299	3309	3319	3329
	*8	*7	*4	*5	*10	*4	*8
COL 1	8	9	10	11	12	13	14

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. Columns 1-14 will appear in Section 4 of the MSE and columns 1 and 15-22 will appear in Section 3 of the MSE.

Supersedes page 171 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE VII. PULSE RESPONSE (CONT)

(See 5.30)

PULSE RESPONSE TABLE (CONT)

		RESPONSE							
					AMPLITUDE				
	REF NO.	PULSE CHARACT	MICRO SEC	NANO SEC	PCT TOL	MIN V +OR-	PCT TOL	MAX TILT PCT	PT OF RESPONSE
	1	3330	3340	3350	3360	3370	3380	3390	3400
	2	3331	3341	3351	3361	3371	3381	3391	3401
	3	3332	3342	3352	3362	3372	3382	3392	3402
	4	3333	3343	3353	3363	3373	3383	3393	3403
	5	3334	3344	3354	3364	3374	3384	3394	3404
	6	3335	3345	3355	3365	3375	3385	3395	3405
	7	3336	3346	3356	3366	3376	3386	3396	3406
	8	3337	3347	3357	3367	3377	3387	3397	3407
	9	3338	3348	3358	3368	3378	3388	3398	3408
	10	3339	3349	3359	3369	3379	3389	3399	3409
		*20	*5	*4	*4	*5	*4	*4	*8
COL	1	15	16	17	18	19	20	21	22

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. Columns 1-14 will appear in Section 4 of the MSE and columns 1 and 15-22 will appear in Section 3 of the MSE.

Supersedes page 172 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE VIII. SPURIOUS OUTPUTS

(See 5.35)

SPURIOUS OUTPUTS TABLE

REF NO.	TEST NAME	CONDITION	TONE CONT	VEL RNG SW POS
1	DISTORTION	3500	3501	3502
2	DISTORTION	3503	3504	3505
3	DISTORTION	3506	3507	3508
4	DISTORTION	3509	3510	3511
5	DISTORTION	3512	3513	3514
6	DISTORTION	3515	3516	3517
7	HUM	3518	3519	3520
8	HUM	3521	3522	3523
9	HUM	3524	3525	3526
10	HUM	3527	3528	3529
11	HUM	3530	3531	3532
12	HUM	3533	3534	3535
13	NOISE	3536	3537	3538
14	NOISE	3539	3540	3541
15	NOISE	3542	3543	3544
	*10	*19	*8	*7
COL 1	2	3	4	5

*Number of print characters per column (column width).
Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. Columns 1-16 will appear in Section 4 of the MSE and columns 1, 2 and 17-22 will appear in Section 3 of the MSE.

Supersedes page 173 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE VIII. SPURIOUS OUTPUTS (CONT)

(See 5.35)

SPURIOUS OUTPUTS TABLE (CONT)

	APPLIED					
	SIGNAL VOLTAGE			FREQUENCY DISCRETE		
REF NO.	PLRT AND VALUE	UNITS	PCT TOL	VALUE	UNITS	HZ +OR- TOL
1	3545	3546	3547	3548	3549	3550
2	3551	3552	3553	3554	3555	3556
3	3557	3558	3559	3560	3561	3562
4	3563	3564	3565	3566	3567	3568
5	3569	3570	3571	3572	3573	3574
6	3575	3576	3577	3578	3579	3580
7	3581	3582	3583	3584	3585	3586
8	3587	3588	3589	3590	3591	3592
9	3593	3594	3595	3596	3597	3598
10	3599	3600	3601	3602	3603	3604
11	3605	3606	3607	3608	3609	3610
12	3611	3612	3613	3614	3615	3616
13	3617	3618	3619	3620	3621	3622
14	3623	3624	3625	3626	3627	3628
15	3629	3630	3631	3632	3633	3634
	*5	*10	*4	*5	*10	*4
COL 1	6	7	8	9	10	11

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes were used will print. Columns 1-16 will appear in Section 4 of the MSE and columns 1, 2 and 17-22 will appear in Section 3 of the MSE.

Supersedes page 174 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE VIII. SPURIOUS OUTPUTS (CONT)
(See 5.35)

SPURIOUS OUTPUTS TABLE (CONT)

REF NO.	APPLIED FREQUENCY RANGE FROM VALUE	FROM UNITS	TO VALUE	TO UNITS	LOAD OHMS
1	3635	3636	3637	3638	3639
2	3640	3641	3642	3643	3644
3	3645	3646	3647	3648	3649
4	3650	3651	3652	3653	3654
5	3655	3656	3657	3658	3659
6	3660	3661	3662	3663	3664
7	3665	3666	3667	3668	3669
8	3670	3671	3672	3673	3674
9	3675	3676	3677	3678	3679
10	3680	3681	3682	3683	3684
11	3685	3686	3687	3688	3689
12	3690	3691	3692	3693	3694
13	3695	3696	3697	3698	3699
14	3700	3701	3702	3703	3704
15	3705	3706	3707	3708	3709
	*5	*10	*5	*10	*4
COL 1	12	13	14	15	16

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes are used will print. Columsn 1-16 will appear in Section 4 of the MSE and columns 1, 2 and 17-22 will appear in Section 3 of the MSE.

Supersedes page 175 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 2026-10-23T21:02Z
Check the source to verify that this is the current version before use.

TABLE VIII. SPURIOUS OUTPUTS (CONT)

(See 5.35)

SPURIOUS OUTPUTS TABLE (CONT)

	RESPONSE					
	SIGNAL VOLTAGE					
REF NO.	PLRT AND VALUE	UNITS	PCT TOL	MIN OR MAX	MAX DB (+ OR -)	MAX PCT
1	3710	3711	3712	3713	3714	3715
2	3716	3717	3718	3719	3720	3721
3	3722	3723	3724	3725	3726	3727
4	3728	3729	3730	3731	3732	3733
5	3734	3735	3736	3737	3738	3739
6	3740	3741	3742	3743	3744	3745
7	3746	3747	3748	3749	3750	3751
8	3752	3753	3754	3755	3756	3757
9	3758	3759	3760	3761	3762	3763
10	3764	3765	3766	3767	3768	3769
11	3770	3771	3772	3773	3774	3775
12	3776	3777	3778	3779	3780	3781
13	3782	3783	3784	3785	3786	3787
14	3788	3789	3790	3791	3792	3793
15	3794	3795	3796	3797	3798	3799
	*5	*10	*4	*3	*8	*4
COL 1	17	18	19	20	21	22

*Number of print characters per column (column width). Heading spans are shown by underlining.

Codes selected from the table and entered on the SRS along with the desired data will cause the computer to generate the table and enter the data in the respective cells. Only those lines from which codes are used will print. Columns 1-16 will appear in Section 4 of the MSE and columns 1, 2 and 17-22 will appear in Section 3 of the MSE.

Supersedes page 176 of 30 June 1976.

Source: https://assist.dla.mil -- Downloaded: 202610-23T21:02Z
Check the source to verify that this is the current version before use.