INCH-POUND
MIL-R-55347B(CR)
AMENDMENT 1
22 November 1988

# MILITARY SPECIFICATION
# RADIO TELETYPEWRITER SET AN/GRC-142( )/ AN/GRC-122( )

This amendment forms a part of MIL-R-55347B(EL), dated 14 April 1978, and is approved for use within the Communications Electronics Command, Department of the Army, and is available for use by all Departments and Agencies of the Department of Defense.

PAGE 2

2.1: Delete MIL-P-116 and MIL-S-55505.
Add:

| | |
|---|---|
| "SC-F-960637 | AN/GRC-122/142D and E Power Schematic |
| SC-F-960696 | Signal Schematic Diagram AN/GRC-122/142D and E |
| SC-F-960672 | Panel Assembly Power Distribution" |

PAGE 3

3.3.1.2: Delete SC-F-595036 and substitute SC-F-960637.

PAGE 5

3.5c: Delete Teletypewriter TT-98( )/FG and substitute "Communications Terminal AN/UGC-74( )". Delete TT-98( )/FG and substitute "AN/UGC-74( )" two places.

3.5f: Delete 200 F and substitute "230 F".

3.7 Vibration operation: Add the following sentence: "Test shall be performed on components listed in 4.12.1."

PAGE 12

4.2c(1) & (2): Delete and substitute:

"4.2c Quality conformance inspection of equipment before packaging (see 4.5)."

AMSC - N/A FSC 5815
DISTRIBUTION STATEMENT A. Approved for public release; distribution is unlimited.



Source: https://assist.dla.mil -- Downloaded: 2026-10-22T23:13Z
Check the source to verify that this is the current version before use.

PAGE 19

4.6 Bounce preconditioning: Add the following sentence: "The bounce preconditioning shall be performed on components sited in 4.20."

PAGE 20

4.8.1d: Delete

PAGE 22

4.8.2.1: Delete and substitute:

"4.8.2.1 Continuity of the conductors test. Continuity resistance tests to determine conformance with the requirements of 3.3.1.1 shall be performed on each power circuit in accordance with the paragraphs below. A calibrated low resistance reading ohmmeter or equivalent shall be used in performing the test. (Refer to Drawing SC-F-960637)."

a Place the following circuits in the ON position.

(1) Main AC circuit breaker CB1.

(2) PWR SPLY DC circuit breaker CB2.

(3) ELECT HTR circuit breaker CB3.

(4) TTY & AUX EQUIP BLWR circuit breaker CB4.

(5) LTS & CONV SHLTR BLWR circuit breaker CB5.

(6) DC MAIN circuit breaker CB6.

(7) RADIO TTY EQUIP BLWR circuit breaker CB7.

(8) UGC-74 AUX circuit breaker CB8.

(9) LTS SHLTR BLWR circuit breaker CB9.

(10) GAS HTR circuit breaker CB10.

b Place AC/DC control switch to AC position.

c Measure continuity resistance from pin A of AC power input connector located at power entrance box to the following:

(1) Pin X of J5 connector at power terminal assembly.



Source: https://assist.dla.mil -- Downloaded: 2026-10-22T23:13Z
Check the source to verify that this is the current version before use.

(2) Pin M of P2 connector located at curbside UGC-74.

(3) Brass contact of J7A connector located at equipment blower.

(4) Pin M of P1 connector located at front UGC-74.

(5) Pin C of 115 VAC AUX EQUIP connectors attached to curbside and roadside racks holding auxiliary equipment.

(6) Brass contacts of J4 & J5 CONV outlets.

(7) Brass contacts of J6 connector located at heater.

d Place power supply and main circuit breakers CB2 and CB1 in the OFF position.

e Measure continuity resistance from Pin B of AC power input connector to the following:

(1) Pin Y of J5 connector located at power terminal assembly.

(2) Pin K of P2 connector located at curbside UGC-74.

(3) Silver contact of J7A connector located at equipment blower.

(4) Pin K of P1 connector located at front UGC-74.

(5) Pin A of 115 VAC AUX EQUIP connectors attached to curbside and roadside racks holding auxiliary equipment.

(6) Silver contacts of J4 & J5 CONV outlets.

(7) Silver contact of J6 connector located at heater.

f Measure continuity resistance from Pin C of AC power input connector to ground stud (E31) at power entrance box.

g Place AC/DC control switch to DC position.

h Measure continuity resistance from Pin A of DC power input connector to the following:

(1) Pin A of power in connector to the multifuel heater.



Source: https://assist.dla.mil -- Downloaded: 2026-10-22T23:13Z
Check the source to verify that this is the current version before use.

(2) Pin A of the power connectors to AM-3349, RT-662 or RT-834 and MD-522.

(3) Pin A of inverter power in connector.

i Place all remaining circuit breakers in the OFF position.

j Measure continuity resistance from Pin C of DC power input connector to the following:

(1) Pin D of DC power input connector.

(2) Ground stud (E31) located at power entrance box.

(3) Pin C of the power input connector to the multifuel heater.

(4) Pin W of connector J5 located at the power terminal assembly.

(5) Pin C of the power connectors to AM-3349, RT-662 or RT-834 and MD-522.

(6) Pin C of power input connector to the inverters.

PAGE 25

4.8.2.2.2i: Delete.

PAGE 26

4.8.2.2.3j: Delete CB2 and substitute "CB7". Delete Motor Generator and substitute "inverter".

PAGE 27

4.8.3.1: Delete SC-F-595035 and substitute SC-F-960696.

PAGE 28

4.8.3.1.1 TABLE V Continuity Measurements: Delete J.9 and substitute "J19".

PAGE 32

4.9.1a: Delete Teletypewriter TT-98( )/FG and substitute "Communications Terminal AN/UGC-74( )". Delete AN/DC and substitute "AC/DC". Delete SB-3358/GRC-142.



Source: https://assist.dla.mil -- Downloaded: 2026-10-22T23:13Z
Check the source to verify that this is the current version before use.

PAGE 33

4.9.1j: Delete TT-98( )/FG and substitute "AN/UGC-74( )", two places.

PAGE 34

4.9.2a: Delete TT-98( )/FG and substitute "AN/UGC-74( )".

4.9.2e: Delete TT-98( )/FG and substitute "AN/UGC-74( )".

PAGE 36

4.10h(3): Delete TT-98( )/FG and substitute "AN/UGC-74( )" two places.

PAGE 37

4.11.1a(4): Delete TT-98( )/FG and substitute "AN/UGC-74( )".

4.11.1a(5): Delete AUX TT-98( )/FG and substitute "AUX AN/UGC-74( )".

PAGE 38

4.12.1b: Delete and substitute:

"4.12.1b Power Distribution Panel SC-D-960672."

4.12.2: Delete Continuous monitoring of all electrical circuits is required and substitute "Measurements shall be taken before and after each vibration."

PAGE 41

4.17: Delete 1 1/2 ton, M-715 truck and substitute " 1 1/4 ton, M-880( ) or M-1028( ) truck."

PAGE 43

4.19b: Delete and substitute:

"4.19b Power Distribution Panel SC-D-960672."

4.20b: Delete and substitute:

"4.20b Power Distribution Panel SC-D-960672."



Source: https://assist.dla.mil -- Downloaded: 2026-10-22T23:13Z
Check the source to verify that this is the current version before use.

PAGE 45

4.21: Delete MIL-STD-462 with Notice 3 and substitute "MIL-STD-461". Delete MIL-STD-462 and substitute "MIL-STD-461".

PAGE 47

4.26: Delete.

4.27: Delete.

PAGE 48

5.1: Delete and substitute:

"5.1 Packaging requirements. The packaging requirements for the desired level(s) of protection shall be as specified by the acquisition activity (see 6.2)."

6.2h: Delete.

Custodian:
ARMY - CR

Preparing Activity:
ARMY - CR

(Project No. 5815-A132)



Source: https://assist.dla.mil -- Downloaded: 2026-10-22T23:13Z
Check the source to verify that this is the current version before use.