BY ORDER OF THE SECRETARY OF THE AIR FORCE

AFI 11-2C-130V3 CL-9
17 APRIL 2000

Flying Operations

MAFFS OPERATIONS
COCKPIT CREW MAFFS CHECKLIST

This checklist establishes procedures for the operation of C-130 aircraft employed by Mobility Air Forces (MAF) to accomplish their worldwide missions.

This checklist complements AFI 11-2C-130V3, *C-130 Operations Procedures*, and is printed on standard 8 ½" x 11" bond paper then trimmed to a unique size 4 ½ " x 6 ½" that will fit the standard plastic C-130 aircrew checklist binders. Units may request copies of this checklist printed on a water proof-based media (in the size outlined) from the OPR. This product reduces weight and eliminates the need for plastic inserts. Limit water proof copies to aircrew only for use in-flight and training purposes.

Summary of Revisions: Corrected checklist step placement.

PART ONE - NORMAL PROCEDURES

PRE-SLOWDOWN CHECKLIST 2
SLOWDOWN CHECKLIST..... 3
ONE MINUTE WARNING CHECKLIST 3
RELEASE POINT CHECKLIST 4
COMPLETION OF DROP CHECKLIST..... 4

Supersedes AFI 11-2C-130V3 CL-9, 1 April 2000
OPR: HQ AMC/DOV (CMS Finnegan)
Certified by: HQ USAF/XOO (Maj Gen Michael S. Kudlacz)
Number of Printed Pages: 10 / Distribution: F

PART TWO - EMERGENCY PROCEDURES

EMERGENCY DROP AFTER TAKEOFF..... 4
EMERGENCY DROP PROCEDURES 6
(AFT CARGO DOOR CLOSED AND TUBES RETRACTED)
EMERGENCY DROP WITHOUT ELECTRICAL POWER 8
(AFT CARGO DOOR CLOSED AND TUBES RETRACTED)
EMERGENCY DROP WITHOUT PNEUMATIC POWER 9
(AFT CARGO DOOR CLOSED AND TUBES RETRACTED)

PART ONE - NORMAL PROCEDURES

PRE-SLOWDOWN CHECKLIST

1. **"CREW, PRE-SLOWDOWN CHECKLIST"** (P)
2. **"PRE-SLOWDOWN CHECKLIST ACKNOWLEDGED LOADMASTER"** (LM)
3. Pressurization - Begin Depressurizing (E)
4. Stall Speeds - **"REVIEWED"** (P, CP, E)
5. Altimeters - **"SET"** (State Setting) (P, CP)
6. Radar Altimeters - **"SET"** (State Setting) (P)
7. Landing Gear Warning Light Circuit Breaker - PULLED (E)
8. GPWS Circuit Breaker - PULLED (Some Airplanes) (E)
9. Pressurization - No Pressure (E)
10. **"PRE-SLOWDOWN CHECKS COMPLETE"** (LM, E)

SLOW-DOWN CHECKLIST

1. Flaps - **"SET"** (As Required) (CP)
2. Landing Lights - **"SET"** (Extended/ON) (CP)
3. Ramp and Door - **"CLEAR TO OPEN"** (E)

NOTE

The aft cargo ramp and door will not be cleared to open until the aircraft is below 150 knots

NOTE

The aft cargo ramp and door will be operated by the LM from the rear of the aircraft.

4. Air Conditioning Panel - AUTO (E)
5. Armed Light - **"ON"** (CP)

NOTE

If using the incremental unit the armed light will not be on until the final drop.

6. **"SLOWDOWN CHECKS COMPLETE"** (LM, E)

ONE MINUTE WARNING CHECKLIST

1. **"CREW, ONE MINUTE WARNING"** (P)
2. **"ONE MINUTE WARNING ACKNOWLEDGED LOADMASTER"** (LM)
3. Engine Bleed Valves - **"SET"** (As Required) (E)
4. Release Point and Escape - **"REVIEWED"** (P, CP)

RELEASE POINT CHECKLIST

1. **"READY, READY, DROP"** (CP)
2. Status of Load - **"LOAD CLEAR"** (Or Condition) (LM)
3. **Flaps -** " 50 PERCENT" **(CP)**

COMPLETION OF DROP CHECKLIST

1. Engine Bleed Valves - **"SET"** (As Required) (P, E)
2. Landing Gear Warning Light Circuit Breaker - RESET (E)
3. GPWS Circuit Breaker - RESET (Some Airplanes) (E)
4. Air Conditioning Panel - No Pressure (E)
5. Landing Lights Retracted/OFF - **"SET"** (CP)
6. Flaps - **"UP"** (CP)
7. Pressurization - As required. (E)

NOTE

Insure that the door light is out prior to setting the pressure.

8. **"DROP CHECKS COMPLETE"** (LM, E)

PART TWO - EMERGENCY PROCEDURES

EMERGENCY DROP AFTER TAKEOFF

1. Emergency Drop - **"CLEARED TO DROP"** (P)

WARNING

Stand clear of discharge valve actuator.

2. EMERGENCY DROP Button - Depress (P, LM)

NOTE

Immediately dial up pressure regulator setting to 40 PSI

3.Status of Load - "LOAD CLEAR" **(State Condition) (LM)**

WARNING

Stand clear of discharge valve actuator.

NOTE

Actions 'a' through 'n' will be accomplished by the LM.

a. Selector Knob - CLOSE DROP

b. CLOSE DROP Button - Depress and Hold until Drop Valves Close (If Required)

c. Selector Knob - CLOSE ARM and Depress Close Arm button

d. Tank Arm Switches - All DOWN/Lights OFF (If Applicable)

e. Selector Knob - OFF

f. Aux Pump - ON

g. Cargo Ramp - LOWERED upon clearance from Pilot

WARNING

Lowering the ramp will increase aerodynamic drag significantly. Ensure a safe altitude and airspeed can be maintained prior to lowering the ramp.

h. TUBES IN Button - Depress

i. Cargo Ramp - UP

j. Aft Cargo Door - CLOSED

k. Aux Pump - OFF

l. MAIN POWER Button - Depress/OFF

m. Circuit Breaker - OFF

n. Air Control Supply Valve - CLOSED

4. **"EMERGENCY DROP CHECKLIST COMPLETE"** (LM, E)

EMERGENCY DROP PROCEDURES
(Aft Cargo Door Closed & Tubes Retracted)

NOTE

This procedure assumes normal electrical and pneumatic power available to the MAFFS units.

1. Pressurization - **"EMERGENCY DEPRESSURIZE"** (E)
2. Ramp and Door - **"CLEARED TO OPEN"** (P)

WARNING

Lowering the ramp will increase aerodynamic drag significantly. Ensure a safe altitude and airspeed can be maintained prior to lowering the ramp.

3. Aux Pump - ON (LM)

NOTE

The aft cargo door and ramp will be operated by the LM from the rear of the aircraft.

4. Aft Cargo Door - OPEN (LM)
5. Cargo Ramp - LOWERED (LM)
6. Air Control Supply Valve - Checked OPEN (150 PSI) (LM)
7. TUBES OUT Button - Depress (LM)
8. Left and Right Tubes - Out and Locked (LM)
9. Emergency Drop - **"CLEARED TO DROP"** (P)

WARNING

Stand clear of the discharge valve actuator.

10. EMERGENCY DROP Button - Depress (LM)

11. Status of Load - **"LOAD CLEAR"** (State Condition) (LM)

WARNING

Stand clear of discharge valve actuator

NOTE

Actions a through l will be accomplished by the LM.

a. Selector Knob - CLOSE DROP

b. CLOSE DROP Button - Depress and Hold Until the Drop Valves Close (If Applicable)

c. Selector Knob - CLOSE ARM and Depress CLOSE ARM Button

d. Tank Arm Switches - All DOWN/Lights OFF (If Applicable)

e. Selector Knob - OFF

f. TUBES IN Button - Depress

g. Cargo Ramp - UP

h. Aft Cargo Door - CLOSED

i. Aux Pump - OFF

j. MAIN POWER Button - Depress/OFF

k. Circuit Breaker - OFF

l. Air Control Supply Valve - CLOSED

12. **"EMERGENCY DROP CHECKS COMPLETE"** (LM, E)

EMERGENCY DROP WITHOUT ELECTRICAL POWER

(Aft Cargo Door Closed & Tubes Retracted)

1. Pressurization - **"EMERGENCY DEPRESSURIZE"** (E)
2. Ramp and door - **"CLEARED TO OPEN"** (P)

WARNING

Opening the ramp and door will increase aerodynamic drag significantly. Ensure a safe altitude and airspeed can be maintained prior to lowering the ramp.

3. Aux Pump - ON (LM)

NOTE

The aft cargo ramp will be operated by the LM from the rear of the aircraft.

4. Aft Cargo Door - OPEN (LM)
5. Cargo Ramp - LOWERED (LM)
6. Emergency Drop - **"CLEARED TO DROP"** (P)

NOTE

Action ‘a’ through ‘c’ must be accomplished by the LM to complete the drop.

a. Air control supply valve - Checked OPEN (150 PSI)

b. Extend Nozzles Manually by Depressing OUT Button (B) on the Solenoid Located on the Ramp Pallet.

WARNING

Stand clear of discharge valve actuator.

c. Retardant - To Release Retardant, Depress OPEN (B) Control Button on Solenoid Located on Control Pallet; Retardant Will Gravity Drain.

7. Status of Load - **"LOAD CLEAR"** (State Condition) (LM)

WARNING

Stand clear of discharge valve actuator.

NOTE

Actions a through f will be accomplished by the LM.

a. Close Drop Valve - Depress CLOSE (A) Control Button on Control Pallet.

b. Nozzles - Retract Nozzles by Depressing IN Button (A) on Ramp Pallet.

c. Cargo Ramp - UP

d. Aft Cargo Door – CLOSED

e. Aux Pump - OFF

f. Air Control Supply Valve – CLOSED

8. **"EMERGENCY DROP CHECKS COMPLETE"** (LM, E)

EMERGENCY DROP WITHOUT PNEUMATIC POWER

(Aft Cargo Door Closed & Tubes Retracted)

1. Pressurization - **"EMERGENCY DEPRESSURIZE"** (E)
2. Ramp and Door - **"CLEARED TO OPEN"** (P)

WARNING

Opening the ramp and door will increase aerodynamic drag significantly. Ensure a safe altitude and airspeed can be maintained prior to lowering the ramp.

3. Aux Pump - ON (LM)

NOTE

The aft cargo door and ramp will be operated by the LM from the rear of the aircraft.

4. Aft Cargo Door - OPEN (LM)

5. Cargo Ramp - LOWERED (LM)

WARNING

Since an air charge of 150 PSI may be stored in the line, exercise extreme caution while disconnecting.

NOTE

Actions a through e must be accomplished by the LM to complete the drop.)

a. Air Line to Ramp Pallet - Disconnected

b. Tubes - Manually Push each tube to the OUT Position

c. Emergency Selector Valves - MANUAL

WARNING

Stand clear of discharge valve actuator.

d. Emergency Air Cylinder Valve - OPEN

e. Retardant - Allow to Gravity Drain

6. Status of Load - **"LOAD CLEAR"** (State Condition) (LM)

7. Cargo Ramp - UP (LM)

CAUTION

Because of the inability to retract the tubes, the cargo door must not be closed.

8. Aux Pump - OFF (LM)

9. "EMERGENCY DROP CHECKS COMPLETE" (LM, E)

MARVIN R. ESMOND, Lt General, USAF
DCS/Air and Space Operations