BY ORDER OF THE COMMANDER
934TH AIRLIFT WING

934 AIRLIFT WING INSTRUCTION
21-112

19 AUGUST 2026

Maintenance

HANGAR DOOR OPERATIONS

COMPLIANCE WITH THIS PUBLICATION IS MANDATORY

ACCESSIBILITY: Publication and forms are available on the e-publishing website at **www.e-Publishing.af.mil** for downloading or ordering

RELEASABILITY: There are no releasability restrictions on this publication

---

OPR: 934MXG/MXQ

Certified by: 934MXG/CC
(Colonel Amy S. Johannsen)

Supersedes: 934AWI21-112, 17 June 2016

Pages: 8

This instruction implements Air Force Policy Directive (DAFPD) 21-1, *Air and Space Maintenance.* This instruction extends the guidance Department of the Air Force Instruction (DAFI) 21-101 AFRC Supplement, *Aircraft and Equipment Maintenance Management;* DAFMAN 91-203, *Occupational Safety Fire and Health Standards*. It provides safety guidelines and designates responsibility for training, qualification, and documentation for personnel who operate hangar doors. It applies to all users and maintainers of this equipment. Refer recommended changes and questions about this publication to the Office of Primary Responsibility (OPR) using the Air Force Form 847, *Recommendation for Change of Publication;* route AF Form 847 from the field through the appropriate functional chain of command. Ensure that all records created as a result of processes prescribed in this publication are maintained in accordance with Air Force Instruction (AFI) 33-322, *Records Management and Information Governance Program*, and disposed of in accordance with Air Force Records Information Management System (AFRIMS) Records Disposition Schedule (RDS).

SUMMARY OF CHANGES

This publication has been substantially revised and must be completely reviewed. Changes have been made to update organizational names, office symbols, and operating procedures since the previous version.

1. Responsibilities.

1.1. Commanders and Supervisors will ensure only properly trained and qualified personnel operate hangar doors.

1.2. Mission Support Group (MSG)/Civil Engineer (CE)

1.2.1. MSG/CE will be responsible for the installation and repair of signage, floor safety markings, and repair of hangar doors including electrical, mechanical, and all warning devices.

1.2.2. The MSG/CE Facility Maintenance section will conduct annual inspections to ensure all the mechanical and electrical components are operating correctly.

1.2.2.1. For door maintenance issues, call MSG/CE trouble desk at extension 713-1918.

2. General.

2.1. This Air Wing Instruction (AWI) applies to the following hangar doors:

2.1.1. Building 821 North door, 821 South and the South hangar door in building 870.

2.2. All operators must be trained by a qualified trainer annually. Training must include physical operation of hangar doors prior to certification of each specific hangar door.

2.3. Hangar door trainers are personnel who are qualified to operate powered doors. They must be thoroughly familiar with all Air Force Instructions, Operating Instructions, and all precautions pertaining to safe hangar door operations.

2.4. Written door operating instructions will be posted next to all door control switches.

2.4.1. See **attachment 2** for building 821 and **attachment 3** for building 870.

3. Training.

3.1. Awareness training is required for personnel routinely working in hangars 821/870 or require access through hangars 821/870 hangar doors. Awareness training will highlight hazards, precautions taken during door operation, and operational safety. Awareness training is not operator training.

3.1.1. Awareness training plan is MS PowerPoint presentation, maintained by Maintenance Group Training office (MXG/MXOT).

3.1.2. Awareness training for MXG personnel will be documented in Maintenance Information System (G081) using course code SAFE001101.

3.1.3. Awareness training is an annual requirement.

3.2. Hangar door operator training is for personnel engaged in hangar door operations.

3.2.1. Operator training consists of lesson plans maintained by MXG/MXOT, hangar door safety awareness training, this 934th AWI 21-112, and DAFI 91-203.

3.2.2. Operator training for MXG personnel will be documented in G081 using course code MARB000821 for hangar 821 north and south doors, MARB000870 for hangar 870 south doors.

3.2.3. Non-MXG personnel may request hangar door operator training through MXG/MXOT and MXQ/QA.

3.3. Requests for training will include a formal written request identifying individual(s), will provide a justification statement, and will be addressed from requestor's squadron commander to MXG/CC.

4. Procedures.

4.1. All operators will refer to and comply with detailed checklists posted on the applicable hangar door (See **attachment 2** for building 821 and **attachment 3** for building 870).

4.1.1. Each building door listed has specific operating characteristics and has a different course code assigned in G081.

4.2. If automatic power door opener fails to operate, contact building manager and/or MSG/CE Trouble desk at 713-1918.

SAMUEL J. KRAEMER, Colonel, USAF
Commander

Attachment 1

GLOSSARY OF REFERENCES AND SUPPORTING INFORMATION

References

AFPD 21-1, *Air and Space Maintenance,* 25 February 2003

DAFI 21-101, AFRC SUP 1, *Aircraft and Equipment Maintenance Management,* 27 March 2026

DAFI 91-203, *Air Force Consolidated Safety Instruction,* 23 February 2026

AFMAN 33-363, *Management of Records,* 1 March 2008.

Prescribed Forms

None.

Adopted Form

DAF847, *Recommendation for Change of Publication*

DAF Form 797, *Job Qualification Standard Continuation*

AF Form 2426, *Training Request and Completion Notification*

Abbreviations and Acronyms

AF—Air Force

AFPD—Air Force Policy Directive

AFRC—Air Force Reserve Command

AFRIMS—Air Force Records Information Management System

AWI—Airlift Wing Instruction

CE—Civil Engineer

DAFI—Department of the Air Force Manual

G081—Maintenance Information System

MSG—Mission Support Group

MXG/CC—Maintenance Group Commander

MXG—Maintenance Group

MXOT—Maintenance Group Training

OPR—Office of Primary Responsibility

POC—Point of Contact

QA—Quality Assurance

RDS—Records Disposition Schedule

Attachment 2

BUILDING 821 HANGAR DOOR OPERATION CHECKLIST

Figure A2.1. Building 821 Hangar Door Operation Checklist.

HANGAR 821 NORTH AND SOUTH DOORS
ALL PERSONNEL WILL BE QUALIFIED/TRAINED PRIOR TO HANGAR DOOR OPERATION
NOTE: 1.) If door malfunctions, contact building manager and /or MSG/CE Trouble desk at Extension 1918. 2.) Doors will begin to move approximately 5 seconds after alarm sounds if main door alarm does not sound, Notify MSG/CE 3.) Main Doors must be fully open **BEFORE** opening Overhead tail-door. 4.) Overhead tail door controls are on the west wall of 821S, and the east wall 821N.
CAUTION: 1.) Hearing protection is required during any hangar door operation. 2.) While doors are moving, continually monitor to ensure doors are clear of obstructions, personnel, equipment, and aircraft. 3.) Never use vehicles to open or close hangar doors. 4.) During winter months do not open North and South hangar doors at the same time. a. To prevent inadvertent activation of fire alarm and freezing of water lines only open hangar doors necessary to move aircraft and equipment, close doors immediately after movement.
PRE-OPERATIONS CHECKLIST

1.) Locate and inspect pinch points and crush point areas for obstructions.	
2.) Inspect hangar door tracks for debris and both doors and tracks for damage.	
3.) Ensure the area is clear of equipment, aircraft, and personnel both inside and out.	
4.) Ensure all personnel entry doors are closed and latched.	
5.) Ensure Tail door is down/closed prior to operation of main doors.	

Attachment 3

BUILDING 821 HANGAR DOOR OPERATION PROCEDURE

Figure A3.1. Building 821 Hangar Door Operation Procedure.

OPENING HANGAR DOORS IN BUILDING 821
1.) At main door, center section, push the appropriate control button identified by the arrows. 2.) To ensure the safety of personnel, the hangar doors must be opened at a **minimum of 10 feet** and brought to a complete stop prior to entering or exiting through the doors. 3.) Open the main horizontal doors all the way to the wing tip clearance line before aircraft movement through door area. 4.) Open overhead tail door fully before aircraft movement through door area, ensure red alignment marks match up on outside of tail door.
CLOSING HANGAR DOORS IN BUILDING 821
1.) Fully close the overhead tail door first, before closing main hangar doors. 2.) At the main door, center section, push the appropriate control buttons identified by arrows, hold the button until door is closed. 2.1.) If the door is to remain partially open, ensure that a **minimum of 10 feet** of clearance is available 2.2.) Ensure that the door has stopped moving prior to passing through opening.
EMERGENCY PROCEDURES
NOTE: 1.) In the event of electrical failure, hangar doors can be operated manually by building manager or CE personnel.
Main Door Manual Procedures 1.) Open the panels located on each center door section. 2.) Pull the clutch disengage handle, located on each side of the center door. 3.) Manually push the doors into position.
Overhead Door Manual Procedures 1.) Gain access to the hangar roof, move to a position above the overhead door. 2.) Pull the cable to engage the chain drive. 3.) Pull the chain until the overhead door is in the fully open position.

Attachment 4

BUILDING 870 HANGAR DOOR OPERATION CHECKLIST

Figure A4.1. Building 870 Hangar Door Operation Checklist.

HANGAR 870 DOORS

ALL PERSONNEL WILL BE QUALIFIED/TRAINED PRIOR TO HANGAR DOOR OPERATION

NOTE:

1.) If door malfunctions, contact building manager and /or MSG/CE Trouble desk 7131918.
2.) Doors will begin to move approximately 5 seconds after alarm sounds.
a. If main door alarm does not sound, contact MSG/CE.
3.) Overhead tail door must be fully open **BEFORE** opening Main Doors.

CAUTION:

1.) Hearing protection is required during any hangar door operation.
2.) Never use vehicles to open or close hangar doors.
3.) Hangar 870 has a low temperature alarm for water deluge system
a. During winter months open hangar doors necessary to move aircraft and equipment, close doors immediately after movement to prevent inadvertent activation of fire alarm and the freezing of water lines.

4.) While doors are moving, continually monitor to ensure the doors are clear of obstructions, personnel, equipment, and aircraft.

5.) Only in an emergency situation where the tail door chains cannot be reached will the main doors be opened or closed, while the overhead door is closed.

PRE-OPERATION CHECKLIST

1. Locate and inspect the pinch points and crush point areas for obstructions.	
2. Inspect the hangar door tracks for debris and both doors and tracks for damage.	
3. Ensure the area is clear of equipment, aircraft, and personnel both inside and out.	
4. Ensure all personnel entry doors are closed and latched.	
5. Ensure alcoves are clear of equipment and personnel.	
6. Ensure tail door is up/open prior to operation of main doors.	

Attachment 5

BUILDING 870 HANGAR DOOR OPERATION PROCEDURE

Figure A5.1. Building 870 Hangar Door Operation Procedure.

OPEN HANGAR DOORS BUILDING 870

1.) Open the overhead tail door to the fully open position first, before any aircraft movement through the door area.

a. The overhead tail door controls are on the east wall of hangar 870, push the appropriate control buttons, they are identified by the arrows.

2.) At the main horizontal door, center section, push the appropriate control buttons they are identified by the arrows.

3.) Fully open the main horizontal doors to the wing tip clearance line, before any aircraft movement through the door area.

a. To ensure the safety of personnel, all hangar doors must be opened to a **minimum of 10 feet** and will be brought to a complete stop, prior to entering or exiting through doors.

CLOSING HANGAR DOORS BUILDING 870

1.) Fully open the overhead tail door prior to closing main horizontal doors.

a. Overhead tail door controls are on the east wall of hangar 870 push appropriate control button identified by the arrows.

2.) At the main horizontal door, center section, push the appropriate control buttons, they're identified by the arrows.

3.) Close the overhead tail door, only after fully closing the main hangar doors.

4.) To ensure the safety of personnel, the hangar doors must remain open at a **minimum of 10 feet** and will be brought to a complete stop, prior to entering or exiting through doors.

EMERGENCY PROCEDURES

NOTE:

1.) In the event of electrical failure, hangar doors can be operated manually by building manager or CE personnel.

Main Door Manual Procedures	Overhead Tail Door Manual Procedures
1.) Open appropriate center door panel. 2.) Pull clutch disengage handle. 3.) Manually push door into position.	1.) Gain access inside bottom of tail door. 2.) Pull cable to engage chain drive. 3.) Pull chain until overhead door is in position.