

- The **Read-Only Attributes of the Material Flow Objects**.

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
NumPartsSinceSetup	0			-> integer
NumPred	1			-> integer
NumSucc	3			-> integer

Name of the read-only attribute Current value of the read-only attribute Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected **Class** [general description].
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected **Instance** [general description].

To query the value of a *read-only attribute*, you might, for example, type:

```
print Store.Capacity
```

Capacity [SimTalk] - Store

Returns the capacity of the *Store* designated by <Path>.

Remarks

The *Capacity* is the product of *XDim* times *YDim* times *ZDim*.

Type

Read-only attribute

Syntax

```
<Path>.Capacity → integer
```

Watchable

The read-only attribute is [watchable](#).

Return Value

The return value has the data type *integer*.

Example

```
if MyStore.Capacity <= lotsize  
    @.move(MyStore)  
end
```

SimTalk

[XDim \[SimTalk\] - Store](#)

[YDim \[SimTalk\] - Store](#)

[ZDim \[SimTalk\] - Store](#)

See also

[X-Dimension \[Store\]](#)

[Y-Dimension \[Store\]](#)

Z-Dimension [Store]

Stock.MyPartName [SimTalk]

Returns the current stock of the parts designated by *MyPartName* in the *Store* designated by <Path>.

Remarks

MyPartName is the name of the respective part, which you set in the **Configuration Table** of the *Store*.

Type

Read-only attribute

Syntax

```
<Path>.Stock.MyPartName → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyStore.Stock.PartRed  
// might, for example, return 1
```

See also

[Configuration \[button\]](#)

Attributes of the Store

Attributes of the Store

The *Store* provides:

- The *attributes* listed in the table of contents to the left.
- The [Attributes of All Objects](#).
- The [Attributes of the Material Flow Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.